

ASSEMBLY INSTRUCTIONS

# RESIN GARDEN SHED

SKU: T-PS24-0697

Patiowell,  
Store  
Your  
Patio Well

[www.patiowell.com](http://www.patiowell.com)



**Patiowell**  
Resin Garden House  
Installation Tutorial  
[https://www.patiowell.com/  
pages/video-T-PS24-0697](https://www.patiowell.com/pages/video-T-PS24-0697)


✉ [saleservice@patiowell.com](mailto:saleservice@patiowell.com)

# SITE PREPARATION

Level the ground surface.



Recommendation: Construct a wooden or concrete base as a foundation.



## BEFORE STARTING ASSEMBLY

Remove all of the pieces from the 4 packages and spread them out on the ground. Before installation, please check the type and quantity of parts first.


It is recommended to use a clean work surface to spread the parts out and for pre-assembly steps. Review all instructions before you begin, continue to refer to instructions during assembly.

Be sure to follow all steps thoroughly.

Please prepare these components in advance at the beginning of each stage.



## REQUIRED TOOLS



## CAUTION


Some parts have steel edges. Please be careful when handling components. Always wear work gloves, eye protection and long sleeves when assembling or performing any maintenance on your shed. Do not attempt assembly on days with strong winds or low temperatures.




Requires two people and takes 1-2 hours for Installation.  
Recommended to wear gloves to avoid scratches.  
Please read the manual carefully before installation.

DO NOT RETURN YOUR UNIT  
TO THE STORE  
**Contact us first**  
[saleservice@patiowell.com](mailto:saleservice@patiowell.com)


# FLOOR PARTS




A1 X2




A2 X8



A3 X2



A4 X8



A5 X1

# WALL PARTS



B1 X2



BJ1 X4













DK-1 X1








DK-2 X1


# WALL PARTS

 <p>B1-1 X11</p>	 <p>BJ2 X2</p>	 <p>B1-2 X1</p>	 <p>B1-4 X1</p>
		 <p>B1-3 X1</p>	 <p>10-B2 X18</p>
 <p>10-B3 X2</p>		 <p>10-B4 X2</p>	
 <p>10-B6 X2</p>		 <p>B5 X6</p>	


# WINDOW PARTS

 <p>W1 X2</p>	 <p>W2 X2</p>	 <p>W4 X2</p>	 <p>W5 X2</p>
 <p>W3 X2</p>			

# ROOF PARTS




10-E1 X12




10-E2 X2




E3 X4




10-E4 X2




F1 X10




F2 X5



10-F4 X2



DK-3 X1









10-E11 X2











E12 X2

















# ROOF PARTS

 <p>C1 X1</p>	 <p>C2 X1</p>		
 <p>F3 X5</p>	 <p>F5 X10</p>	 <p>C3 X2</p>	




























# DOOR PARTS

 <p>D1 X2</p>	 <p>D2 X2</p>	 <p>DB-2 X2</p>	 <p>DB-3 X1</p>
 <p>DB-4 X1</p>	 <p>DB-1 X4</p>		


# ACCESSORIES

			
C4 X3	A6 X2	D1-3 X2	D1-2 X1
			
E5 X4	E6 X2	E7 X4	E8 X8
			
E9 X2	DB-5 X4	DB-6 X1	DB-7 X1
			
E10 X2	E13 X1	M4 X32+2	M5 X30+2

# SCREW


 <p>64+2 pcs</p>   <p>S1 M5*10</p>	 <p>48+2 pcs</p>   <p>S2 M3.9*25</p>
 <p>114+5 pcs</p>   <p>S3 M3.9*30</p>	 <p>393+5 pcs</p>   <p>S4 M4-12</p>
 <p>32+2 pcs</p>   <p>S5 M4*10</p>	 <p>10+1 pcs</p>   <p>S7 M5*25</p>
 <p>30+2 pcs</p>   <p>S8 M5*45</p>	 <p>4 pcs</p>   <p>S9 M4*25</p>
 <p>16+1 pcs</p>   <p>S10 M4*30</p>	

# CONTENTS




## Floor Part Instruction

11-15  
(page)




## Wall Part Instruction

15-31  
(page)



## Roof Part Instruction

32-58  
(page)




## Door Part Instruction

58-62  
(page)




## STEP 1




## STEP 2


Please install the remaining 7 A2 blocks in sequence.




## STEP 3




## STEP 4





## STEP 5







## STEP 6




# STEP 7





Insert A1 at an angle.




## STEP 8




Screw position



## STEP 9




Put 10-B2, B5 into the floor corresponding grooves.








## STEP 10




After placing BJ1 and BJ2, note the gaps between BJ1, BJ2 and 10-B2, and BJ1 and B5.



## STEP 11




After placing 10-B2, note the gap between BJ2 and 10-B2.




## STEP 12



✓



✗




After placing BJ1, note the gap between BJ1 and 10-B2.




## STEP 13



✓



✗




After confirming the gap between BJ1 and 10-B2,B5, then use S3 to connect and fix.




S3  
32 pcs

# STEP 14










Confirm the gap between BJ1 and 10-B2.



Confirm the gap between the inner sides of plates 10-B2.

After confirming the gap of the above accessories, fix BJ1 and 10-B2 by hand, and then connect and fix with S2.




	
S2	S4
2 pcs	2 pcs





## STEP 15

For details, see STEP 14.




Confirm the gap between BJ1 and B5.






S2  
2 pcs

## STEP 16

For details, see STEP 14.



Confirm the gap between BJ1 and 10-B2.




S2  
2 pcs





S4  
2 pcs

## STEP 17

For details, see STEP 14.




Confirm the gap between BJ1 and 10-B2.






## STEP 18

For details, see STEP 14.




Confirm the gap between BJ1 and B5.







## STEP 19

For details, see STEP 14.




Confirm the gap between BJ1 and 10-B2.







## STEP 20

For details, see STEP 14.




Confirm the gap between BJ1 and 10-B2.





## STEP 21

For details, see STEP 14.




Confirm the gap between BJ1 and B5.






S2  
2 pcs

## STEP 22

For details, see STEP 14.



Confirm the gap between BJ1 and 10-B2.




S2  
2 pcs





S4  
2 pcs

## STEP 23

For details, see STEP 14.




Confirm the gap between BJ1 and 10-B2,10-B3.






## STEP 24

For details, see STEP 14.




Confirm the gap between BJ1 and B5.







## STEP 25

For details, see STEP 14.




Confirm the gap between BJ1 and 10-B2,10-B3.







## STEP 26

For details, see STEP 14.




Confirm the gap between BJ1 and 10-B4,10-B6.







## STEP 27

For details, see STEP 14.




Confirm the gap between BJ1 and B5.






S2  
4 pcs

## STEP 28

For details, see STEP 14.






Confirm the gap between BJ1 and 10-B4, 10-B6.



S2  
4 pcs



S4  
2 pcs

## STEP 29



Confirm the gap between BJ1 and B1.




## STEP 30



S2  
6 pcs






## STEP 31




Confirm the gap between BJ1 and B1.

## STEP 32




S2  
6 pcs





## STEP 33





## STEP 34




# STEP 35




# STEP 36




Please install W1 and W2 first, confirm the card QQ (as shown in the figure), and then install the window.




Oblique placement




Flat forward thrust




Place W3 in the groove




Connect with S4





Place W5 in the appropriate position





Connect with S4




## STEP 37



## STEP 38




## STEP 39







**For Front Door**

S4  
3 pcs


## STEP 40




## STEP 41







After confirming the correct position of C1 (refer to ✓ picture), connect and fix with S4.




  
S4  
2 pcs

## STEP 42




After confirming the correct position of C2 (refer to ✓ picture), connect and fix with S4.



  
S4  
4 pcs




## STEP 43




## STEP 44

Note: E8 corresponds to E8, E9 corresponds to E9.









## STEP 45






## STEP 46






## STEP 47









## STEP 48





		
S5	M4	S7
2 pcs	2 pcs	2 pcs

## STEP 49





		
S5	M4	S7
2 pcs	2 pcs	2 pcs

## STEP 50




10-E2  
Bend 10-E2

## STEP 51





Install E3





Verify that 10-E2 is centered

## STEP 52



Installing E12




# STEP 53





S4  
2 pcs




# STEP 54



Ensure that 10-E2 is centered before installing screw S4.







Hold down 10-E2 while installing screw S4.




# STEP 55





Note: The side of the 10-E1 board with seams is facing downwards.




Check the gap between the inner sides of plates 10-E1 and 10-E2.




Hold down the upper roof panel while installing screw S4.





# STEP 56



For details, see STEP 55.





Hold down the upper roof panel while installing screw S4.








# STEP 57



## STEP 58








Gently lift 10-E1, align 10-E4/10-E1 with 10-E1, push forward, and buckle down into the wall panel.



Adjust with a scraper

# STEP 59





Hold the top roof panel 10-E1 while installing the screws S4. Note that the screws S4 should also be installed in the same position on the other side of the roof panel.





S4  
22 pcs


## STEP 60



## STEP 61





Install E3




Verify that 10-E2 is centered.


# STEP 62





✓



✗







Ensure that 10-E2 is centered before installing screw S4.




Hold down 10-E2 while installing screw S4.

S4  
22 pcs





# STEP 63



Check the gap between the inner sides of plates 10-E1 and 10-E2.





Hold down the upper roof panel while installing screw S4.








# STEP 64



For details, see STEP 55.





Hold down the upper roof panel while installing screw S4.










# STEP 65



# STEP 66








Gently lift 10-E1, align 10-E11/10-E4 with 10-E1, push forward, and buckle down into the wall panel.



Adjust with a scraper










# STEP 67



Hold the top roof panel 10-E1 while installing the screws S4. Note that the screws S4 should also be installed in the same position on the other side of the roof panel.

  
S4  
22 pcs

# STEP 68









Note: Please check whether the buckle of E6 is fastened to the corresponding position, and then install S3 and S4.

  
S3  
18 pcs





  
S4  
20 pcs



# STEP 69





	
S3	S4
16 pcs	40 pcs

# STEP 70






	
S7	S3
2 pcs	12 pcs

## STEP 71



S3  
24 pcs

## STEP 72





X10


S4  
80 pcs



## STEP 73







X10






Please install S4 first and then S3.

X4



			
S4	S3	S8	M5
24 pcs	8 pcs	10 pcs	10 pcs

## STEP 74




Please align the A5 with the groove of the floor first. Confirm that the A5 is aligned with the center line of the floor, and then press A5 again.

## STEP 75





S9  
4 pcs

## STEP 76






## STEP 77




  
S4  
10 pcs

## STEP 78




  
S10  
4 pcs

## STEP 80




## STEP 81




  
**S4**  
 10 pcs





## STEP 82



## STEP 83



# STEP 84



- In case of fire, do not attempt to extinguish any burning polypropylene with water. Unsuitable for storage of flammable or corrosive substances.
- It is of utmost importance to assemble all of the parts according to the directions. Do not skip any step.
- Please consult your local authorities if any permits are required to erect shed.
- Periodically check shed to assure that it remains stable and that the site remains level.
- It is highly recommended to secure the shed to an immovable object or to the ground by drilling holes in the floor at the pre-marked locations and inserting proper screws into the ground (size: 1.9"-3" ,screws are not included).
- Wear safety-goggles and always follow the manufacturer's instructions when using power tools.
- Wash shed with garden hose or a mild detergent solution. Using a stiff brush or abrasive cleaner could damage shed.
- Hot items such as recently used grills, blowtorches, etc. must not be stored in the shed.
- Heavy articles should not be leaned against the walls, as this may cause distortion.
- Keep roof clean of snow and leaves. Heavy amounts of snow on roof can damage the shed making it unsafe to enter.
- Although wind direction varies, it is an important factor when taking into account where to place your shed. Therefore, it is recommended to reduce wind exposure of the shed in general, and the door side in particular.
- Keep doors closed and locked to prevent wind damage.
- Do not stand on the roof.