



Estimated Time for Assembly

45 mins




Assembly the furniture on empty carton, carpet, or rug to prevent scratches or damage.




This furniture requires 2 people to assembly.
Make sure no parts are missing or damaged before assembly.


Not actual size




① X1




② X1




③ X1




④ X1




⑤ X1




⑥ X1




⑦ X1




⑧ X2




⑨ X1



⑩ X1




⑪ X1




⑫ X1


Not actual size




⑬X1




⑭X1




⑮X1




⑯X1




⑰X1




⑱X1




⑲X1




⑳X1




㉑X1



㉒X1




㉓X1




㉔X1


Not actual size




②⑤X1




②⑥X3




②⑦X3




②⑧X3




②⑨X3
























③⑩X3



③①X1













Cam Lock Fastening System


Insert the cam bolt into the hole first, then insert the cam lock and lock it.





STEP 1




| | |
|---|----|
| (B) | X6 |
|  | |
| $\phi 6.5 \times 35$ | |



| | |
|---|----|
| (E) | X3 |
|  | |
| $\phi 3.5 \times 14$ | |

| | |
|---|----|
| (M) | X1 |
|  | |
| 14" CL L=350 | |




STEP 2

| | |
|---|----|
| (C) | X4 |
|  | |
| $\phi 8 \times 30$ | |



STEP 3




| | |
|----------------------|-----|
| (B) | X15 |
| | |
| $\phi 6.5 \times 35$ | |




| | |
|----------------------|-----|
| (E) | X12 |
| | |
| $\phi 3.5 \times 14$ | |

| | |
|-------|----|
| (M) | X3 |
| 14" | |
| | CL |
| L=350 | |


| | |
|-------|----|
| (M) | X1 |
| 14" | |
| | CR |
| L=350 | |










STEP 4







Insert the cam bolt into the hole first, then insert the cam lock and lock it.





STEP 5




STEP 6




STEP7





Insert the cam bolt into the hole first, then insert the cam lock and lock it.





STEP 8








| | |
|---|----|
| (A) | X2 |
|  | |
| $\phi 15 \times 9.5$ | |


| | |
|--|----|
| (B) | X2 |
|  | |
| $\phi 6.5 \times 35$ | |

| | |
|---|----|
| (D) | X6 |
|  | |
| $\phi 6 \times 30$ | |


| | |
|---|----|
| (G) | X5 |
|  | |
| $\phi 4 \times 35$ | |




Insert the cam bolt into the hole first, then insert the cam lock and lock it.



Proper orientation of CAM LOCK









STEP 9




| | |
|---------|-----|
| (B) | X18 |
| | |
| ø6.5*35 | |

| | |
|-------|----|
| (D) | X6 |
| | |
| ø6*30 | |

| | |
|-------|----|
| (G) | X5 |
| | |
| ø4*35 | |





Insert the cam bolt into the hole first, then insert the cam lock and lock it.






Proper orientation of CAM LOCK

STEP 10




| | |
|---|----|
| (A) | X4 |
|  | |
| $\phi 15 \times 9.5$ | |

| | |
|---|-----|
| (D) | X10 |
|  | |
| $\phi 6 \times 30$ | |






Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Proper orientation of CAM LOCK

STEP 11






Insert the cam bolt into the hole first, then insert the cam lock and lock it.





Proper orientation of CAM LOCK


STEP 12



 FLIP OVER





Insert the cam bolt into the hole first, then insert the cam lock and lock it.







Proper orientation of CAM LOCK

STEP 13





| | |
|---|----|
| Ⓑ | X6 |
|  | |
| ø6.5*35 | |


| | |
|--|----|
| Ⓖ | X9 |
|  | |
| ø4*35 | |




STEP 14




| | |
|---|----|
| (A) | X6 |
|  | |
| $\phi 15 \times 9.5$ | |


| | |
|---|----|
| (C) | X6 |
|  | |
| $\phi 8 \times 30$ | |


THIS STEP REQUIRES 2 PEOPLE




STEP 15





| | |
|---|-----|
| (H) | X12 |
|  | |
| ø3*14 | |


| | |
|--|----|
| (R) | X1 |
|  | |
| | |





STEP 16




| | |
|---|----|
| (A) | X4 |
|  | |
| $\phi 15 \times 9.5$ | |

| | |
|--|----|
| (B) | X4 |
|  | |
| $\phi 6.5 \times 35$ | |

| | |
|---|----|
| (G) | X4 |
|  | |
| $\phi 4 \times 35$ | |





Insert the cam bolt into the hole first, then insert the cam lock and lock it.





Proper orientation of CAM LOCK


STEP 17




| | |
|---|----|
| (E) | X6 |
|  | |
| ø3.5*14 | |

| | |
|-------|--|
| (M) | X1 |
| 14" |  |
| DL | |
| L=350 | |

| | |
|-------|---|
| (M) | X1 |
| 14" |  |
| DR | |
| L=350 | |







STEP 18



| | |
|---------|-----|
| Ⓐ | X12 |
| | |
| ø15*9.5 | |


| | |
|---------|-----|
| Ⓑ | X12 |
| | |
| ø6.5*35 | |

| | |
|-------|-----|
| Ⓖ | X12 |
| | |
| ø4*35 | |





Insert the cam bolt into the hole first, then insert the cam lock and lock it.


X 3





STEP 19



| | |
|---|-----|
| (E) | X18 |
|  | |
| ø3.5*14 | |


| | |
|-------------|---|
| (M) | X3 |
| 14" |  |
| DL L=350 | |


| | |
|-------------|---|
| (M) | X3 |
| 14" |  |
| DR L=350 | |





X 3

STEP 20





| | |
|---|----|
| ⓐ | X1 |
|  | |
| 106*16*8 | |


| | |
|---|----|
| ⓑ | X2 |
|  | |
| M4*18 | |





STEP 21




| | |
|---|----|
| (F) | X2 |
|  | |
| ø3*12 | |


| | |
|--|----|
| (J) | X3 |
|  | |
| 106*16*8 | |


| | |
|---|----|
| (K) | X6 |
|  | |
| M4*18 | |


| | |
|---|----|
| (N) | X1 |
|  | |
| | |





STEP 22




| | |
|---|----|
| Ⓘ | X2 |
|  | |
| ø4*14 | |

| | |
|---|----|
| Ⓕ | X1 |
|  | |
| 109*99*38.5 | |


| | |
|---|----|
| Ⓟ | X1 |
|  | |
| ø35 | |




You can install the hair dryer rack(L) on the left or right according to your needs



STEP 23




Pass the bulb wire through the pre punched plate, then gently press the bulb and make it adhere to the plate.




STEP 24

Pass the bulb wire through the pre punched plate, then gently press the bulb and make it adhere to the plate, and then connect the adjacent bulbs successively through the wire head slot on the opposite side (corresponding to the line of the same color).




STEP 25



When making up, you can use the switch to turn on or off the light. The dressing table brings you 3 color temperature light modes, touch the button you can easily light up the mirror and change colors to meet your different needs, long press to adjust the brightness.




STEP 26




Install the tipping restraint hard ware




1. make mark on the wall




2. drill two Ø6 holes on the wall



3. put two anchors in the holes



4. fix the device on the wall by the long screws



5. Push the cabinet close to the wall so that the two bases are close to each other, and then put on nylon tie to tighten it.

