


# Assembly Instructions



## ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.

EASY  DIFFICULT

## Tools Required for Assembly:

Allen Wrench



(Included)

Phillips Screwdriver



(Not Included)




2 PERSONS RECOMMENDED


# ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


## BASIC ASSEMBLY TECHNIQUES




1 When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




2 Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




3 Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



4 Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.



5 Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.




6 Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.



FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.

### Parts List



#1 x 1 pc  
Headboard



#2 x 1 pc  
Left HB Side



#3 x 2 pcs  
Side Rail




#4 x 1 pc  
Footboard



#5 x 3 pcs  
Slat



#6 x 4 pcs  
Foot



#7 x 3 pcs  
Slat Support Leg



#8 x 1 pc  
Right HB Side

### Hardware List



#A x 8 pcs  
Bolt 5/16"x1"



#B x 8 pcs  
Bolt 5/16"x3"



#C x 16 pcs  
Flat Washer




#D x 16 pcs  
Lock Washer



#E x 2 pcs  
Angle Bracket



#F x 22 pcs  
Screw




#G x 1 pc  
Allen Wrench



Due to the size and/or weight of this product, it is highly recommended that the assembly should be done near the area of its intended location. Make sure you have enough space to move around during the assembly. ALWAYS have at least two people to help with transporting and assembling of the product to avoid any potential injury and/or damage.




- I. Align the brackets of the left HB side (#2) with the brackets of the headboard (#1).
- II. Align the angle bracket (#E) with the pre-drilled holes on bottom of the headboard (#1) and the left HB side (#2). Secure the angle bracket (#E) with 8 screws (#F) using a Phillips screwdriver to tighten them down to the headboard (#1) and the left HB side (#2).
- III. Repeat process above to assemble the right HB side (#8) onto the headboard (#1).





- I. Align the feet (#6) onto the pre-drilled holes on the bottom corners of the headboard (#1).
- II. Prepare 4 bolt assemblies by inserting FIRST the lock washer (#D) onto the bolt (#B) and then the flat washer (#C) onto the SAME bolt (#D), in that order.
- III. Insert the bolt assemblies through the holes of the feet (#6) and secure those bolts using the Allen wrench (#G) to lock them in with the headboard (#1).
- IV. Repeat the process above to assemble the feet (#6) onto the footboard (#4).

#B x 8 pcs  
#C x 8 pcs  
#D x 8 pcs




Turn right (clockwise) to tighten



#A x 8 pcs  
#C x 8 pcs  
#D x 8 pcs


Turn right (clockwise) to tighten



- I. Prepare 4 bolt assemblies by inserting FIRST the lock washer (#D) onto the bolt (#A) and then the flat washer (#C) onto the SAME bolt (#A), in that order.
- II. Insert two bolt assemblies through the right side and two bolt assemblies through the left side of the pre-drilled holes of the headboard (#1) using the Allen wrench (#G) but expose about 1/2" of the bolts' threads.
- III. Mount the brackets of the side rails (#3) onto the bolts (#A) on each side of the headboard (#1). Make sure all the washers are in the FRONT of the brackets. Use the Allen wrench (#G) to tighten the bolts with the two parts together.
- IV. Repeat the process above to assemble the other ends of the side rails (#3) onto the footboard (#4).



Align the threaded end of the slat support leg (#7) with the pre-drilled hole of the slat (#5) and tighten by hand until secured. Repeat the process for the remaining two slats (#5).



X 3


Turn right (clockwise) to tighten



Align the ends of the assembled slat (#5) with the pre-drilled holes on each side of the side rails (#3). Secure two screws (#F) onto each end of the slat (#5) by using a Phillips screwdriver to tighten them down to the side rails (#3). Repeat the process for the remaining three slats (#5).

Adjust the leveler according to the ground level. To lower or to raise the slat support leg, you need to turn the leveler clockwise or counterclockwise, respectively.

#F x 6 pcs →



Turn right (clockwise) to tighten

**ASSEMBLY IS COMPLETED**