


ASSEMBLY INSTRUCTIONS

HOPPER STUDIO


PRODUCT NAME : Sophia 3 Door Cabinet
DIMENSIONS : 51" L x 15" W x 34" H
ITEM NO. : 7185AB583BCL25
 7185AW583BCL25
 7185GY583BCL25
 7185LB583BCL25
 7185MC583BCL25
 7185TT583AUL25




1. Check for damaged or missing parts . Call 1-800-696-8446 to order missing supplies.
2. Use a soft surface or the carton as a working surface to prevent damage during assembly.
3. It is recommended to have 2 adults on hand for assembly.
4. Gather all tools prior to assembly.
5. **WARNING!** When included, anti-tipping hardware **MUST** be installed for your safety.

how to use cam lock system


1.




2.




3.






























4.




5.




| PARTS LIST: | | | QTY |
|-------------|-------------------|--|------|
| A | Top Assembly |  | 1pc |
| B | Left Side Panel |  | 1pc |
| C | Right Side Panel |  | 1pc |
| D | Back Rail |  | 2pcs |
| E | Middle Panel |  | 1pc |
| F | Bottom Panel |  | 1pc |
| G | Side Leg |  | 2pcs |
| H | Middle Leg |  | 1pc |
| I | Back Panel |  | 1pc |
| J | Left Door |  | 1pc |
| K | Right Door |  | 2pcs |
| L | Handle |  | 3pcs |
| M | Left Shelf Panel |  | 1pc |
| N | Right Shelf Panel |  | 1pc |

| HARDWARE : | | | QTY |
|------------|--------------------------------------|---|-------|
| O | Wooden Dowel Ø8x40mm |  | 20pcs |
| P | Cam Lock Bolt |  | 20pcs |
| Q | Cam Lock |  | 20pcs |
| R | Flat Washer Ø5/16" |  | 10pcs |
| S | Lock Washer Ø5/16" |  | 10pcs |
| T | Hexagonal Nut Ø5/16" |  | 10pcs |
| U | Wrench for Nut |  | 1pc |
| V | Door Catcher |  | 6set |
| W | Umbrella Screw Ø5/32" x 5/8" |  | 24pcs |
| X | Screw with Washer Ø5/32" x 5/8" |  | 24pcs |
| Y | Umbrella Machine Screw Ø5/32" x 5/8" |  | 6pcs |
| Z | Shelf Pin |  | 8pcs |
| AA | Tipping Restraint |  | 2set |


STEP 1




STEP 2





STEP 3




STEP 4




STEP 5




STEP 6




STEP 7




STEP 8




STEP 9




STEP 10



STEP 11



STEP 12



Note: adjust levelers on an uneven floor.

Note: The long screw included is suitable for most wall situations.
Use appropriate screw for your application. Do not overtighten the cable.
WARNING! Anti-tipping hardware MUST be installed for your safety.