

NOTICE

- * Please make sure that you have all parts indicated and they are in good condition before you begin assembly of this item. Refer to part list and hardware list below for guidance.
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly.
- * This item may require periodic tightening.
- * If you are having difficulty, our friendly Customer Care team is always here to help.


PREPARATION

- * Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.
- * If any part is missing or damaged, do not attempt to assemble the product.
- * Estimated Assembly Time: 60 minutes.
- * Tools Required for Assembly (included): Allen Key

CARE AND MAINTENANCE

Adhesive felt pads should always be applied to areas of furniture which make direct contact with flooring, said application will prevent damage to the furniture and or surfaces on which the furniture lies. Objects placed on articles of furniture should rest on non abrasive material as to prevent damage to the wood finish. Wipe up spills immediately and avoid common hazards such as hot dishes, harsh solvents and abrasives. Cleaning should be done with a soft lint free cotton cloth dampened with water or furniture polish.

Product Dimensions: 18"W x 15.8"D x 24"H



Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	TOP PANEL		1X
B	LEFT PANEL		1X
C	RIGHT PANEL		1X
D	BOTTOM ASSEMBLY		1X
E	BACK PANEL		1X
F	LEG FRAME		2X
G	BASE FRAME		1X
H	DRAWER FRONT		1X
I	DRAWER LEFT		1X
J	DRAWER RIGHT		1X
K	DRAWER BACK		1X
L	DRAWER BASE		1X

⚠ WARNING ⚠

WEIGHT CAPACITY: 22 LBS


WARNING: DO NOT STAND ON THE NIGHT STAND

WARNING: DO NOT OVER TORQUE BOLTS/SCREWS


PIECE	DESCRIPTION	PICTURE	QUANTITY
HW1	BOLT 6 x 1 x 30 MM		12X
HW2	SPRING WASHER		8X
HW3	FLAT WASHER		8X
HW4	FLAT HEAD SCREW 3 x 1 x 32 MM		8X
HW5	FLAT HEAD SCREW 3 x 1 x 19 MM		2X
HW6	FLAT HEAD SCREW 3 x 1 x 16 MM		6X
HW7	CAMBOLT		12X
HW8	CAMLOCK		12X
HW9	MACHINE SCREW 4 x 1 x 25 MM		2X
HW10	HANDLE		1X
HW11	DOWEL		8X
HW12	ALLEN KEY		1X
HW13	WEDGE		6X

PREPARATION


- * Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
- * If any part is missing or damaged, do not attempt to assemble the product.
- * Estimated Assembly Time: 60 minutes.
- * Tools Required for Assembly (included): Allen Key
- * If you are having difficulty, our friendly Customer Care team is always here to help.




STEP 1 ATTACH CAMBOLTS (HW7) TO TOP PANEL (A) AND BOTTOM ASSEMBLY (D).




STEP 2 ATTACH LEFT PANEL (B) AND RIGHT PANEL (C) TO TOP PANEL (A) USING CAMLOCKS (HW8) AND DOWELS (HW11).




STEP 3 SLIDE BACK PANEL (E) INTO THE GROOVE OF UNIT.




STEP 4 ATTACH BOTTOM ASSEMBLY (D) TO UNIT USING CAMLOCKS (HW8) AND DOWELS (HW11).




STEP 5 ATTACH LEG FRAMES (F) TO UNIT USING BOLTS (HW1), SPRING WASHERS (HW2) AND FLAT WASHERS (HW3). TURN BOLTS USING ALLEN KEY (HW12).
NOTE : DO NOT OVER TIGHTEN THE BOLTS.




STEP 6 ATTACH BASE FRAME (G) TO UNIT USING BOLTS (HW1). TIGHTEN BOLTS USING ALLEN KEY (HW12).
NOTE : TIGHTEN ALL BOLTS COMPLETELY USING ALLEN KEY FROM STEP 5.




STEP 7 ATTACH WEDGES (HW13) TO UNIT USING FLAT HEAD SCREWS 16 MM (HW6). ADJUST THE ADJUSTER THAT HAS ALREADY BEEN ASSEMBLED TO THE LEGS TO STABILIZE YOUR UNIT.




STEP 8 ATTACH HANDLE (HW10) TO DRAWER FRONT (H) USING MACHINE SCREWS (HW9). ATTACH DRAWER LEFT (I) AND DRAWER RIGHT (J) TO DRAWER BACK (K) USING FLAT HEAD SCREWS 32 MM (HW4). SLIDE DRAWER BASE (L) INTO THE GROOVE. ATTACH DRAWER FRONT (H) TO DRAWER LEFT (I) AND DRAWER RIGHT (J) USING FLAT HEAD SCREWS 32 MM (HW4).




STEP 9 LOOSEN SLIGHTLY THE SCREWS PRE-INSTALLED ON THE BACK OF THE DRAWER FRONTS.



STEP 10 INSERT THE DRAWER INTO THE UNIT, THEN ADJUST THE DRAWER FRONT PANEL LEFT OR RIGHT AND UP OR DOWN UNTIL THE DRAWER GAPS LOOK PROPORTIONAL.



STEP 11 PULL THE DRAWER OPEN SLOWLY AND RE-TIGHTEN THE SCREWS FROM STEP 9. MAKE SURE THE FRONT PANEL DOES NOT MOVE AND LOCK THE DRAWER FRONT PANEL INTO POSITION WITH FLAT HEAD SCREWS 19 MM (HW5).



STEP 12 SLIDE THE DRAWERS INTO UNIT.