


ASSEMBLY INSTRUCTIONS

279LK-411 Harborview Desk



STEP 1:

- 1. Pull desk drawer out as far as it will extend without completely removing drawer.
- 2. Remove all (4) drawer dividers by sliding each one up from drawer box. Keep dividers nearby for re-installment.

STEP 2:

- 1. Place desk top assembly upside-down on clean, non-marring surface.
- 2. Position one 'Z' pedestal on one end of desk so that holes on pedestal align with holes on desk top.
- 3. Use Allen Wrench (D) to attach 'Z' pedestal to desk top with (2) Flat Washers (C), (2) Lock Washers (B), and (2) 2-3/8" long Bolts (A). Do not securely tighten bolts at this time.
- 4. Repeat Steps 2 & 3 for other 'Z' pedestal on other end of desk.
- 5. Return desk to an upright position.

STEP 3:

- 1. Pull desk drawer out again as far as it will go without completely removing drawer to access holes for assembly.
- 2. Access holes through inside of desk and use Allen Wrench (D) to attach 'Z' pedestal to desk top assembly with (4) Flat Washers (C), (4) Lock Washers (B), and (4) 1" long Bolts (E). Do not securely tighten bolts at this time.
- 3. Repeat above step for other 'Z' pedestal on other end of desk.
- 4. Securely tighten all bolts from STEP 2 and STEP 3.
- 5. Completely slide drawer dividers from STEP1 back into drawer box.
- 6. Push desk drawer back into position.
- 7. Place assembled desk in desired location.

