


Assembly Instructions




Before Assembly

Tips Before Your Start:


- Remove all wrapping material, including staples & packing straps before you start to assemble.
- DO NOT tighten all screws and bolts until the assembly is completely assembled.
- Keep all hardware parts out of reach of children.

QUICKFIT



Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.


CAM LOCK



When fitting a cam lock, ensure the starting position is correct before inserting the connecting QUI CKFIT

Quickfit head should be in the centre of the cam lock when the two panels are joined.

Cam lock should be inserted before quickfit.




Turn cam lock clockwise to tighten.


Before Assembly

Tips Before Your Start


How to separate the drawer slider:



Drawer Front Alignment















If the drawer front panel is NOT level after being assembled, then...




Loosen the screws on the left and right hand side, then adjust the drawer slide up or down, until the drawer fronts are even/level, then tighten the screws.


Part List

<p>No. A Quantity: 32 Pcs Cam Lock Dowel 8*28mm</p> 	<p>No. B Quantity: 48 Pcs Cam Ø15</p> 	<p>No. C Quantity: 48 Pcs Sticker Ø20</p> 	<p>No. D Quantity: 12 Pcs Dowel 8*30mm</p> 
<p>No. E Quantity: 2 Pcs Drawer Slider 10"</p> 	<p>No. F Quantity: 16 Pcs Screw M3.5*12mm</p> 	<p>No. G Quantity: 8 Pcs Screw M4*30mm</p> 	<p>No. H Quantity: 8 Pcs Double-ended rod 6*64mm</p> 
<p>No. I Quantity: 4 Pcs Foot Pad Ø20</p> 	<p>No. J Quantity: 24 Pcs Screw M8*25mm</p> 	<p>No. K Quantity: 1 Pcs Allen Key 5#</p> 	<p>No. L Quantity: 16 Pcs Screw M8*30mm</p> 

Product structure




STEP 1




No. B
Quantity: 8 Pcs
Ø15



No. D
Quantity: 2 Pcs
8*30mm




No. H
Quantity: 4 Pcs
6*64mm



Please note that attention should be paid to distinguish the numbering when assembling!


STEP 2




No. B
Quantity: 8 Pcs
Ø15




No. D
Quantity: 2 Pcs
8*30mm



No. H
Quantity: 4 Pcs
6*64mm




STEP 3



No. A
Quantity: 16 Pcs
8*28mm




STEP 4




No. B
Quantity: 4 Pcs
Ø15



No. D
Quantity: 2 Pcs
8*30mm




STEP 5




No. B
Quantity: 4 Pcs
Ø15



No. D
Quantity: 2 Pcs
8*30mm




STEP 6



No. A
Quantity: 8 Pcs
8*28mm



STEP 7



No. B
Quantity: 8 Pcs
Ø15




STEP 8




Since two kinds of screws are used in the product assembly, please pay attention to distinguish the numbering of the screws.


No. J
Quantity: 8 Pcs
M8*25mm




No. K
Quantity: 1 Pcs
5#




STEP 9


 Here the assembly needs to be locked from the inside to the foot column to ensure the stability of the product.

 Since two kinds of screws are used in the product assembly, please pay attention to distinguish the numbering of the screws.

No. L
Quantity: 8 Pcs
M8*30mm





No. K
Quantity: 1 Pcs
5#




STEP 10



The first screw hole should corresponded with the board location hole




x2



x2

No. E
Quantity: 2 Sets
10"



No. F
Quantity: 8 Pcs
M3.5*12mm





STEP 11

No. B
Quantity: 4 Pcs
Ø15




No. D
Quantity: 2 Pcs
8*30mm




STEP 12

No. J
Quantity: 4 Pcs
M8*25mm



No. K
Quantity: 1 Pcs
5#





STEP 13

The same assembly method for two boards, please use the same assembly method.

No. B
Quantity: 4 Pcs
Ø15




No. D
Quantity: 2 Pcs
8*30mm




STEP 14

The same assembly method for two boards, please use the same assembly method.

No. J
Quantity: 4 Pcs
M8*25mm



No. K
Quantity: 1 Pcs
5#




STEP 15




Since two kinds of screws are used in the product assembly, please pay attention to distinguish the numbering of the screws.

No. J
Quantity: 8 Pcs
M8*25mm



No. K
Quantity: 1 Pcs
5#




STEP 16



Here the assembly needs to be locked from the inside to the foot column to ensure the stability of the product.


No. L
Quantity: 8 Pcs
M8*30mm




No. K
Quantity: 1 Pcs
5#



Since two kinds of screws are used in the product assembly, please pay attention to distinguish the numbering of the screws.




STEP 17



No. I
Quantity: 4 Pcs
Ø20



STEP 18




x2


No. A
Quantity: 8 Pcs
8*28mm




STEP 19




No. G
Quantity: 8 Pcs
M4*30mm



STEP 20



STEP 21



No. B
Quantity: 8 Pcs
Ø15




x2


STEP 22




The first screw hole should corresponded with the board location hole




No. E
Quantity: 2 Sets
10"



No. F
Quantity: 8 Pcs
M3.5*12mm



STEP 23



STEP 24

