

GAZEBO INSTALLATION MANUAL



SIZE 9x13

PARTS LIST

ITEM#	PART #	DESCRIPTION	QTY
1	WWRS-4884	Window Wall (Right Side) 48"	5
2	WWLS-4884	Window Wall (Left Side) 48"	4
3	DOOR-4884	Door 48"	1
4	CRNR-0202	Corner 2"x2"	4
5	HEEN-94875	End Header 94.875" (2 sections)	2 sets
6	HESI-14275	Side Header 142.75" (2 sections plus 1 joiner piece)	2 sets
7	CHIP-0080	Corner Hip 80"	4
8	SRAF-0585	Side Rafters 58.5"	6
9	CHUB-0913	Center Hub for 9x13 Gazebo	1
10	PRCO-5225	Corner Roof Panel, Right 52.25"	4
11	PLCO-5225	Corner Roof Panel, Left 52.25"	4
12	PCSQ-0455	Center Roof Panel 45.5"	2
13	RCAP-0913	Roof Cap for 9x13 Gazebo	1
14	KNOB-0000	Door Knobs	2
15	BOLT-0000	Lag Bolts	4
16	SCRW-0015	Door Knob screws 1.5"	2
17	SCRW-0025	Screws 2.5"	150
18	SBIT-0000	Robertson Screw Bit	1

PARTS LIST

1

Window Wall
(Right Side)
48"



2

Window Wall
(Left Side)
48"



3

Door 48"



4

Corner 2"x2"



5

End Header 94.875" (2 sections)



PARTS LIST

6

Side Header 142.75" (2 sections plus 1 jointer piece)



7

Corner Hip 80"



8

Side Rafters 58.5"



9

Center Hub for 9x13 Gazebo



10



Corner Roof Panel, Right 52.25"

11

Corner Roof Panel,
Left 52.25"



~ 9x13 Gazebo ~

PARTS LIST

12

Center Roof Panel 45.5"



13

Roof Cap for 9x13 Gazebo



14

Door Knobs



15

Lag Bolts



16

Door Knob screws 1.5"




17

Screws 2.5"




18

Robertson Screw Bit



INSTALLATION PROCEDURE

IMPORTANT: Please read the full instructions in entirety before starting assembly of the gazebo. The assembly of this gazebo requires you to provide a 1/2" socket wrench, a 6 foot step ladder, a cordless drill, and a minimum of 2 persons.



1. Ensure that the surface you will be installing the enclosure on is flat, smooth and level. Starting with a Corner and Window Wall (48") align them in an upright position. The inside edge of the Window Wall (48") should be flush with the end of the Corner. Secure the Corner to the Window Wall (48") with four 2.5" screws.



2. Align a Door (48") at a 90 degree angle from the first Window Wall (48") and secure the Corner to the Door (48") with four 2.5" screws.



3. Align a Window Wall (48") next to the Door (48") and secure it with six 2.5" screws (more specifically, 2 screws side by side at the top; 2 screws side by side adjacent to the bottom of the window opening; 2 screws one at the top and one at the bottom of the wood skirt).



4. Align and attach a Window Wall (48") to the previous Window Wall (48"). Secure window walls to one another as previously described with six 2.5" screws.

INSTALLATION PROCEDURE



5. Align and secure a Corner to the previous Window Wall (48"). Secure the Corner to the Window Wall (48") with four 2.5" screws.



6. Align the next Window Wall (48") at a 90 degree angle from the previous Window Wall. Secure the Corner to this Window Wall (48") with four 2.5" screws.



7. Align the next Window Wall (48") to the previous Window Wall (48"). Secure window walls to one another as previously described with six 2.5" screws.



8. Align and attach a Corner to the last Window Wall (48") secure with four 2.5" screws. Then align and attach another Window Wall (48") at a 90 degree angle from the previous Window Wall (48"). Secure the Corner to this subsequent Window Wall (48") with four 2.5" screws.



9. Align and attach two more Window Walls (48") to the previous Window Wall (48"). Secure window walls to one another as previously described with six 2.5" screws.




10. Align a Corner to the previous Window Wall (48"). Make sure the inside edge of the Window Wall (48") is flush with the end of the Corner. Secure the Corner to the Window Wall (48") with four 2.5" screws. Then align a Window Wall (48") at a 90 degree angle from the previous Window Wall. Secure the Corner to this Window Wall (48") with four 2.5" screws. Then secure the final Window Wall (48") in place to complete the assembly of the gazebo body.

INSTALLATION PROCEDURE



11. Assemble the End Headers. Each set of End Headers consist of two sections. Connect the two sections with three 2.5" screws. Do this again for the second End Header. Once you have assembled the End Headers the full length of each assembled End Header should be 94.875".



12. Assemble the Side Headers. Each set of Side Headers consist of three pieces. There are two 71 3/8" inch sections plus one joiner piece that is 29" in length. Connect the two sections to the joiner piece with eight 2.5" screws. Do this again for the second Side Header. Once you have assembled the Side Headers the full length of each assembled Side Header should be 142 3/4 ".





13. Align and attach the Corner Hips to the Side Headers and End Headers with the Lag Bolts. The Lag bolts should be only hand tight for now.



14. Raise the Center Hub and attach the Corner Hips to the Center Hub. Use one 2.5" screw on each Corner Hip.

15. Once the Corner Hips are attached to the Center Hub you can proceed to tighten the Lag Bolts with a socket wrench. Make sure the top of the Header is flush with the bottom of the dado. Also, make sure the inside of the Header is flush with the inside block on the Corner Hip.



INSTALLATION PROCEDURE



16. Place the Side Rafters in the slots along the Headers and attach the Side Rafters to the Center Hub. Make sure the edge of the Side Rafter is flush with the miter of the Center Hub. Use one 2.5" screw. Do not screw down the Side Rafters to the Headers at this time.



17. Insert Corner Roof Panels into the Roof Frame and secure the Corner Roof Panels to the Corner Hips. Do not secure the Corner Roof Panels to the Side Rafters at this time.



18. Once all the Corner Roof Panels are attached to the Corner Hips, insert the Center Roof Panels in place and secure the Center Roof Panels and the Corner Roof Panels to the Side Rafters. Use one 2.5" screw for each Roof Panel.



19. Attach each Side Rafter to the Headers with one 2.5" screw.

INSTALLATION PROCEDURE



20. Attach the Roof Cap to the top of the Side Rafters with one 2.5" screws per Side Rafter. And now the Roof should be completely assembled.



21. Slide the entire Roof onto the body of the gazebo and secure the Roof to the body of the gazebo by screwing along the perimeter. Use two 2.5" screws for each Window Wall (48").



22. Attach Door Knobs to the Doors with 1.5" screws.



23. The gazebo is now complete and ready to enjoy.