



Assembly Instructions




General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
- V. The provided glue is to secure wood dowels in place . When first inserting dowels , locate the appropriate hole for the dowel , place a small amount of glue in the hole and insert the dowel . Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together , place a small amount of glue on the end of the dowel before attaching parts together . Wipe away excess glue immediately.




- VI. A Phillips head screwdriver is required for the assembly of this product .

























- VII. Power tools should not be used to assemble this product .




Parts List



Hardware List


A		Ø8x30mm	Wooden dowel	17 pcs
B		Ø6x35mm	Cam bolt	6 pcs
C		Ø15x11mm	Cam lock	6 pcs
D		Ø30mm	Sticker	6 pcs
E		M 4	Hex Key	1 pc
F		Ø6x50mm	Screw	11 pcs
G			Door stopper	1 pc
H			Screw	2 pcs
I		Ø3x15mm	Screw	2 pcs
J			Handle	2 pcs
K		Ø4x19mm	Bolt	4 pcs
L			Three fold hinge	4 pcs
M		Ø3.5x15mm	Screw	32 pcs
N		Ø5x13x26mm	Shelf holder	16 pcs
O			Plastic wedge	10 pcs
P		Ø3x17mm	Screw	10 pcs
Q			Anti-inversion hardware	4 pcs
R		Ø4*15mm	Screw	4 pcs
S			House lizard	4 pcs
T		Ø4x35mm	Screw	4 pcs
U			Strip	2 pcs
V			Glue tube	1 pcs




Philips head screwdriver required for assembly
(not included)


*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*


Step 1




A

X17



Step 2




B

X6

Step 3




F	E
	
X5	X1



Step 4





Step 5






Step 6




I	G
	
X2	X1


Step 7




C

X6


Step 8




D

X6

Step 9







N

X16

Step 10





Step 11




H	L	M
		
X2	X4	X20



Step 12




M

X6


Step 13




K	J
	
X2	X1



Step 14




M

X6



Step 15




K	J
	
X2	X1



Step 16



O	P
	
X10	X10


Step 17




Q	R
	
X2	X4


Step 18

Make Four holes 45MM deep




Step 19





S

X4


Step 20




Wall

Q	T
	
X2	X4

Step 21



U

X2

Step 22

