

## **SYSTEM INITIALIZATION**

**After assembly of desk is complete, it is necessary to reset or initialize the motor system.**



### **STEP 1:**

Plug the power cord into an outlet or power strip. *(Display will flash)*

### **STEP 2:**

Press and **continue holding** both the **up** (^) and **down** (v) buttons simultaneously until the desk is at its lowest point, the display will flash "000" followed by a beep and the display will then show the lowest height. *(The buttons can now be released)*

### **NOTE:**

If initialization is interrupted by releasing buttons prematurely *(display will read "000")* and/or if desk does not begin moving, repeat step 2.

### **STEP 3:**

Press the **up** (^) button to raise the desk to the highest position. *(Now release the button)*

### **STEP 4:**

Press the **down** (v) button to lower the desk to the lowest position. *(Now release the button)*

*(The system has now been successfully initialized and synced)*

---

## **INSTALACION DE CONTROL DE MESA Y SINCRONIZACION**

**DESPUES DE COMPLETAR EL ENSAMBLAJE ES NECESARIO REINICIAR O INICIALIZAR EL SISTEMA DEL MOTOR, POFAVOR DE SEGUIR LOS SIGUIENTES PASOS:**

### **PASO 1:**

Conecte el cable de corriente en el enchufe. *(la pantalla va a prender)*

### **PASO 2:**

Presione los botones de (^) arriba y (v) abajo al mismo tiempo hasta que las patas de las columna esten en su punto mas bajo y continúe presionando los botones hasta que la pantalla ensene "000". Luego sonara un pitido y la pantalla mostrara el numero de la medida mas baja, despues de haber echo esto suelta los botones.

### **NOTA:**

Si la inicializacion se interrumpe al soltar los botones prematuramente la pantalla mostrara "000" o si no se mueve, repita el paso dos.

### **PASO 3:**

Presione el boton de arriba (^) para elevar la mesa ala posicion mas alta, despues he haber echo esto suelta el boton.

### **PASO 4:**

Presione el boton de abajo (v) para elevar la mesa ala posicion mas baja, despues he haber echo esto suelta el boton.

*(El sistema se ha inicializado y sincronizado con exito)*

# **HEIGHT ADJUSTABLE BASE**

## **OPERATION GUIDE**



### **METRIC OR IMPERIAL HEIGHT SETTING:**

**The controller can show either Metric (cm) or Imperial (in) height.**

#### **STEP 1:**

Press the **(1)** **(2)** **(M)** buttons simultaneously for 5 seconds until "C-E" appears on the display.  
*Now Release the buttons.*

#### **STEP 2:**

While the display is flashing, press the **(1)** button to show Metric height or press the **(2)** button for the Imperial mode. *(If (1) or (2) is NOT pressed after the display stops flashing, repeat from Step 1)*

*(The height setting is now complete.)*

### **SETTING THE MEMORY FUNCTION:**

#### **STEP 1:**

Use the up (^) and down (v) buttons to reach the desired height of the desk.

#### **STEP 2:**

Press and hold the **(M)** button until the display flashes, then press **(1)**  
*(Display will read "P1" and position 1 is now memorized.)*

*Follow the same procedure for memory preset 2, 3, and 4.  
(Display will read "P2", "P3" and "P4" when the 2nd, 3rd and 4th positions have been memorized)*

*(Memorized positions will remain even if power is lost.)*

### **NORMAL OPERATION:**

Raise or lower the desk by pressing and holding the up (^) or down (v) button on the Controller until the desired height is reached.

**USB Function:** Connect desired USB compatible device to USB port to charge.

### **NOTES:**

- \*Keep base away from water and corrosion-resistant gas.
- \*Use this base with actual technical parameters.
- \*Please contact with any problems or issues.