




# Installation & Assembly



**YOU MAY NEED (NOT SUPPLY)**














# ASSEMBLY DIAGRAM











## PARTS LIST

### PARTS LIST

NO	DESCRIPTION	QTY	NO	DESCRIPTION	QTY
①	Left side panel 	1	⑧	Bottom outside front panel 	1
②	Right side panel 	1	⑨	Upper front end panel 	1
③	Bottom panel 	1	⑩	Left door panel 	
④	Bottom inside front panel 	1	⑪	The right door 	
⑤	rear drop down 	1			
⑥	Upper back panel 	1			
⑦	Long front panel 	1			

## PARTS LIST


### HARDWARE LIST



NO	DESCRIPTION	QTY	NO	DESCRIPTION	QTY
A	Three-in-one eccentric wheel 	28	G	4*23mm screw 	4
B	Three-in-one connecting rod 	28	H	Door Handle 	2
C	Three-in-one sticker 	28			
D	8*40mm wood dowel pins 	8			
E	Door hinge 	4			
F	4*16mm screw 	24			

### CAUTION:


Please confirm the parts list before installation

## STEP 1




HARDWARE LIST	
Three-in-one connecting rod B  28 PCS	


1. Put the three-in-one connecting rod in the  $\varnothing 10\text{mm}$  hole of the following panels and tighten them with a cross screwdriver or an electric tool.





## STEP 2





1. Strike the  $\varnothing 8 \times 40\text{mm}$  wood dowel pin into the  $\varnothing 8\text{mm}$  hole of the above panels with an iron hammer. Please note that the hole of the three-in-one connecting rod should also be 8mm. The hole of the three-in-one connecting rod connects to the hole of  $\varnothing 15\text{mm}$  three-in-one eccentric wheel.




HARDWARE LIST	
8*40mm wood dowel pins D  8 PCS	

## STEP 3






1. Connect No. 3-4-5-6-7 panel to No.2 panel tightly with the three-in-one eccentric wheel.





2. Cover the mounting hole of the eccentric wheel with a three-in-one sticker.


### HARDWARE LIST

Three-in-one eccentric wheel	Three-in-one sticker	
A  9 PCS	C  9 PCS	

## STEP 4






1. Connect No. 3-4-5-6-7 panel to No.2 panel tightly with the three-in-one eccentric wheel.





2. Cover the mounting hole of the eccentric wheel with a three-in-one sticker.


### HARDWARE LIST

Three-in-one eccentric wheel	Three-in-one sticker	
A  9 PCS	C  9 PCS	

## STEP 5





1. Install No. 6 panels with the three-in-one eccentric wheel tightly.



2. Cover the mounting hole of the eccentric wheel with a three-in-one sticker.



### HARDWARE LIST

Three-in-one  
eccentric wheel  
A  4PCS


Three-in-one  
sticker  
C  4PCS



## STEP 6





1. Install No. 6 panels with the three-in-one eccentric wheel tightly.



2. Cover the mounting hole of the eccentric wheel with a three-in-one sticker.



### HARDWARE LIST

Three-in-one  
eccentric wheel  
A  4PCS


Three-in-one  
sticker  
C  4PCS




## STEP 7



1. Install the hinge cup to the door panel with 4\*16mm screws.



2. Install the hinge to the side panel with 4\*16mm screws.





4. Adjust the door panel clearance.

### HARDWARE LIST

4*16mm screw	Door hinge	
F  24PCS	E  4PCS	

## STEP 8



Install the door handle with 4\*23mm handle screws.

### HARDWARE LIST

4*23mm screw	Door handle	
G  4PCS	H  2PCS	



**Choking hazard-Small Parts :** This unit contains small parts, not for children under 3 years.

**Tip-over hazard :** Secure finished unit to wall stud using L-Bracket and wall screw (#10\*1.5"W/out provided). If a wall stud is not neccessible , Consault your local hardware store for appropriate mounting hardware . Failure to properly install will result in product collapse or tip-over. Serious injury can occur .