


Assembly Instructions



ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.

EASY



DIFFICULT

Tools Required For Assembly:

Allen Wrench



(Included)




2 PERSONS RECOMMENDED

ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


BASIC ASSEMBLY TECHNIQUES




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.



Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.




Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.




FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.


Parts List



#1 x 1pc
Headboard



#2 x 2pcs
Side Rail (L & R)



#3 x 1pc
Footboard



#4 x 2pcs
Center Support Rail



#5 x 39pcs
Slat



#6 x 4pcs
Center Support Rail Leg



#I x 6pcs
L iron


Hardware List



#A x 40pcs
Bolt Ø5/16"X1-1/2"



#B x 40pcs
Lock Washer




#C x 40pcs
Flat Washer



#D x 26pcs
Center Connector



#E x 26pcs
End Cap



#F x 1pc
Allen Wrench M5



#G x 1pc
Wrench



#H x 8pcs
Hex Nut




#1

#A x 24pcs
#B x 24pcs
#C x 24pcs

1. Prepare 24 bolt assemblies by first inserting a lock washer (#B) onto the bolt (#A) then a flat washer (#C) onto that same bolt (#A).


2. Align the side rails (#2L/R) to the holes along the headboard (#1) and footboard (#3), then align the irons (#1) to the corners. Insert the bolt assemblies into each hole. Secure using the Allen wrench (#F).



#2

#A x 8pcs
#B x 8pcs
#C x 8pcs
#H x 8pcs

1. Prepare 8 bolt assemblies by first inserting a lock washer (#B) onto the bolt (#A) then a flat washer (#C) onto that same bolt (#A).




2. Align the center support rail legs (#6) to the holes along the center support rail (#4), then insert the bolt assemblies from above and secure using the Allen wrench. Insert the hex nuts (#H) onto those bolts from below and secure using a wrench (#G).

x 2



#A x 8pcs
#B x 8pcs
#C x 8pcs


1. Prepare 8 bolt assemblies by first inserting a lock washer (#B) onto the bolt (#A) then a flat washer (#C) onto that same bolt (#A).



2. Align each end of the center support rails (#4) to the center holes along the headboard (#1) and footboard (#3). Insert a bolt into each hole and secure using the Allen wrench (#F).



Assemble 13 complete slats by referring to the image. Make sure all parts are firmly inserted, then place them onto the side rails.



Make sure the curved side of the slats face upward.

