


# Lifting Coffee Table



## Instruction Manual

Thank you for shopping with us!












We appreciate your purchase and are ready to be at your service!

If you find parts missing, broken, or hard to put together or when you are not satisfied or have any valuable suggestions, please do not hesitate to contact us first!


We will definitely give you a satisfactory solution or answer then!

Power tool is recommended for the assembly.












# PART LIST

				
<p>Top Panel</p> <p>1 PC</p>	<p>Bottom Panel</p> <p>1 PC</p>	<p>Inner Side Panel</p> <p>2 PCS</p>	<p>Outer Side Panel</p> <p>2 PCS</p>	<p>Inner Long Panel</p> <p>2 PCS</p>
				
<p>Outer Long Panel</p> <p>2 PCS</p>	<p>Left Partition Panel</p> <p>1 PC</p>	<p>Right Partition Panel</p> <p>1 PC</p>	<p>Leg</p> <p>4 PCS</p>	<p>Left Support Bracket</p> <p>1 PC</p>
 <p>Right Support Bracket</p> <p>1 PC</p>				


# ASSEMBLY OVERVIEW



# HARDWARE LIST

<div>#1</div>  <div>Ø5*40mm</div>	<div>#2</div>  <div>Ø8*20mm</div>	<div>#3</div>  <div>Ø8*30mm</div>	<div>#4</div>  <div>Ø6*35mm</div>	<div>#5</div>  <div>Ø15*12mm</div>
<div>Screw</div> <div>14 PCS (Extra 2)</div>	<div>Wood Dowel</div> <div>8PCS (Extra 2)</div>	<div>Wood Dowel</div> <div>12PCS (Extra 2)</div>	<div>Cam-bolt</div> <div>16PCS (Extra 2)</div>	<div>Cam-lock</div> <div>16PCS(Extra 2)</div>
<div>#6</div>  <div>Ø4*25mm</div>	<div>#7</div>  <div>Ø4.5*13mm</div>	<div>#8</div>  <div>M6*13mm</div>	<div>#9</div>  <div>4mm</div>	<div>#10</div>  <div>Ø10*2mm</div>
<div>Screw</div> <div>14PCS (Extra 2)</div>	<div>Screw</div> <div>24 PCS (Extra 2)</div>	<div>Bolt</div> <div>16 PCS(Extra 2)</div>	<div>Allen Wrench</div> <div>1 PC</div>	<div>Bumper</div> <div>4 PCS</div>
 <div>Phillips Screwdriver</div> <div>1 PC</div>				

# Instructions For Fastening CAM-BOLT and CAM-LOCK




CAM-BOLT




CAM-LOCK


Tools Required




## INSERTING AND TIGHTENING CAM-BOLT



Place Cam-bolt on pre-drilled hole and screw in vertically




Shoulder is flushed (on the same level) with the panel.




Shoulder is above the panel.

Place Cam-bolt on the designated pre-drilled holes on the panel. Use a Phillips Screwdriver to screw-in Cam-bolt vertically until shoulder is flushed (on the same level) with panel.


## INSERTING CAM-LOCK



Insert Cam-lock with arrow align to Cam-bolt head




CORRECT



WRONG


Align the arrow on the Cam-lock to the Cam-bolt head and insert the Cam-lock. Ensure Cam-lock is fully inserted.

## TIGHTENING CAM-LOCK




Use a Flat-head Screwdriver to turn Camlock clockwise so it locks onto the head of the Cam-bolt. Turn until it is snug (about 3/4ths of a turn) -- over-tightening could damage Cam-lock or/and Cam-bolt.

## Step 1.




## Step 1.

Screw in Cam-bolt (4) into designated holes on inner long panel (part E).




## Step 2.




## Step 2.

Attach Inner Long Panel (part E) to Outer Long Panel (part F) via Wood Dowel (#2) & Screw (#6),




### Step 3.




### Step 3.

Attach Inner Side Panel (part C) to Outer Side Panel ( part D ) via Wood Dowel (#2) & Screw (#6).





### Step 4.




### Step 4.

Attach parts (C&D,G,H, C&D) to unit (E&F) via Cam-bolt (#4),insert Cam-lock (#5) to turn clockwise to tighten.





## Step 5.




## Step 5.

Insert another unit (E&F) into unit as shown by using Cam-lock (#5) to lock .




## Step 6.




## Step 6.

Attach Bottom Panel (part B) to frame ( unit C,E,G & H ) via Wood Dowel (#2).






### Step 7.




### Step 7.

Use screwdriver or power tool to fasten Screw (#1).




### Step 8.



### Step 8.

Use Screw (#8) and Allen Wrench (#9) to fasten Leg (part I) and tighten.




### Step 9.




### Step 9.

Lay Bumper (#10) on corner.




## Step 10.




### Step 10.


Attach Left/Right Support Bracket (part J , K) to Top Panel (part A) by using Screw (#7).



## Step 11.




#7 x12



x1


## Step 11.

With assistance, use Screw (#7) to fasten bracket (part J & K) to panel (part H & G).



## Step 12.

Push forward the Top Panel (part A), then table-top closed.



The assembly of the table is complete.