

Assembly Instructions

Before beginning the assembly process, please read and save these instructions for reference.

Following these guidelines will ensure a smooth and successful assembly of your product.

1. Part Identification:

Carefully separate and identify all the parts included in your package. Confirm that you have all the components listed in the instruction manual. This step will help you avoid any missing or misplaced parts during assembly.

2. Work Surface:

To prevent any scratches or damage to the product, assemble it on a soft mat or a similar protective surface. This will provide a cushioned area for the components and protect the surfaces from unwanted marks.

3. Step-by-Step Assembly:

Follow the assembly instructions provided, proceeding one step at a time. Take care to understand each step properly before proceeding to the next one. This sequential approach ensures that the assembly is done correctly and minimizes the chance of errors.

4. Proper Screw Seating:

When attaching screws and nuts, it is essential not to fully tighten them until all screws are correctly seated. By partially tightening each screw and nut initially, you can ensure that they are aligned properly and fit securely before final tightening.


5. Avoid Over-Tightening:

While each screw and nut should be tightened correctly, it is crucial not to over-tighten them. Over-tightening can cause damage to the product or compromise its structural integrity. Use the appropriate amount of force to secure the components without excessive tightening.


If you encounter any questions or problems during the assembly process, please do not hesitate to contact us.

We strive to provide excellent customer support and will respond to your inquiries within 24 hours. Our team will offer you a suitable solution to address any concerns you may have.

Parts List









Hardware List




Code	Description	Quantity	Code	Description	Quantity
A	Ø6x35mm Cam bolt	74+4	M	Drawer Slides	12
B	Ø15x10mm Cam lock	74+4	N	Plastic anchor	2
C	Ø8x30mm Wooden dowel	24+2	O	Iron sheet	2
D	M4x35mm Screw	42+3	P	Foot pad	2+2
E	M3x12mm Screw	72+4	Q	Foot pad	3+2
F	M8x50mm Wooden dowel	5+1			
G	Anti falling iron sheet	2			
H	M4x12mm Screw	2+1			
I	Back clip	12+2			
J	M3x16mm Screw	16+2			
K	Handel	6			
L	M4x18mm Bolt	6+1			

Step 1






G*2	H*2	A*6
		

Step 2






X 2






A*4


Step 3




Step 4





Step 5



Press the plastic plastic part in the indicated direotion to seaparste drawer runner M1 and M2 beore assembling.




X12

Step 6







M2 * 3	E * 9
	

Step 7







M2






M2 * 3	E * 9
	



Step 8






A * 7



Step 9





M2*3	E*9
	



Step 10



A*7




Step 11





M2 * 3	E * 9
	

Step 12


X 2





C * 4	B * 4
	


Step 13




X 2





C*4	D*4
	

Step 14






		B*5
		


Step 15




Step 16







Step 17







Step 18





Step 19







Step 20





Step 21







Step 22




Step 25



Step 26





Step 27




I *12	J *12

Step 28




D*2	N*2


Step 29



X 6




Step 30






X 6


Step 31






X 6

L * 6	K * 6	A * 36
		


Step 32




X 6

		B * 36
		


Step 33





X 6







M1



M1*12	E *36
	

Step 34



Preparation: Slide the inner rail (movable track) to the frontmost position
 Precise installation: Position the drawer horizontally. Align both slide rails precisely, then push inward with steady, even pressure until you hear a "click," indicating the lock is engaged. Installation complete.

WARNING: NEVER FORCE the drawer! Incorrect start position or forcing the drawer will cause ball bearings to fall out and damage the slide.

Note: If the drawer does not slide smoothly, lift the release lever on one side and press it downward on the other side at the same time. Pull out the slider bracket from the slider arm, then re-assemble the drawer until they go in smoothly.

Step 35

