



Assembly Instructions





Assembly Instructions:


1. Carefully read tGese instructions and keep tGem for future reference.
2. Refer to tGe parts list for guidance and ensure tGat you Gave all tGe pieces before starting tGe assembly process, if anytGing is missing, damaged, incorrect, contact us FIRSTLY BEFORE assembling.
3. WGen assembling, place all parts on a soft, clean, and flat surface, sucG as a carpet, to prevent any scratcGes.
4. To avoid misalignment of tGe Goles, Please don't full tigGten tGe screws until you ensure all parts in place.










X2




When using the electric screwdriver ,
Reduce the power and torque to avoid damaging the furniture




?
















Make sure all parts are included. Most board parts are labeled or stamped on the raw edge. Contact us for free replacement if having damaged or missing parts.

Parts & Hardware List





Hardware List

A	x2	B	x2	C	x24+1	D	x8+1	E	x28+1	F	x14+1	G	x4	H	x4
															
ø6x40		ø15x12		M6X8mm		M6X30mm		M6X35mm		M6X55mm		M6X70mm		M6	


I	x1	J	x4	K	x11+1
					
M4x65x30		M6Xø23mm		ø8x40	

Installation of Cams and Pins


Screw the pin into the hole. To set the cams correctly, ensure that the arrow on the cam is opening to the hole of the pin it is locking. Lock the cam by turning the cam head with a screwdriver until it is tightened. Please do not use an electric screwdriver to assemble the unit.






Read each step carefully before starting. It is very important that each step of instruction is performed in the correct order. If these steps are not followed in sequence, assembly difficulties will occur.





1




2








C	x12	I	x1
			
M6X8mm		M4x65x30	

3







4





C	x12	I	x1
			
M6X8mm		M4x65x30	



5




E	x4	I	x1
			
M6X35mm		M4x65x30	

6




E	x8	I	x1
			
M6X35mm		M4x65x30	



7





8







9





F	x14	I	x1
			
M6X55mm		M4x65x30	



10






E	x16	I	x1
			
M6X35mm		M4x65x30	




11





D	x4	I	x1
			
M6X30mm		M4x65x30	



12



A	x2	B	x2	H	x4
					
ø6x40		ø15x12		M6	

13



G	x4	I	x1
			
M6X70mm		M4x65x30	

14

