

Ready To Ship  
**CABINETS**

**This cabinet will need the following tools and supplies:**


- Powered Drill with Phillips Head bit or Phillips Screw Driver
- Dead Blow Hammer or Rubber Mallet
- Air Powered Staple Gun or Inexpensive Manual Staple Gun
- 3/8 or 10 Millimeter Staples
- Bottle of Wood Glue
- Hammer and 2D Finish Nails
- Optional: Pneumatic Pin Nailer



## WALL CABINET ASSEMBLY



1. Apply a bead of wood glue into the grooves on the back side of the front face cabinet.



2. Fasten 90-degree assembly bracket along the edge of the groove, this will serve to support the panel in place while the glue forms a permanent bond. Repeat the previous step into opposite side.



3. Slide the top and bottom panels in place and use 90-degree assembly brackets to attach them to the front and to one of the sides.



4. Leave the opposite side on attach for the moment. That way, we can put the back panel in and then put the third assembly on the bracket afterwards.




5. Slide the back panel into the grooves. Line everything up and fasten it together using a staple gun.



6. Afterwards, attach the back panel to the top and bottom using three inch and a quarter wood screws included, put them in the pre-drilled holes, and screw them in.



7. Now that the back panel is secured in place, you can attach a final 90-degree angle bracket to the remaining side on both the top and bottom of the cabinet.



8. Apply clear bumpers to each corner of the doors, and your cabinet is complete.