

ASSEMBLY INSTRUCTIONS



**IMPORTANT
FOR DOMESTIC USE ONLY
PLEASE READ BEFORE YOU CONTINUE FURTHER**

THE PRODUCT YOU HAVE PURCHASED WILL GIVE YOU MANY YEARS OF SERVICE IF YOU FOLLOW THE GUIDELINES FOR ITS SAFE ASSEMBLY AND PERIODIC MAINTENANCE AND CLEANING.

ASSEMBLE ON A SOFT CLEAN SURFACE.

DO NOT USE ANY TOOLS OTHER THAN THOSE SHOWN.


ANY SPANNERS OR ALLEN KEYS REQUIRED ARE INCLUDED WITH THE FITTINGS KIT.

DO NOT FOR ANY REASON USE A POWER TOOL TO ASSEMBLE THIS PRODUCT. ITS USE WILL INVALIDATE ANY CLAIM YOU MAY HAVE AND COULD MAKE THIS PRODUCT UNSAFE.

DEPENDING ON THE AMOUNT OF USE THIS PRODUCT RECEIVES IT MAY BE NECESSARY TO TIGHTEN UP THE FIXINGS FROM TIME TO TIME. THIS IS COMPLETELY NORMAL FOR ANY FLAT PACK FURNITURE. DO NOT OVERTIGHTEN FIXING.

FOR CLEANING, YOU MAY USE A DAMP CLOTH (NOT WET) DO NOT USE POLISH, DÉTERGENT OR CHEMICAL CLEANERS.





























THE SURFACE OF THIS ITEM IS NOT HEAT RESISTANT. ALWAYS USE A PLACE MAT UNDER HOT OR COLD ITEMS TO PREVENT MARKING.




PART LIST

Part Number	Part Code	Part Description	Quantity	Carton
1	S100-101-058-EU2-01	Inner Side Panel	1	2/4
2	S100-101-058-EU2-02	Centre Shelf	1	2/4
3	S100-101-058-EU2-03	Top Panel	1	3/4
4	S100-101-058-EU2-04	Base Panel	1	3/4
5	S100-101-058-EU2-05	Base Front Apron	1	3/4
6	S100-101-058-EU2-06	Base Back Apron	1	3/4
7	S100-101-058-EU2-07	Left Side Panel	1	1/4
8	S100-101-058-EU2-08	Back Crossbars	2	3/4
9	S100-101-058-EU2-09	Right Side Panel	1	1/4
10	S100-101-058-EU2-10	Inner Side Frame 1	1	3/4
11	S100-101-058-EU2-11	Inner Side Frame 2	1	3/4
12	S100-101-058-EU2-12	Back Panel	3	4/4
13	S100-101-058-EU2-13	Door Panel - Left	1	4/4
14	S100-101-058-EU2-14	Door Panel - Right	1	4/4
15	S100-101-058-EU2-15	Mirrored Door	1	4/4
16	S100-101-058-EU2-16	Shelf Panel	3	2/4
17	S100-101-058-EU2-17	Drawer Back	2	2/4
18	S100-101-058-EU2-18	Drawer Side - Left (Large)	1	2/4
19	S100-101-058-EU2-19	Drawer Side - Right (Large)	1	2/4
20	S100-101-058-EU2-20	Drawer Front - (Large)	1	2/4
21	S100-101-058-EU2-21	Drawer Base	2	2/4
22	S100-101-058-EU2-22	Drawer Bottom Support Rail	2	2/4
23	S100-101-058-EU2-23	Drawer Side - Left (Small)	1	2/4
24	S100-101-058-EU2-24	Drawer Side - Right (Small)	1	2/4
25	S100-101-058-EU2-25	Drawer Front - (Small)	1	2/4


HARDWARE LIST

A		DOWEL 6 X 30MM	46 PCS	O		MIRRORED DOOR HINGES 5/8	3 PCS
B		BOLT M6 X 50MM	18 PCS	P		DRAWER RUNNER A - L/R	4 PCS
C		BOLT M7 X 60MM	2 PCS	Q		DRAWER RUNNER B - L/R	4 PCS
D		SCREW M3.5 X 16MM	37 PCS	R		SCREW M4 X 30MM	4 PCS
E		TACK	36 PCS	S		HANDLE SCREW 19MM	6 PCS
F		SCREW M4 X 38MM	8 PCS	T		LOCK	1 SET
G		HANDLE	3 PCS	U		SCREW M3.5 X 12MM	20 PCS
H		TAPPING SCREW M8 X 12MM	18 PCS	V		CAM BOLT + CAM NUT	4 SETS
I		HANGING RAIL SUPPORT	2 PCS	W		PLASTIC FOOT	5 PCS
J		HANGING RAIL	1 PC	X		PLASTIC FOOT FRONT	1 PC
K		PLASTIC H STRIP	2 PCS	Y		SCREW M4 X 50MM	12 PCS
L		SHELF SUPPORT	12 PCS	Z		ALLEN KEY	1 PC
M		PVC STOPPER	1 PC	Z1		ANTI - TIP STRAP	2 PCS
N		RIGHT/LEFT DOOR HINGES 7/8	6 PCS	Z2		SCREW M4 X 16MM	2 PCS



(SCREWDRIVER NOT PROVIDED)

USE A FLAT HEAD SCREWDRIVER TO TIGHTEN THE CAM NUTS. A QUARTER TURN CLOCKWISE IS ALL THAT IS NEEDED.



STEP 1 - PUSH CAM BOLT INTO INSERT

STEP 2 - ALIGN THE CAM BOLT WITH THE HOLE AND PUSH TOGETHER UNTIL FLUSH. (MAKE SURE THE ARROW OF THE CAM LOCK IS POINTING TOWARD ON THE EDGE OF THE PANEL.)

STEP 3 - THE HEAD OF THE BOLT GOES INTO THE WIDE MOUTH OF THE CAM LOCK. YOU THEN TURN THE LOCK SO THE NARROW PART CLOSES OVER THE BOLT.

STEP 1

PARTS REQUIRED


7 - LEFT SIDE PANEL x1

9 - RIGHT SIDE PANEL x1




HARDWARE REQUIRED

I  01

L  06

U  02

TOOLS REQUIRED



STEP 2

PARTS REQUIRED


1 - INNER SIDE PANEL x1

HARDWARE REQUIRED



A  04

I  01

L  06

U  02

TOOLS REQUIRED



STEP 3



PARTS REQUIRED

2 - CENTRE SHELF	x1
4 - BASE PANEL	x1
5 - BASE FRONT APRON	x1
6 - BASE BACK APRON	x1
8 - BACK CROSSBARS	x2

HARDWARE REQUIRED

A		28
---	---	----

TOOLS REQUIRED




STEP 4


PARTS REQUIRED


3 - TOP PANEL	x1
10 - INNER SIDE FRAME 1	x1
11 - INNER SIDE FRAME 2	x1


HARDWARE REQUIRED

A		04
---	---	----



D		01
---	---	----

M		01
---	---	----

P		04
---	---	----

U		16
---	---	----

TOOLS REQUIRED




STEP 5

PARTS REQUIRED


1 - INNER SIDE PANEL x1

2 - CENTRE SHELF x1

HARDWARE REQUIRED

B  02

TOOLS REQUIRED




STEP 6


PARTS REQUIRED

3 - TOP PANEL x1



4 - BASE PANEL x1



HARDWARE REQUIRED

Y  04


TOOLS REQUIRED





STEP 7

PARTS REQUIRED


- 5 - BASE FRONT APRON x1
- 6 - BASE BACK APRON x1
- 7 - LEFT SIDE PANEL x1



HARDWARE REQUIRED

- B  07
- C  01


TOOLS REQUIRED





STEP 8

PARTS REQUIRED



- 8 - BACK CROSSBARS x2
- 9 - RIGHT SIDE PANEL x1



HARDWARE REQUIRED

- B  09
- C  01


TOOLS REQUIRED




STEP 9

PARTS REQUIRED



- 10 - INNER SIDE PANEL x1
- 11 - INNER SIDE PANEL x1




HARDWARE REQUIRED

- Y  08


TOOLS REQUIRED




BACK SIDE VIEW



BACK SIDE VIEW




SIDE VIEW








STEP 10

PARTS REQUIRED



- 12 - BACK PANEL x3





HARDWARE REQUIRED

- D  06
- E  24
- K  02
- W  05
- X  01

TOOLS REQUIRED



PLEASE INSERT THE BACK PANEL INTO THE UNIT








STEP 11



PARTS REQUIRED

13 - DOOR PANEL - LEFT	x1
14 - DOOR PANEL - RIGHT	x1
15 - MIRRORED DOOR	x1

HARDWARE REQUIRED

D		18
G		03
N		06
O		03
S		06

TOOLS REQUIRED




PLEASE MAKE SURE THE MIRRORED DOOR HINGES (HARDWARE O) ARE ATTACHED TO THE MIRRORED DOOR (PART 15)



STEP 12

PARTS REQUIRED



13 - DOOR PANEL - LEFT	x1
------------------------	----



HARDWARE REQUIRED

H		06
J		01

TOOLS REQUIRED



1. VERTICAL ADJUSTMENT VIA SLOT IN THE MOUNTING PLATE

2. LATERAL ADJUSTMENT BY SCREW ADJUSTING


3. FRONT-TO-BACK BY THE SLACKING THE HINGE ARM MOUNTING SCREW

YOU SHOULD RE-ADJUST SCREWS AS SHOWN TO ALIGN DOOR ONCE HINGES HAVE BEEN ATTACHED.

STEP 13

PARTS REQUIRED


- 14 - DOOR PANEL - RIGHT x1
- 15 - MIRRORED DOOR x1
- 16 - SHELF PANEL x3



HARDWARE REQUIRED

- H  12

TOOLS REQUIRED






STEP 14



PARTS REQUIRED

- 17 - DRAWER BACK x1
- 18 - DRAWER SIDE-LEFT(LARGE) x1
- 19 - DRAWER SIDE-RIGHT(LARGE) x1
- 20 - DRAWER FRONT-(LARGE)x1

HARDWARE REQUIRED

- A  04
- F  04
- V  02


TOOLS REQUIRED




STEP 15

PARTS REQUIRED

21 - DRAWER BASE x1





HARDWARE REQUIRED

E  06

T  01

V  02


TOOLS REQUIRED



STEP 16


PARTS REQUIRED


22 - DRAWER BOTTOM SUPPORT RAIL x1




HARDWARE REQUIRED



A  02

D  06

Q  02

R  02

TOOLS REQUIRED






STEP 17



PARTS REQUIRED

- 17 - DRAWER BACK x1
- 23 - DRAWER SIDE-LEFT(SMALL) x1
- 24 - DRAWER SIDE-RIGHT(SMALL) x1
- 25 - DRAWER FRONT-(SMALL) x1

HARDWARE REQUIRED

- A  02
- F  04
- V  02


TOOLS REQUIRED





STEP 18

PARTS REQUIRED



- 21 - DRAWER BASE x1



HARDWARE REQUIRED

- E  06
- V  02


TOOLS REQUIRED



STEP 19

PARTS REQUIRED


22 -DRAWER BOTTOM SUPPORT RAIL x1



HARDWARE REQUIRED



A  02

D  06

Q  02



R  02

TOOLS REQUIRED




STEP 20




PARTS REQUIRED



HARDWARE REQUIRED

TOOLS REQUIRED



STEP 21PART REQUIREDHARDWARE REQUIREDZ1  02Z2  02TOOLS REQUIRED**WARNING**

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.

Wall fixings are not supplied with this product as different wall materials require different types of fixing devices. Please make sure you use fixings suitable for the walls in your home.

