





Steel Storage Rack

MODEL NUMBER (s)
ZB301260WD-5 ZB361872WD-5
ZB481872WD-5



5Shelf 60h x 12d x 30" w				5Shelf 72h x 18d x 36" w				5Shelf 72h x 18d x 48" w			
Description	Qty	Part Number	Size	Description	Qty	Part Number	Size	Description	Qty	Part Number	Size
A Beams	10	URM40	29"-7/16"	A Beams	10	URM46	35"-7/16"	A Beams	10	URM46	47"-7/16"
B Braces	10	URM2	11"-7/16"	B Braces	10	URM6	17"-7/16"	B Braces	10	URM6	17"-7/16"
C Posts	8	URPS30	30"	C Posts	8	URPS36	36"	C Posts	8	URPS36	36"
D Shelves	5	1230W	12"X30"	D Shelves	5	1836W	18"X36"	D Shelves	5	1848W	18"X48"
E Couplers	4	COUPLERS	4"	E Couplers	4	COUPLERS	4"	E Couplers	4	COUPLERS	4"

Safety Instructions

These units should be placed on a level surface. Failure to do so can result in poor product performance or create a possible safety hazard. This unit should be securely anchored to a wall or floor with suitable fasteners, which are not included. Do not use this unit for anything other than the manufactures intended purpose. **DO NOT STAND ON ANY PART OF THE UNIT, OR USE IT AS A LADDER.** Evenly distribute the weight on each level and always keep the heavier loads on the bottom. Use care when working with metal parts.

General Instructions

Assembly is done with the rivets of the beams and braces fitting into the slots of the post. A rubber mallet may be used on the beams and braces to seat the rivets properly. A hammer can also be used, providing one uses a cloth or a block of wood between the hammer head and the parts to prevent damage. Tap gently and be sure the rivets are straight and fully engaged.

Should you have any comments, damage, missing parts, or problems with assembly of this unit please feel free to contact our customer service
MONDAY - FRIDAY 8:00 AM - 5:00PM CST
WEBSITE: WWW.BANDGOODSINC.COM
EMAIL: HELP@BANDGOODSINC.COM

To better assist you please have the following information available: model number, UPC or a description.



The plastic coupler has patents pending

Made in Vietnam

Assembly Instructions

Step

1

Figure B

Note:
Post are directional.
The slot must point down.




Figure A






Figure C



Assemble two (2) post with one (1) brace. Skipping one slot from the bottom of the post (see figure A), place the rivets into post with the slot pointing down, and with the shelf ledge of the brace facing up (see figure B). Tap lightly to seat rivets. Repeat with two (2) post and one (1) brace. Assemble the two (2) post units with two (2) beams (see figure C). Skip one hole from the bottom of post, tap lightly to seat rivets.

Step

2



Start by adding a wire shelf to the level previously built, then continue working by adding the second level using two (2) beams and two (2) braces in the post slots of your desired location. Again place the rivets of the beams and braces into the post slots with the shelf ledge facing up and tap lightly to seat the rivets.


IMPORTANT NOTE : Make sure all rivets are fully seated into the post slots.

Step

3

Note:
Post are directional. The slot must point down.

Figure D




Add a wire shelf to the previously built level, then assemble the top post to the bottom post by using four (4) of the post couplers. Place the couplers into the top of the bottom post, and the bottom of the top post and tap down to properly seat (see figure D). Continue by adding the third level using two (2) beams and two (2) braces just above the post couplers. Again tap lightly to seat the rivets.

Step

4

Figure E



Add a wire shelf to the previously built level, then continue by adding the fourth and fifth level to the unit using two (2) beams and two (2) braces per level. Tap lightly to properly seat the rivets and add the final wire shelves to the unit (see figure E).