### **Index** B **Parts** Description Q'ty No. Α Dresser 1 pc В Mirror 1 pcs Wood Bracket 2 pcs С

NOTE:Inspect all packing material for small parts, which may have come loose during shipment. Indentify and compare all parts against the parts list.

Leg

4 pcs

## Frichael Amini.


construct this exquisite piece.


#### JANE SEYMOUR<sup>TM</sup> A DESIGN COLLABORATION

Hollywood Loft "UPHOLSTERED Dresser / Mirror" ASSEMBLY INSTRUCTION 9001650-104/9001650-401 9001660-08/9001660-401



www.amini.com





Instructions:

Figure 2

1.Place **B**(Mirror) onto A(Dresser). Secure B and A by inserting K(Flat Washer) +J(Spring Washer) +I(Hex Bolt) and tighten with M(Screw Driver)

#### Instructions:

Figure 1

1. Lay down the A(Dresser) to a smooth, soft and flat surface.

2.Place D(Leg) onto A(Dresser). Secure D and A by inserting  $G(Flat\ Washer)$  + $F(Spring\ Washer)$  + $E(Hex\ Bolt)$  and tighten with  $H(Wrench\ 10mm)$ .

#### **Assembly Hardwares (MIRROR)**

# No. Description Q'ty I Hex Bolt (∅1/4"\*1-1/4"L) 8pcs J Spring Washer (∅1/4"\*12mm) 8pcs K Flat Washer (∅1/4"\*19mm) 8 pcs M Screw Driver 1 pc

#### **Assembly Hardwares (Dresser)**

No.	Description		Q'ty
Е	<b>**</b>	Hex Bolt (Ø1/4"*1-1/4"L)	12pcs
F	0	Spring Washer (Ø1/4"*12mm)	12pcs
G	0	Flat Washer (Ø1/4"*16mm)	12 pcs
Н		Wrench 10mm	1 pc

Wichael Amini. &

## JANE SEYMOUR™ A DESIGN COLLABORATION

Hollywood Loft "UPHOLSTERED Dresser / Mirror" ASSEMBLY INSTRUCTION 9001650-104/9001650-401 9001660-08/9001660-401

