




# Installation & Assembly

Version:1.0




x2




**EN\_IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.**


## USING CAM LOCK AND QUICKFIT




**EN\_QUICKFIT:** Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.



**EN\_CAM LOCK:** When fitting cam lock, ensure starting position is correct before you insert connecting quickfit.


















**EN\_Quickfit** head should be in the centre of the cam lock when the two panels are joined.  
Cam lock should be inserted before quickfit.




**EN\_Turn** cam lock clockwise to tighten.


**PACKING DETAILS**



















NO.	PARTS	QTY	SPARE
1		x2	
2		x2	
3		x2	
4		x2	
5		x2	
6		x2	
7		x2	
8		x2	
9		x4	
10		x4	


NO.	PARTS	QTY	SPARE
11		x4	
12		x4	
13		x4	
14		x4	
	 Hardware Kit	x1	



x2



<p><b>A</b> x44 Ø6x35mm +3(spare)</p> 	<p><b>B</b> x44 Ø15x10mm +3(spare)</p> 	<p><b>C</b> x28 Ø6x30mm +2(spare)</p> 	<p><b>D</b> x16 Ø4x35mm +1(spare)</p> 	<p><b>E</b> x48 Ø3.5x12mm +4(spare)</p> 	<p><b>F</b> x4</p>  
<p><b>G</b> x2</p>  <p>G-1</p>  <p>G-2</p>	<p><b>H</b> x16 Ø3x16mm +1(spare)</p>  <p>H-1</p>  <p>H-2</p>	<p><b>I</b> x2</p> 	<p><b>J</b> x2 Ø3x10mm</p>  <p>J-1</p>  <p>J-2</p>	<p><b>DL</b> x4 L300mm</p> 	<p><b>DR</b> x4 L300mm</p> 
<p><b>CL</b> x4 L300mm</p> 	<p><b>CR</b> x4 L300mm</p> 				






E x24

DL x4

DR x4

02



x4



F x4

03

x4





E x12

CL x4

x2

04





E x12


CR x4

x2

05




A x10




x2

06




A x10



x2

07




B x10

C x10




x2

08




B x10

C x10





x2

09



x2




x2

A x8

J x2






I x2



J-1




J-2



B x8

C x8

x2











H-1




H-2








(1)



(2)



x2



x2

x2

