




CARPORT USER MANUAL

10 X 20 FT

12 X 20 FT



⚠ Attention:
Please read the manual completely before starting the installation(A ladder & an electric drill are recommended for the assembly.)







1. Please confirm that the parts are complete and undamaged.
(Corresponding part number is affixed to each part)






If any parts are missing or damaged, please contact the customer support email to reissue or contact seller.






1.1 customer support email: dexso_service@outlook.com

Please Contain: ① Order number ② Model number ③ Item Number ④Photos of the missing/damaged parts(optional)

1.2 Steps to Contact seller (amazon.com orders only):
Step 1: Log into your Amazon account
Step 2: Go to “Your Orders” and find the purchase
Step 3: Click on “Contact Seller”


Item NO.	Item Name	Reference Image	Qty.
1	Steel Pipe		8 PCS
2	Steel Pipe		9 PCS
3	Steel Pipe		8 PCS
A	3-Way Corner Connector		6 PCS
B	4-Way Corner Connector		6 PCS
C	Foot Plate		8 PCS

Item Name	Reference Image	Qty.
Ground Peg		32 PCS
M8 x 50MM Screw		8 PCS
Rope		4 PCS
Anchor		4 PCS
Bungee Cords		60 PCS + 4 PCS Spares

Item Name	Reference Image	Qty.
Top Cover		1 PC
Sidewall		1PC
Sidewall		1PC
Zipper Door		2 PCS
		2 PCS

2. Arrange and classify the parts neatly to facilitate installation.

This is the part structure diagram of our product, you can combine this diagram and follow the steps to install





3.Start installation works


Step 1:



Assemble the long pipes required on the top of the carport (the length after connection is 20 feet), a total of three. You will use ② x 3 pcs
A x 2 pcs, B x 2 pcs for each pipe.

Part Required


② 9 PCS


Ⓐ 6 PCS




Ⓑ 6 PCS



Step 2:

Connect the obtained three 20 Feet long pipes with the pipe ① to get the carport roof frame.


Part Required




Step 3:


Put the Top Cover on the top frame

Part Required



1 PC




 Attention: Be sure to cover the top cover at this time, otherwise the subsequent installation will not work normally



Step 4:

Connect 2 pipe ③ with the top frame.

Part Required




③2pcs




Step 5:

Connect 2 pipe ③ with the top frame.

Part Required



③2pcs



Step 6:

Repeat the Step 4 & Step 5 to install another side.


Part Required




③4pcs

Step 7:

Part Required




12 PCS



2pcs

Pass 2 doors through bungee jumping rope


Installed in the frame




Step 8:

Connect the pipe C with ③ pipe that already installed, at this point you will get a complete carport frame with roof.


Part Required



8pcs






8pcs



Step 9:

Use bungee cords to install the gate and side walls.



Part Required



Step 10:

Fix the drawstring and tent feet to the ground.

Part Required



Step 11:

