


Assembly Instructions



ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.


EASY  DIFFICULT

Tools Required For Assembly:

Allen Wrench



Phillips Screwdriver




2 PERSONS RECOMMENDED

ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


BASIC ASSEMBLY TECHNIQUES




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.



Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.




Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.




Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.



FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.




Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.

Parts List


Hardware List



#1 x 1pc
Talbe Top




#A x 12 pcs
Bolt 5/16" x 1"




#2 x 1pcs
Bottom Panel




#B x 4 pcs
Bolt 5/16" x 2"




#3 x 4 pcs
Leg




#C x 16 pcs
Lock Washer



#4 x 2pcs
Shelf



#D x 16 pcs
Flat Washer



#E x 1 pc
Allen Wrench



#F x 1 pc
Fall prevention hardware



#G x 8 pcs
Shelf support




#H x 8 pcs
Screw




Align legs (#3) to the holes of the shelf (#2). Prepare 4 bolts assemblies by inserting a lock washer (#C), then a flat washer (#D) onto bolts (#B). Secure with bolts (#B) by using an Allen wrench (#E).

#B x 4 pcs
#C x 4 pcs
#D x 4 pcs




Align legs (#3) to the holes of the bottom of the table top (#1). Prepare 12 bolts assemblies by inserting a lock washer (#C), then a flat washer (#D) onto bolts (#A). Secure with bolts (#A) by using an Allen wrench (#E).

#A x 12 pcs
#C x 12 pcs
#D x 12 pcs






Unscrew the knobs located in the table top.




Attach the knob to the outside of the table top and secure.





#G x 8 pcs
#H x 8 pcs

Adjust the level of the shelf located in the table top by using the shelf support (#G), then secure shelf with screws (#H).



Optional: Attach fall prevention hardware to the wall, then to the table top to prevent the product from falling.

#F x 1 pc

