





## Before You Start

-  **Read each step carefully before starting. It is very important to ensure each step followed in correct order, otherwise assembly difficulties may occur.**
-  Most of board parts are labeled or stamped on the raw edges. Have a check to make sure all parts are included.
-  Work in a spacious area, preferably on a carpet close to where the unit will be used.
-  Keep the handtools close at hand. Do not use power tools to assemble your furniture. They may scratch or damage the parts.



## **Care and Maintenance**

**Use a soft, clean cloth that will not scratch the surface when dusting.**

**Use of furniture polish is not necessary.**

**Should you choose to use polish, test first in an inconspicuous area.**

**Using solvents of any kind on your furniture may damage the finish.**

**Never use water to clean your furniture as it may cause damage to the finish.**

**Liquid spills should be removed immediately. Using a soft cleancloth, blot the spill gently. Avoid rubbing.**

**Check bolts/screws periodically and tighten them if necessary.**

## **Further advice about wood furniture care**

**It is best to keep your furniture in a climate-controlled environment.**


**Extreme temperature and humidity changes can cause fading, warping, shrinking and splitting of wood.**

**It is advised to keep furniture away from direct sunlight as sun may damage the finish.**

**Proper care and cleaning at home will extend the life of your purchase.**


**Following these important and helpful tips will enhance your furniture as it ages.**

**STEP C:**




To drive plastic anchor into the wall.

**STEP D:**



















Fix the bracket to the wall with screw.


# Detail View





## Part List

<b>A</b>  Horizontal HB/FB - 8pcs	<b>A1</b>  Horizontal HB/FB - 4pcs	<b>B</b>  Leg (Left front/Right back) - 2pcs
<b>C</b>  Leg (Left back) - 1pc	<b>D</b>  Leg (Right front) - 1pc	<b>E</b>  Guard rail (Back) - 2pcs
<b>F</b>  Upper side rail (Back) - 1pc	<b>G</b>  Vertical guard rail - 2pcs	<b>H</b>  Guard rail (Front) - 2pcs
<b>I</b>  Upper side rail (Front) - 1pc	<b>J</b>  Lower side rail (Front) - 1pc	<b>K</b>  Lower side rail (Back) - 1pc
<b>L</b>  Left side ladder - 1pc	<b>M</b>  Right side ladder - 1pc	<b>N</b>  Step ladder - 3pcs
<b>O</b>  Slats - 2set (14pcs/set)		


STEP A:



10	
4PCS	
13	
2PCS	


Installing the Anti-Tip Bracket.

STEP B:





Drill holes in the wall.

**STEP 5:**









**STEP 6:**









Note: Do not lock the screws of the bed slats to the outermost edge of the bed slats, you need to leave a certain space at the edges, otherwise it will cause the board to break. Do not lock the bed slats on the edge of the wood, please hold firmly before screwing, hold it in place with one hand, then lock the screw.


## Hardware List

<b>1</b>  $\text{Ø}10 \times 40\text{mm}$ Wood dowel (6pcs)	<b>2</b>  $(\text{Ø}15)1/4 \times 100\text{mm}$ Hex-Head bolts (16pcs)	<b>3</b>  $(\text{Ø}15)1/4 \times 80\text{mm}$ Hex-Head bolts (22pcs)
---	--	---


<b>4</b>  $(\text{Ø}12)1/4 \times 60\text{mm}$ Hex-Head bolts (6pcs)	<b>5</b>  $(\text{Ø}12)1/4 \times 40\text{mm}$ Hex-Head bolts (6pcs)	<b>6</b>  $(\text{Ø}12)1/4 \times 30\text{mm}$ Hex-Head bolts (6pcs)
--	--	--

<b>7</b>  $1/4 \times 15 (9.5\text{mm})$ Horizontal-Hole bolts (44pcs)	<b>8</b>  $\text{Ø}4 \times 30\text{mm}$ Wood screws (16pcs)	<b>9</b>  $(1/4)4.5 \times 58\text{mm}$ Allen key (1pc)
--	--	---

<b>10</b>  $\text{Ø}4 \times 25\text{mm}$ Wood screws (4pcs)	<b>11</b>  $\text{Ø}4 \times 38\text{mm}$ Wood screws (2pcs)	<b>12</b>  $\text{Ø}9 \times 32\text{mm}$ Plastic anchor (2pcs)
--	--	---


<b>13</b>  $58 \times 16 \times 16 (1.5\text{mm})$ Metal bracket (2pcs)
---

### ASSEMBLY TOOLS REQUIRED ( NOT INCLUDED )




PLEASE BE CAREFUL DO NOT DAMAGE THE HOLE POSITION WHEN YOU USE POWER TOOLS !

**STEP 1:**




2	7
16PCS	16PCS


Note: Part 7 will face up with the "x" mark on it, otherwise it cannot be tightened




**STEP 2:**



1	3
4PCS	20PCS
6	7
3PCS	20PCS



**STEP 3:**



**STEP 4:**

