




Mass: 254.4 kg

SHIRE
BUILT AROUND OUR REPUTATION

© 8x6 Highclere



These instructions are for your safety. Please read through them thoroughly before use.
PLEASE KEEP THIS LEAFLET FOR FUTURE REFERENCE

Let's get started...



Important information...

Safety	03
Preparation of base	04
Warranty	04
Care, maintenance & Recycling	05

In more detail...



Parts List	06
Fascia & Nail List	07
Hardware chart	8
Before you start	9
Detailed Technical Drawing	10-11
Assembly instructions	12-24

EN	For a copy of the instructions or a copy in another language please send an email or write to the address below.
F	Pour obtenir un exemplaire des instructions ou une copie dans une autre langue s'il vous plaît envoyez un e-mail ou écrire à l'adresse ci-dessous.
I	Per richiedere una copia del libretto di istruzioni, in italiano, o in un'altra lingua, per favore, invia una e-mail o scrivi a l'indirizzo sottostante.
PL	Na kopii instrukcji lub kopii w innym języku prosimy o wysłanie maila lub pisać na adres podany poniżej.
RUS	Для получения копии инструкции или копия на другом языке, пожалуйста, отправьте по электронной почте или написать по указанному ниже адресу.
TR	Başka bir dilde talimatları veya bir kopyasını bir kopyası için bir e-posta gönderebilir veya aşağıdaki adrese yazınız.

Safety

Check that you have noted all the following instructions:



- We advise the use of non slip protective gloves throughout the assembly process.
- We advise the use of steel capped protective footwear throughout the assembly process.
- We advise that you use a helper to hold the glass in position whilst you nail the beading in place.
- We advise the use of protective headwear and safety goggles throughout the assembly process.
- Where a ladder is in use another person must hold the ladder.
- Do not attempt to work in windy conditions.
- We advise the use of a scaffold tower when fitting the roof, for felting or if you cannot reach from the ground.
- Do not allow children near the tools and work area.
- Follow any safety precautions quoted by the manufacturer for any equipment you use.
- Check all parts before assembly.
- Only use child and animal safe wood preservative.
- Do not use creosote.
- Allow the wood preservative to fully dry before use.
- Regularly check the building for wear and tear.

Important!

EVERY PRECAUTION IS TAKEN TO ENSURE THAT YOUR BUILDING HAS NO ELEMENT INCORRECTLY PLACED OR POSSIBLY HAZARDOUS, HOWEVER PRIOR TO USE PLEASE CHECK ALL SURFACES FOR THE FOLLOWING:

- (1) RAISED GRAIN, SPLINTERS: Sand down timber to smooth finish
- (2) NAIL/SCREW/PIN HEADS PROUD: Tap home to be flush with surface of timber.
- (3) DAMAGED SCREW HEADS RESULTING IN SHARP SPLINTERS OF METAL: Replace.
- (4) SHARP ENDS OF NAILS/ SCREWS/ PINS PROTRUDING THROUGH THE PANEL: Remove and reposition.
- (5) ENSURE ALL PARTS ARE SECURED AGAINST REASONABLE FORCE: Remove and refit.
- (6) ENSURE THERE ARE NO LOOSE PARTS: Remove and refit/discard.



IMPORTANT ! For your safety please read carefully the safety warnings

Preparation of base...

We recommend that the base onto which your building will stand should be at least 75mm larger in each direction than the total floor size of the building.

- **Actual floor area of the building:** 2300mm x 1790mm
- **Total height clearance:** 2183mm
- **Roof size:** 2442mm x 2327mm

The chosen position in your garden for your building should be excavated to a depth of 75mm to allow a base of sand, on to which paving slabs can be evenly laid. You may also use an adjustable timber base or a concrete base. Whatever base you decide upon IT MUST BE LEVEL AND FIRM.

Warranty...

10 Year anti rot warranty subject to the following:

- The building must be raised so it is not in contact with any water retaining base surface (for example grass).
- This can be achieved using a timber, concrete or slab base.
- When using a concrete or slab base use damp proofing strips under the bearers.
- The building must have been completely treated and sealed prior to assembly.
- The building must have been re-treated and re-sealed annually.

NOTE: Wood is a natural product, and therefore the following are excluded from the warranty:

- Colour change.
- Warping.
- Splitting.

The following are also excluded:

- Damage resulting from poor assembly.
- Poor treatment application.
- Poor care and maintenance.
- Changes to the design.
- Misuse.
- General wear and tear.

Building Photographs

It will be greatly appreciated if you could forward images of your completed building to -

sales@shiregb.co.uk.

Care, Maintenance and Recycling

The 5 golden rules of care:

- (1) Ensure your base is level and firm.
- (2) Ensure the building is not sitting directly on the ground using damp proof membrane or the optional timber base.
- (3) Ensure every piece of timber and surface, especially that is hidden upon assembly, is treated with a top quality wood preservative at least twice (before assembly). Turn the panels upside down whilst painting so the treatment runs into the seams.
- (4) Garden buildings are not waterproof, therefore you must seal between all the panels with a silicone based sealant.
- (5) Regularly check your roofing felt for weather damage and leaks.

The 6 golden rules of maintenance:

- (1) Visually check for weather damage.
- (2) Check and replace if necessary any Silicone sealant if used on your building.
- (3) Check the roofing material for wear.
- (4) The doors and windows may require periodical adjustment.
- (5) Ensure your building is well ventilated especially during hot weather.
- (6) During extremely hot periods humidify your building to prevent the timber from drying out.

Recycling and disposal:



packaging

1. Pallet and timber widely recycled.
2. Cardboard widely recycled.
3. Plastic strapping subject to local regulations.
4. Plastic sheeting subject to local regulations.




Building


1. Timber widely recycled.
2. Metal fixings widely recycled.
3. Glass widely recycled.
4. **Roofing felt not currently recycled.**

Stacked Parts List


FLOOR PANEL
(A5652)x01




PLAIN PANEL
(A5641)x01




LH WINDOW PENT
(A5653)x01




RH WINDOW PENT
(A5654)x01




SOFFIT
(A5639)x01




DOUBLE DOOR PANEL
(A5644)x01




WINDOW PANEL
(A5645)x01




LH ROOF PANEL
(A5655)x01




RH ROOF PANEL
(A5655)x01



2.7m Felt Strip
(A2555)x03




ACRYLIC 1534x547
(A1317)x05




Fascia and Nail Bag Parts List


FASCIA 19X145X2480
(A4445)x01




FASCIA 19X145X1941
(A4446)x02




FASCIA 19X145X470
(A5650)x02




COVERSTRIP 12X46X1837
(A3986)x02




COVERSTRIP 12X46X2086
(A5649)x01



BEADING 1538MM
(A0073)x10



BEADING 550MM
(A0075)x10




DOOR HANDLE
(A2179)x01



Hardware Chart Scale 1:1


16mm Panel Pins
(A0024) x90




13mm Felt Nail
(A0023) x226




40mm Round head nail
(A0025) x28



25mm Posi-drive screw
(A0032) x08



60mm Posi-drive screw
(A0035) x58





Before you start...

Things to check before you start:

- ✓ Ensure your base is ready – See page 4.
- ✓ Check all parts as listed in the parts lists.
- ✓ Read the instructions fully before starting work.
- ✓ Follow all the health and safety guidelines.




When you see the drill icon
Only ever drill through the first piece of framework which will be a pilot hole for the screw to attach the second piece of framework
The required drill bit size is shown with the icon.



You will need:




- Hammer



- Spirit level




- Ladder




- 1mm 3mm 5mm 8mm drill bit



- Drill




- Tape measure & Ruler




- Sand paper



- Gloves




- Saw




- Pencil




- Goggles



- A helper for some tasks




- Screwdriver




- Sharp knife



- Masking tape





2.7M FELT STRIP
A2555

RH ROOF PANEL
A5655

FASCIA 19X145X1941
A4446

PLAIN PANEL
A5641

COVERSTRIP 12X46X1837
A3986

RH WINDOW PENT
A5654

ACRYLIC 1534x547
A1317

BEADING 1538mm
A0073

BEADING 550mm
A0075

FLOOR PANEL
A5652

In more detail.....

Assembly instructions:



These instructions are for your safety. Please read through them thoroughly before use.
Treat all the parts before assembly – see page 5!

GB-IE


The 8' Plain Panel, Door and Window Panel FIT INSIDE THE RH & LH Window Panels !

The "Panel Layout" is showing you how the **Door** and **Window Panels** can be swapped.


01



Floor Panel
(A5652)x01



**The door and window panels
can be swapped.**





**Please see Page 4 for base
instructions.**


Carefully put the **Floor Panel (A5652)** onto your chosen **base**.

GB-IE Fix the **Door Handle (A2179)** to the **Double Door Panel (A5644)** as shown below. Make sure the Handle is fixed to the **primary** door (the door that is opened first). Fix with **25mm Screws (A0032)**.


02



Double Door Panel (A5644)x01



Door Handle (A2179)x01





25mm screws (A0032)x08



If using a drill or electric screwdriver carefully but firmly push the opposite end to the screwdriver bit into the screw head and keep the pressure on to prevent the screwdriver spinning in the screw.


Drill a pilot through first panel only so the screw stem drops through and the screw self taps into the second panel.




Drill the **LH Window Pent (A5653)** and the **Plain Panel (A5641)** as below. Make sure the holes in the LH Window Pent are inline with the floor bearers. Place the LH Window Pent onto the floor into the corner and push the Plain Panel up to it and fix with **60mm Screws (A0035)**.

GB-IE

03




NOTE
Some holes drilled for later use




Floor Panel (A5652)x01



LH Window Pent (A5653)x01





Plain Panel (A5641)x01



60mm Screws (A0035)x03




Inline with floor bearer



DO NOT
FIX WALLS TO
FLOOR
UNTIL ASKED

Drill the **RH Window Pent (A5654)** as below, making sure the holes are inline with the floor bearers. Fix with **60mm Screws (A0035)** using the pilot holes drilled in the previous step.


04




NOTE
Some holes drilled for later use




RH Window Pent (A5654)x01



60mm Screws (A0035)x03




Inline with floor bearer




Drill the **Double Door Panel (A5644)** as below. Make sure you don't drill through the doors. Place the panel onto the edge of the floor and fix with 3x **60mm Screws (A0035)**.

05





Double Door Panel (A5644)x01



60mm Screws (A0035)x03

NOTE
Some holes drilled for later use




DO NOT
FIX WALLS TO
FLOOR
UNTIL ASKED


GB-IE

Drill the **Window Panel (A5645)** as below. Make sure the holes are drilled at an angle as the drill will not fit in between the bars.
Fix the panel with 6x **60mm Screws (A0035)** using the holes drilled previously.



06




Window Panel (A5645)x01




60mm Screws (A0035)x06



DO NOT
FIX WALLS TO
FLOOR
UNTIL ASKED



NOTE
Some holes
drilled for
later use




Drill the **LH Roof Panel (A5655)** as below. Drill through the top as below, mark to make sure the holes are drilled so that the panel can be secured into the walls. Flip over and drill **two** holes along the edge that sits against the front Door and Window Panels. Then fix with **60mm Screws (A0035)**. On the inside, secure the panel to the front using the pilot holes drilled.






07



LH Roof Panel (A5655)x01




60mm Screws (A0035)x11




Drill the **RH Roof Panel (A5655)** as below. Turn over and drill **two** holes in the side that sits along the front Door and Window Panel. Drill **three** holes along the side that joins the two panels together. Fix with **60mm Screws (A0035)** as below. On the inside, screw the roof panels together using the pilot holes drilled in the previous step and secure to the front Window and Door panel.



08





RH Roof Panel (A5655)x01




60mm Screws (A0035)x14



Side that joins both panels →





Back




Drill the **Soffit (A5639)** as below. The second view shows which end the drills should be placed. Make sure the holes are drilled so that the screws go into the walls and that the Soffit is secured to the building. Fix with **60mm Screws (A0035)**.


09



Soffit (A5639)x01




60mm Screws (A0035)x08





GB-IE Make sure your building is square and true.
Fix the walls to the floor using the pilot holes drilled in the previous steps.

10




60mm Screws (A0035)x10




GB-IE Fix the **Coverstrips 12x46x1837 (A3986)** to the back of your building as below.
Fix the **Coverstrip 12x46x2086 (A5649)** to the front of your building as below.
Fix with 4x **40mm Nails (A0025)** in each.


11




Coverstrip 12x46x1837 (A3986)x02



Coverstrip 12x46x2086 (A5649)x01



40mm Nails (A0025)x12





A5649

3 Strips of **2.7M Felt (A2555)** have been supplied.

Fit the first and second piece of felt as shown below, making sure there is an even overhang front and back. Pull the Felt tight and secure with **13mm Felt Nails (A0023)** approximately 100mm apart.




12



2.7M Felt Strip (A2555)x03






13mm Felt Nails (A0023)x112




GB-IE

Fit the last piece of **Felt (A2555)** on the top of your building.
Fix the same as the others with **13mm Felt Nails (A0023)**.


13



2.7M Felt Strip (A2555)x01




13mm Felt Nails (A0023)x56




GB-IE

Fix the **Fascia 19x145x2480 (A4445)** to the front of the building.
Then fit the **Fascia 19x145x470 (A5650)** and **Fascia 19x145x1941 (A4446)** to the sides using **40mm Nails (A0025)**.


14




Fascia 19x145x2480 (A4445)x01




Fascia 19x145x470 (A5650)x02



Fascia 19x145x1941 (A4446)x02



40mm Nails (A0025)x16







Fit the **Acrylic 1534x547 (A1317)** as shown below. Whilst someone holds the acrylic, fit the **Beading 1538 (A0073)** with 6 pins, and the **Beading 550 (A0075)** with 3 pins in front. **WEAR THE CORRECT SAFETY EQUIPMENT**




15




Acrylic 1534x547 (A1317)x05




Beading 1538 (A0073)x10



Beading 550 (A0075)x10



16mm Panel Pins (A0024)x90



**DANGER OF CUTTING
HANDLE WITH CARE**