




ASSEMBLY INSTRUCTIONS

MONTELLO CANE DOOR SIDEBOARD

ITEM# 24500

ASSEMBLY REQUIREMENTS	1.5 Hours Assembly Time (Approximate)	2 -Person Assembly 	Tools Required (Not Provided): Phillips Screwdriver  ⊕ Flat Head Screwdriver  ⊖
-----------------------	---	---	---

Thank you for purchasing our product!

Please refer and use this assembly instruction to assemble the product.
Contact our customer service department in case there are any missing or damaged parts or hardware.
Replacement parts are normally shipped within 2 or 3 days.

Email: replacementparts@buylateral.com
Within 30 days from delivery date

We appreciate your business!

PRODUCTS PURCHASED THROUGH OUR AUTHORIZED VENDORS ONLY ARE ELIGIBLE FOR REPLACEMENT PARTS.

THIS PRODUCT IS FOR INDOOR AND HOUSEHOLD USE ONLY - NOT FOR COMMERCIAL USE.

ASSEMBLY PREPARATION

1. Remove all packaging materials, staples and packing straps from the carton.
2. Refer to Parts List and Hardware List and ensure they are correct before assembly.
Contact customer service for missing parts.
3. Place all wooden parts on a clean, flat and soft surface (e.g. carpet or rug) to prevent parts from getting scratched.

SAFETY PRECAUTION

1. KEEP ALL HARDWARE PARTS OUT OF REACH OF CHILDREN.
2. DISPOSE PLASTIC PACKAGING MATERIAL IMMEDIATELY TO AVOID ANY RISK OF SUFFOCATION TO CHILDREN AND ANIMALS.

TIPS FOR ASSEMBLY

1. Allow ample room for assembly and in close proximity to where product will be placed.
2. Assemble the product on a surface that does not scratch or damage the exterior gloss and finish of the furniture.
3. Identify all of the parts, hardware and quantities required for each step.
4. During assembly, do not over-tighten any fittings as this may cause damage.
5. DO NOT USE POWER TOOLS TO ASSEMBLE THIS PRODUCT.
6. Always place the product on a flat, level surface.
7. Do not sit or stand on the partially assembled product; only use the product for which it is intended.


CARE AND MAINTENANCE

1. Wipe clean with a soft, dry cloth; avoid the use of harsh chemicals or household cleaners as they may damage the exterior finish of the furniture.
2. Hardware may loosen over time. Periodically, check that all connections are tight; re-tighten as necessary.
3. Solid wood is impacted by heat and humidity fluctuations which may cause small joint separations or hairline cracks; place the furniture away from direct sunlight and air conditioning vents, heating vents or units to protect the furniture.
























ASSEMBLY INSTRUCTIONS

MONTELLO CANE DOOR SIDEBOARD

ITEM# 24500



Hardware List














ITEM	DESCRIPTION	PART	QTY	ITEM	DESCRIPTION	PART	QTY
A	Cam-bolt	 6*35mm	10 pcs	M	Bolt	 4*16mm	4 pcs
B	Cam-lock	 15*10mm	10 pcs	N	Knob		4 pcs
C	Wood Dowel	 8*30mm	16 pcs	O	Screw	 4*40mm	2 pcs
D	Screw	 3*14mm	20 pcs	P	Screw	 4*12mm	2 pcs
E	Magnetic Catch		2 pcs	Q	Plastic Anchor		2 pcs
F	Screw	 3*12mm	4 pcs	R	Bracket		2 pcs
G	Magnetic Bar		4 pcs	S	Allen Key	 6mm	1 pc
H	Bolt	 8*30mm	5 pcs	T	Allen Key	 8mm	1 pc
I	Screw	 7*40mm	6 pcs	U	Backply Stopper		16 pcs
J	Shelf Pin		8 pcs	V	Screw	 4*25mm	4 pcs
K	Screw	 4*14mm	48 pcs	W	Adjustable Leg Stud		5 pcs
L	Hinge		8 pcs				

ASSEMBLY INSTRUCTIONS

MONTELLO CANE DOOR SIDEBOARD

ITEM# 24500

Parts List


ITEM	DESCRIPTION	PART	QTY	ITEM	DESCRIPTION	PART	QTY
1	Top Panel		1 pc	8	Right Door		2 pcs
2	Connect Bar		2 pcs	9	Bottom Panel		1 pc
3	Left Panel		1 pc	10	Leg		5 pcs
4	Right Panel		1 pc	11	Side Back Panel		2 pcs
5	Divide Panel		1 pc	12	Middle Back Panel		2 pcs
6	Adjustable Shelf		2 pcs	13	H Connect Bar		2 pcs
7	Left Door		2 pcs				

ASSEMBLY INSTRUCTIONS


MONTELLO CANE DOOR SIDEBORD

ITEM# 24500

ASSEMBLY OVERVIEW



INSTRUCTIONS FOR CAM-BOLT AND CAM-LOCK




CAM-BOLT




CAM-LOCK


Tools Required




INSERTING AND TIGHTENING CAM-BOLT



Place Cam-bolt on pre-drilled hole and screw in vertically.




Shoulder is flushed (on the same level) with the panel.




Shoulder is above the panel.

Place Cam-bolt to the designated pre-drilled holes on the panel. Use a Phillips Screwdriver to tighten Cam-bolt vertically until shoulder is flushed (on the same level) with panel. Do not over-tighten or under-tighten.

INSERTING CAM-LOCK




Insert Cam-lock with arrow align to Cam-bolt head.




Align the arrow on the Cam-lock to the Cam-bolt head and insert the Cam-lock. Ensure Cam-lock is fully inserted.

TIGHTENING CAM-LOCK





Use a Flat-head Screwdriver to turn Cam-lock clockwise so it locks onto the head of the Cam-bolt. Turn until it is snug (about 3/4ths of a turn) -- over-tightening could damage Cam-lock or/and Cam-bolt.

STEP 1




A		10 pcs
D		4 pcs
E		2 pcs
P		2 pcs
R		2 pcs



- Lay Top Panel (1), Left Panel (3), Right Panel (4), Divide Panel (5) and Connect Bar (2) as shown on a material that does not scratch or damage the parts.
- Screw in Cam-bolt (A) into the designated holes on (1, 2, 3, 4 & 5 (both sides)). Refer to Page 5 for instructions on inserting and tightening Cam-bolt.
- Attach Bracket (R) to (1) with Screw (P) at the designated locations of (1). Check that each bracket can slide forward and backward.
- Attach Magnetic Catch (E) in the middle location of Connect Bar (2) with Screw (E).


STEP 2



H		5 pcs
T		1 pc
W		5 pcs


- Attach Leg (10) to Bottom Panel (9) and then fasten with screw in Bolt (H). Use Allen Key (T) to drive and tighten (H).
- Screw in Adjustable Leg Stud (W) to (10).

STEP 3




- Lay Left & Right Panel (3 & 4) from STEP 1 on a material that does not scratch or damage the parts and insert Wood Dowel (C) into the designated holes beside the cam-bolt on each part
- Attach Connect Bar (2) to Side Panel (3 & 4) via cam-bolts and wood dowel on the respective parts.
- Insert Cam-lock (B) into the designated holes on (2) then turn clockwise to lock onto the cam-bolts on (2). Refer to Page 5 for instructions on inserting and tightening Cam-lock.

STEP 4




- With assistance, position Right Panel (4) & Connect Bar (2) assembly from STEP 3 and Divide Panel (5) from STEP 1 as shown.
- Insert Wood Dowel (C) into the designated hole at the end edge of (2).
- Attach (5) to (2) via cam-bolts and wood dowel on the respective parts.
- Insert Cam-lock (B) into the designated holes on (2) then turn clockwise to lock onto the cam-bolt on (5).

STEP 5




- With assistance, position Left Panel (3) & Connect Bar (2) assembly from STEP 3 and Divide Panel (5) as shown.
- Insert Wood Dowel (C) into the designated hole at the end edge of Bottom Connect Bar (2).
- Attach (2) to via cam-bolts and wood dowel on the respective parts.
- Insert Cam-lock (B) into the designated hole on (2) and then turn clockwise to lock onto the cam-bolts on (2).

STEP 6




- Insert Wood Dowel (C) into the designated holes on the bottom edge of Side Panel (3 & 4) and Divide Panel (5).
- Attach Bottom Panel (9) from STEP 2 to (3, 4 & 5) via cam-bolts and wood dowel on the respective parts.
- Fasten (9) to (3, 4 & 5) with Screw (I). Tighten Screw (I) with Allen Key (S) completely.




STEP 7




- With assistance, set the assembly from STEP 6 right-side up as shown.
- Fit Back Panel (11 & 12) via groove on Side Panel (3 & 4), Divide Panel (5) and Bottom Panel (9).
- Fit H Connect Bar (13) between Back Panels (11 & 12) as shown.

STEP 8




B		6 pcs
C		6 pcs
V		4 pcs




- Insert Wood Dowel (C) to the inner two holes on the top edge of Side Panel (3 & 4) and Divide Panel (5).
- With assistance, attach Top Panel (1) from STEP 1 to (3, 4 & 5) via Cam-bolt and Wood Dowel on the respective parts.
- Insert Cam-lock (B) into the designated holes on (3, 4 & 5) and then turn clockwise to lock onto cam-bolt.
- Fasten Connect Bar (2) to (1) with Screw (V).

STEP 9




Wedge Backply Stopper (U) at each corner against Back Panel (11 & 12) and into the respective groove on Top Panel, Side Panel, Divide Panel and Bottom Panel. Next, fasten (U) using Screw (D).


STEP 10



- Drill two holes in the wall per the length and diameter of Plastic Anchor (Q) and the height needs to be the same as the hole on Bracket (R) .
- Press (Q) into the drilled hole. Ensure that the anchor fits securely in the wall.
- Drive Screw (O) through the screw hole on adjustable Bracket (R) into the screw hole on (Q) to secure the unit to the wall.





STEP 11


J		8 pcs
---	--	-------



- Insert Shelf Pin (J) into the designated holes on the same level at the desired height on Panel (3, 4 & 5).
- Place Shelf (6) by tilting it to fit between the respective panels and then level it to sit on (J).


STEP 12



F	 3*12mm	4 pcs
G		4 pcs
K	 4x14mm	16 pcs
L		8 pcs




- Fit Door Wing of Hinge (L) to the hinge well on Door (7 & 8).
- Align screw holes on Door Wing of (L) to the pilot holes on (7 & 8) and fasten with Screw (K). Do not tighten (K) completely until both screws are in place on each Door Wing of the Hinge.
- Attach Magnetic Bar (G) to (7 & 8) with Screw (F).

STEP 13







K	 4x14mm	8 pcs
M		2 pcs
N		2 pcs




- With assistance position Door (7 & 8) as shown and align the screw holes on Panel Wing of Hinge (L) to pilot holes on Left and Divide Panel (3 & 5).
- Use a Phillips screwdriver to drive Screw (K) to fasten Panel Wing of Hinge to (3 & 5). Do not tighten (K) completely until both screws are in place.
- Attach Knob (N) to Door (7 & 8) with Bolt (M).

STEP 14



K	 4x14mm	8 pcs
M		2 pcs
N		2 pcs




Turn Adjustable Leg Stud clockwise or anti-clockwise to level the sideboard as needed.

- With assistance position the next set of Door (7 & 8) as shown and align the screw holes on Panel Wing of Hinge (L) to pilot holes on Right and Divide Panel (4 & 5).
- Use a Phillips screwdriver to drive Screw (K) to fasten Panel Wing of Hinge to (4 & 5). Do not tighten (K) completely until both screws are in place.
- Attach Knob (N) to Door (7 & 8) with Bolt (M).
- Adjust Leg Stud as needed.


The assembly of the sideboard is complete.

DOOR ADJUSTMENT


Use the procedures below to adjust the doors as needed:




If the top of the door is not level with the side panel, loosen the screw at the back of the hinge as shown, then move the hinge in or out until the desired gap is achieved, and then re-tighten the back screw.




If the top of the door is not level with the side panel, loosen the screw at the back of the hinge as shown, then move the hinge in or out until the desired gap is achieved, and then re-tighten the back screw as shown.



If the gap is too tight between the two doors, loosen the screw at the front of the hinge as shown to make the adjustment and then re-tighten the screw.



If the gap is too tight between the two doors, loosen the screw at the front of the hinge as shown to make the adjustment and then re-tighten the screw.



a) If the doors are not leveled with each other, loosen the screws (installed on STEP 13 STEP 14) at the Panel Wing of the hinge, then adjust the hinge up or down until the desired level or when both doors are leveled, and then re-tighten the screws.

b) When all the desired positions are in place, use the remaining Screw (K) to fasten the Wing Panel using the front two screw holes on Panel Wing.

The assembly of the Sideboard is complete.