


# ASSEMBLY INSTRUCTION

## STORAGE BENCH




# ASSEMBLY INSTRUCTION

Please read these instructions fully before starting assembly :

Tools required : Phillips screwdriver (medium)











1. Check you have all the components and tools listed on the following pages.
2. Remove all fittings from the plastic bags and separate them into their groups.
3. Keep children and animals away from the work area, small parts could choke if swallowed.
4. Make sure you have enough space to layout the parts before starting.
5. During assembly do not stand or put weight on the product, this could cause damage.
6. Assemble the item as close to its final position (in the same room) as possible.
7. Assemble on a soft level surface to avoid damaging the unit or your floor.
8. Parts of the assembly will be easier with 2 people.
9. To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.
10. Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
11. Regularly check and ensure That all bolts and fittings are tightend properly.
12. Please do not place items that exceed the load capacity. Care and maintenance :  
Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

# ASSEMBLY INSTRUCTION








# ASSEMBLY INSTRUCTION I

## Part List

<div data-bbox="146 323 214 380">A</div> <div data-bbox="256 394 477 525"></div> <div data-bbox="293 596 440 625">TOP – 1 PC</div>	<div data-bbox="589 323 657 380">B</div> <div data-bbox="748 378 862 569"></div> <div data-bbox="662 596 966 625">SIDE FRAME (R) – 1 PC</div>	<div data-bbox="1032 323 1101 380">C</div> <div data-bbox="1192 382 1312 581"></div> <div data-bbox="1130 596 1433 625">SIDE FRAME (L) – 1 PC</div>
<div data-bbox="146 646 214 703">D</div> <div data-bbox="232 707 480 869"></div> <div data-bbox="222 959 514 989">APRON (BACK) – 1 PC</div>	<div data-bbox="589 646 657 703">E</div> <div data-bbox="686 707 933 869"></div> <div data-bbox="693 959 1002 989">APRON (FRONT) – 1 PC</div>	<div data-bbox="1032 646 1101 703">F</div> <div data-bbox="1192 688 1318 873"></div> <div data-bbox="1096 959 1421 989">VERTICAL PANEL – 1 PC</div>
<div data-bbox="146 999 214 1056">G</div> <div data-bbox="224 1060 506 1232"></div> <div data-bbox="246 1314 555 1344">BOTTOM PANEL – 1 PC</div>	<div data-bbox="589 999 657 1056">H</div> <div data-bbox="680 1071 951 1232"></div> <div data-bbox="662 1314 966 1344">CENTER PANEL – 1 PC</div>	<div data-bbox="1032 999 1101 1056">I</div> <div data-bbox="1127 1094 1382 1241"></div> <div data-bbox="1135 1314 1382 1344">TOP PANEL – 1 PC</div>
<div data-bbox="146 1354 214 1411">J</div> <div data-bbox="219 1423 495 1596"></div> <div data-bbox="246 1667 488 1696">MATTRESS – 1 PC</div>		


# ASSEMBLY INSTRUCTION

## Hardware List


1		2		3	
M6 x 35mm BOLT (2 PCS)		M6 x 60mm BOLT (8 PCS)		6 X 13MM BARREL NUT (8 PCS)	
4		5			
M4 X 30MM X 110MM ALLEN KEY (1 PC)		M3.5 X 15MM SHORT SCREW (6 PCS)			

## ASSEMBLY INSTRUCTION

STEP 1:





STEP 2:





# ASSEMBLY INSTRUCTION

STEP 3:





STEP 4:



# ASSEMBLY INSTRUCTION

STEP 5:



STEP 6 :

