

## ASSEMBLY INSTRUCTIONS

# EEI-7168

VO.08.26.24



**Questions? Contact us!**

609.256.9000 • [cs@modway.com](mailto:cs@modway.com)  
[www.modway.com](http://www.modway.com)

**\*modway**

# Let's get started!

\*modway



Read through all of the instructions before starting



Care instructions are listed in the last step of this manual



Approx. 90 minutes assembly time



Make sure you have all parts and components before discarding any packing materials



2 people recommended for assembly

**Only use hand tools to assemble this item.** Do not use power tools. Do not tighten bolts or screws completely until all hardware is lined up and inserted into the holes.


Do not over-tighten screws and bolts to avoid stripping the hardware or cracking the item.

Assemble your item on a flat, carpeted area, with plenty of space to work. This will prevent damage and scratches to your floors or the item while you're assembling the product.


Keep all components and packaging out of reach of children or animals to avoid risk of choking or suffocation.

## Furniture components:

1	Top Board	x1	16	Door Right	x1
2	Bottom Board	x1	17	Side Board Drawer 1	x1
3	Side Board Left	x1	18	Side Board Drawer 2	x1
4	Side Board Right	x1	19	Side Board Drawer 3	x1
5	Front Board Hutch	x1	20	Side Board Drawer 4	x1
6	Support Board Hutch	x3	21	Front Drawer	x2
7	Back Board Hutch	x1	22	Side Drawer Left	x2
8	PVC Board	x1	23	Side Drawer Right	x2
9	Bottom Skirt 1	x1	24	Back Drawer	x2
10	Bottom Skirt 2	x1	25	Bottom Drawer	x2
11	Bottom Skirt 3	x2	26	Support Drawer	x2
12	Leg	x4	27	Adjustable Shelf	x2
13	Front Skirt 1	x1	28	Fixed Shelf	x1
14	Front Skirt 2	x1	29	Support Board 1	x2
15	Door Left	x1	30	Support Board 2	x2



































x 2



Wait!

Missing parts or hardware? Need assistance?  
Contact us before returning your item. We're here to help!  
609.256.9000 • cs@modway.com

## Provided hardware:

A		Cam Bolt Ø6 x 35 mm	x46	L		Allen Key	x2	W		Flange Nut	x4
B		Cam Lock Ø15 mm	x36	M		Wedge	x30	X		Wrench	x1
C		Wood Dowel Ø8 x 30 mm	x51	N		Screw M 3.5 x 15.5 mm	x30	Y		Screw M 8 x 39 mm	x15
D		Screw M 6.4 x 14 mm	x3	O		Screw M 7 x 50 mm	x6	Z		Screw M 6 x 10.5 mm	x8
E		Joining Strip	x1	P		Wood Dowel Ø6 x 30 mm	x4	AA		Screw M 3.5 x 13 mm	x12
F		Cam Bolt Ø6 x 19.5 mm	x8	Q		Plate	x3	AB		Silicon Bumper	x4
G		Screw Cap Ø15 mm	x12	R		Screw M 6.4 x 53 mm	x7	RM30A		Drawer Runner	x2
H		Screw M 4.5 x 12.5 mm	x75	S		Cam Lock Ø12 mm	x10	HS26C		Hinge	x6
I		Handle	x2	T		Floor Protector	x4	BC410		Corner Brace	x4
J		Screw M 4 x 22 mm	x2	U		Support Hinge	x6	What you need:			 Phillips      Phillips Head Screwdriver
K		Screw M 6.4 x 25 mm	x6	V		Handle	x4				

## Components Carton Placement

### Carton 1 of 2

Label	Description	Qty
1	Top Board	x1
2	Bottom Board	x1
5	Front Board Hutch	x1
6	Support Board Hutch	x3
7	Back Board Hutch	x1
9	Bottom Skirt 1	x1
10	Bottom Skirt 2	x1
11	Bottom Skirt 3	x2
12	Leg	x4
22	Side Drawer Left	x2
23	Side Drawer Right	x2
24	Back Drawer	x2
27	Adjustable Shelf	x2
28	Fixed Shelf	x1

### Carton 2 of 2

Label	Description	Qty
3	Side Board Left	x1
4	Side Board Right	x1
8	PVC Board	x1
13	Front Skirt 1	x1
14	Front Skirt 2	x1
15	Door Left	x1
16	Door Right	x1
17	Side Board Drawer 1	x1
18	Side Board Drawer 2	x1
19	Side Board Drawer 3	x1
20	Side Board Drawer 4	x1
21	Front Drawer	x2
25	Bottom Drawer	x2
26	Support Drawer	x2

Wait!

Missing parts or hardware? Need assistance?  
Contact us before returning your item. We're here to help!  
609.256.9000 • cs@modway.com


## Step 1

### HARDWARE

- A** Cam Bolt Ø6 x 35 mm x10
- P** Wood Dowel Ø6 x 30 mm x4

### COMPONENTS

- 21** Front Drawer x2
- 22** Side Drawer Left x2
- 23** Side Drawer Right x2




## Step 2

### HARDWARE

- S** Cam Lock Ø12 mm x10
- Y** Screw M 8 x 39 mm x12

### COMPONENTS



- 21** Front Drawer x2
- 22** Side Drawer Left x2
- 23** Side Drawer Right x2
- 24** Back Drawer x2
- 25** Bottom Drawer x2
- 26** Support Drawer x2



## Step 3

### HARDWARE





AA	Screw M 3.5 x 13 mm	x12
RM30A	Drawer Runner	x2



## Step 4

### HARDWARE

M	Wedge	x8
N	Screw M 3.5 x 15.5 mm	x8
V	Handle	x4





## Step 5

### HARDWARE

- C** Wood Dowel Ø8 x 30 mm x16
- F** Cam Bolt Ø6 x 19.5 mm x8

### COMPONENTS

- 3** Side Board Left x1
- 4** Side Board Right x1





## Step 6

### HARDWARE

- A** Cam Bolt Ø6 x 35 mm x4

### COMPONENTS

- 3** Side Board Left x1
- 4** Side Board Right x1




## Step 7

### HARDWARE

<b>H</b>	Screw M 4.5 x 12.5 mm	x12
<b>K</b>	Screw M 6.4 x 25 mm	x6
<b>L</b>	Allen Key	x1
<b>U</b>	Support Hinge	x6

### COMPONENTS

<b>3</b>	Side Board Left	x1
<b>4</b>	Side Board Right	x1





## Step 8

### HARDWARE

<b>A</b>	Cam Bolt Ø6 x 35 mm	x12
<b>C</b>	Wood Dowel Ø8 x 30 mm	x4

### COMPONENTS

<b>13</b>	Front Skirt 1	x1
<b>14</b>	Front Skirt 2	x1
<b>28</b>	Fixed Shelf	x1




## Step 9

### HARDWARE

- B** Cam Lock Ø15 mm x4

### COMPONENTS

- 3** Side Board Left x1  
**4** Side Board Right x1  
**28** Fixed Shelf x1




## Step 10

### HARDWARE

- A** Cam Bolt Ø6 x 35 mm x8  
**C** Wood Dowel Ø8 x 30 mm x20

### COMPONENTS



- 17** Side Board Drawer 1 x1  
**18** Side Board Drawer 2 x1  
**19** Side Board Drawer 3 x1  
**20** Side Board Drawer 4 x1  
**29** Support Board 1 x2  
**30** Support Board 2 x2



## Step 11

### COMPONENTS


17	Side Board Drawer 1	x1
18	Side Board Drawer 2	x1
19	Side Board Drawer 3	x1
20	Side Board Drawer 4	x1
29	Support Board 1	x2
30	Support Board 2	x2



## Step 12

### HARDWARE

B	Cam Lock Ø15 mm	x8
---	-----------------	----




## Step 13

### HARDWARE

**Z** Screw M 6 x 10.5 mm x8


**RM30A** Drawer Runner x2



## Step 14

### HARDWARE

**B** Cam Lock Ø15 mm x4





## Step 15

### HARDWARE

- |          |                   |    |
|----------|-------------------|----|
| <b>L</b> | Allen Key         | x1 |
| <b>O</b> | Screw M 7 x 50 mm | x6 |

### COMPONENTS

- |           |              |    |
|-----------|--------------|----|
| <b>2</b>  | Bottom Board | x1 |
| <b>32</b> | Back Board 2 | x1 |





## Step 16

### HARDWARE

- |          |                 |    |
|----------|-----------------|----|
| <b>B</b> | Cam Lock Ø15 mm | x8 |
|----------|-----------------|----|

### COMPONENTS

- |           |               |    |
|-----------|---------------|----|
| <b>13</b> | Front Skirt 1 | x1 |
| <b>14</b> | Front Skirt 2 | x1 |



## Step 17


### HARDWARE

**H** Screw M 4.5 x 12.5 mm x12

**BC410** Corner Brace x4

### COMPONENTS

**11** Bottom Skirt 3 x2



## Step 18

### HARDWARE


**D** Screw M 6.4 x 14 mm x3

**L** Allen Key x1

**Q** Plate x3

### COMPONENTS

**9** Bottom Skirt 1 x1



## Step 19




### HARDWARE

**H** Screw M 4.5 x 12.5 mm x6

### COMPONENTS

**10** Bottom Skirt 2 x1

**11** Bottom Skirt 3 x2



Only this screw is tightened





## Step 20

### HARDWARE

**H** Screw M 4.5 x 12.5 mm x6

### COMPONENTS

**9** Bottom Skirt 1 x1




Only this screw is tightened

## Step 21

### HARDWARE


- C** Wood Dowel Ø8 x 30 mm x6



## Step 22

### HARDWARE

- L** Allen Key x1  
**R** Screw M 6.4 x 53 mm x7






## Step 23

### HARDWARE

- W** Flange Nut x4
- X** Wrench x1

### COMPONENTS



- 12** Leg x4



## Step 24

### HARDWARE

- H** Screw M 4.5 x 12.5 mm x3
- T** Floor Protector x4





## Step 25

### HARDWARE


**E** Joining Strip x1

### COMPONENTS



**31** Back Board 1 x2



Step 1



Step 2



## Step 26

### HARDWARE

**A** Cam Bolt Ø6 x 35 mm x8

**C** Wood Dowel Ø8 x 30 mm x5





### COMPONENTS

**1** Top Board x1


**5** Front Board Hutch x1

**6** Support Board Hutch x3

**7** Back Board Hutch x1



x 3



## Step 27



### HARDWARE

**B** Cam Lock Ø15 mm x3

### COMPONENTS

**5** Front Board Hutch x1

**6** Support Board Hutch x3





## Step 28

### HARDWARE

**Y** Screw M 8 x 39 mm x3

### COMPONENTS


**7** Back Board Hutch x1



## Step 29

### COMPONENTS

**8** PVC Board x1




## Step 30

### HARDWARE

**B** Cam Lock Ø15 mm x5

### COMPONENTS


**1** Top Board x1



## Step 31

### HARDWARE

- A** Cam Bolt Ø6 x 35 mm x4




## Step 32



### HARDWARE

- B** Cam Lock Ø15 mm x4

- G** Screw Cap Ø15 mm x4




## Step 33



## Step 34

### COMPONENTS

**27** Adjustable Shelf x2




## Step 35

### HARDWARE

<b>H</b>	Screw M 4.5 x 12.5 mm	x12
<b>HS26C</b>	Hinge	x6

### COMPONENTS

<b>15</b>	Door Left	x1
<b>16</b>	Door Right	x1








## Step 36

### HARDWARE

<b>H</b>	Screw M 4.5 x 12.5 mm	x24
<b>I</b>	Handle	x2
<b>J</b>	Screw M 4 x 22 mm	x2
<b>G</b>	Screw Cap Ø15 mm	x8
<b>AB</b>	Silicon Bumper	x4

### COMPONENTS


<b>15</b>	Door Left	x1
<b>16</b>	Door Right	x1



## Step 37

### HARDWARE

- |          |                       |     |
|----------|-----------------------|-----|
| <b>M</b> | Wedge                 | x22 |
| <b>N</b> | Screw M 3.5 x 15.5 mm | x22 |



## Step 38



# Great job!

Bookcase assembly is complete.

## ♥ CARING FOR YOUR ITEM

Indoor use only.

Not contract grade.

Clean using a non-abrasive cloth and a mild cleaner.



Never use harsh chemicals, as they could damage the finish or integrity of the item.



## CONNECT WITH US!


Tag us @modway\_furniture and #modway for a chance to be featured.

# Cabinet Door Alignment




## To adjust the vertical height.

Loosen the four screws "A" on both hinges. Two of them are usually in slotted holes which allows you to adjust up or down by few mm. Then tighten back up.



## To adjust depth.

Loosen screw "B" and adjust door, if the door can not be adjusted, please loosen screw "C", then try again. Tighten screw "B" and "C".



## To adjust side ways.



Turn screw "C" on BOTH hinges on each door.

## TIPPING RESTRAINTS KIT INSTALLATION GUIDANCE

Different wall materials require unique wall fasteners.

The wall plugs (AA2) and screws (AA3) are designed for fixing to concrete walls only.

Please consult your local hardware store to ensure you are using the correct hardware for you wall type.



### Installation Instructions :

1. Attach bracket (AA1) securely to the back top of the furniture using screw (AA4) provided. Allow 8 - 10 cm from each side.
2. Please make a hole for wall plugs position on the wall and minimum 15 mm below bracket secured to the back of unit. Attach the wall plugs (AA2).
3. Install the other bracket (AA1) on the wall over wall plugs (AA2), secure with screw (AA3). Place furniture into position so both brackets (AA1) are aligned.
4. Lace the end of the restrains strap through the larger hole in each bracket. Ensure the restrains strap with grids surface facing the inner loops. Bring both ends together and slide the flat end through the locking end and draw it through until all slack is removed.
5. Make sure that the strap is securely laced & locked.