

Artificial Plant Wall



We continue to be committed to provide you tools with competitive price. "Save Half", "Half Price" or any other similar expressions used by us only represents an estimate of savings you might benefit from buying certain tools with us compared to the major top brands and does not necessarily mean to cover all categories of tools offered by us. You are kindly reminded to verify carefully when you are placing an order with us if you are actually Saving Half in comparison with the top major brands.

NEED HELP? CONTACT US!

Have product questions? Need technical support? Please feel free to contact us.

This is the original instruction, please read all manual instructions carefully before operating. We reserve a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

1. Technical Parameters

	Product size after splicing(inch)	Product Weight(kg)
	20*20	8.8
	15*15	1.74
	40*120	6.8
	60*120	10.4
	15*15	3.6
	20*20	6.4

2. Safety Precautions

WARNING:

Read this material before using this product. Failure to do so can result in serious injury. **SAVE THIS MANUAL**

Assembly Precautions

1. Assemble only according to these instructions. Improper assembly can create hazards.
2. Wear ANSI-approved safety goggles and heavy-duty work gloves during assembly.
3. Keep the assembly area clean and well-lit.
4. Keep bystanders out of the area during assembly.
5. Do not assemble when tired or under the influence of alcohol, drugs or medication.
6. Product capabilities apply to correctly and completely assembled products only.

Use Precautions


1. Do not sit or stand on this item .
2. This product is not a toy. Therefore, do not allow children to play with this item .
3. Use as intended only.

3. Instructions for Use

Assembly(No tools required)

After receiving the sample, arrange the flowers and leaves of the product first


- 1.Observe the direction of the foliage
-Boxwood & Fem : Multi-directional
-ivy &Lavender. Follow the direction of the foliage.
2. Connect panels using the easy snap-to-lock system.
3. For simple and quick installation, from strips 2 panels wide by the desired height.



Chain Link, Wire Mesh & Wrought Iron

Tools: Green zip ties(Not Included)


1. Fasten the first panel or connected set or panels directly to the support.
2. Repeat progressing laterally (clip panel sections together before fastening to the support for a perfect fit.)



Drywall and Wood

Tools: 1/2in.*1/2in. Crown 20 Gauge Staples & Stapler (Not Included)


1. Fasten the first panel or connected panels directly to the top of the wall or service. Use additional staples on the top panel in each column hung.
2. Place 2 Staples on the edges of each panel, making your way down to the bottom panel.
3. Repeat progressing laterally (clip panel sections together before fastening to the support for a perfect fit.)



Concrete, Brick or Block

Tools: 3/16 in.*13/4 in. Washer Head Concrete Screw Anchors, Drill Bit & Drill (Not Included)

1. Hold a single panel in place at the top of the wall or surface. Then, using your drill and drill bit, drill one hole in the top left & suitable square holes found on the backing grid of the panel. Drill each hole approximately 1/4 inch deeper than the anchor screw being used.
2. Screw a washer head concrete anchor in each hole, securing the panel to the surface.
3. Repeat processing downward til a single column is complete ensuring the panels are securely fastened as you progress.
4. Repeat steps 1-3 until your installation is complete.



Metal/Aluminum

Tools: 3/4 in. Truss Head Self-Tapping Screws & Drill (Not Included)

1. Hold a single panel in place at the top of the wall or surface. Using your drill and 3/4 in self-tapping screws, place a screw in the top left & suitable square holes found on the backing grid of the panel.
2. Repeat processing downward til a single column is complete ensuring the panels are securely fastened as you progress.
3. Repeat steps 1 & 2 till your installation is complete.

