























Assembly Instructions

V01.240728.01




Hardware Part List

A		M6x35mm	x83+3	<input type="checkbox"/>	Q			x2	<input type="checkbox"/>
B		M15x10mm	x83+3	<input type="checkbox"/>	R		M4x9mm	x18+1	<input type="checkbox"/>
C		M6x30mm	x26+2	<input type="checkbox"/>	S		M7x50mm	x8	<input type="checkbox"/>
D			x18	<input type="checkbox"/>	T			x1	<input type="checkbox"/>
E		M3x12mm	x72+3	<input type="checkbox"/>	U			x2	<input type="checkbox"/>
F		M6x10mm	x12+1	<input type="checkbox"/>					
G		M6x20mm	x12+1	<input type="checkbox"/>					
H			x2	<input type="checkbox"/>					
I			x4	<input type="checkbox"/>					
J		M4x35mm	x12	<input type="checkbox"/>					
K		M4x12mm	x10+1	<input type="checkbox"/>					
L			x2	<input type="checkbox"/>					
M		M4x30mm	x45+3	<input type="checkbox"/>					
N			x9	<input type="checkbox"/>					
O			x14	<input type="checkbox"/>					
P		M3x16mm	x14+1	<input type="checkbox"/>					

Components Part List


1



x4




9



x1




2



x1




10



x6




3



x1




11



x1




4



x1




12



x2




5



x1




13



x2



6



x2




14



x2




7



x2




15



x1




8



x2



16




x1



Components Part List


17



x3




18



x3




19



x3




20



x9




21



x9




22



x9




23



x9



24




x9



Components Part List - Box 1


1



x4




12



x2




2



x1




13



x2




3



x1




14



x2




6



x2




15



x1




8



x2




16



x1




9



x1




17



x3




10



x6




18



x3




11



x1



19




x3




Components Part List - Box 1

22



x9

23




x9

Hardware Package

x1

Components Part List - Box 2


4



x1




5



x1




7



x2




20



x9




21



x9




24





x9





Disassemble diagram:




Disassemble diagram:



Step 1 / 34



6



x2







A



x4


Note:

Step 2 / 34




Note:

Step 3 / 34



10



x6

F



x12





G



x12

Note:




Step 4 / 34



Note:

To locate correct holes, slide(D) needed to be moved in 2 directions.





Step 5 / 34



Note:





To locate correct holes, slide(D) needed to be moved in 2 directions.

Step 6 / 34








Note:

Step 7 / 34



180°





Note:

Both sides of part 7 needed to be installed.

To locate correct holes, slide (D) needed to be moved in 2 directions.

Step 8 / 34






A  x8

Note:



Both sides of part 7 needed to be installed.

Step 9 / 34



Note:


Step 10 / 34




B  x2

Note:

Step 11 / 34



11



x1



J




x2

Note:

Step 12 / 34



8 x1





B x2



Note:


Step 13 / 34




B  x4

Note:

Step 14 / 34



8



x1



B



x2

Note:


Step 15 / 34



B  x4

Note:

Step 16 / 34




16




x1

Note:

Step 17 / 34



3




x1

K



x8


U




x2

Note:

Step 18 / 34





14  x2

H  x2

Note:


Step 19 / 34



A  x10

Note:

Step 20 / 34




1




x4

S



x8


T



x1

Note:




Step 21 / 34



- C  x8
- J  x8


Note:
Two persons required.


Step 22 / 34



Note:


Step 23 / 34



1  x4

Note:

Step 24 / 34





15



x1

Note:


Step 25 / 34





Note:

FIX THE ANTI-TIPPING ACCESSORES L IN THE RESERVED HOLE OF THE PRODUCT

Step 26 / 34





B  x8 C  x8

Note:


Two persons required.

Step 27 / 34




Note:


Step 28 / 34








x3



x3




x3



Note:


Step 29 / 34




B  x45

Note:


Step 30 / 34





x3



x3






x3

E  x18 N  x9

Note:


Step 31 / 34



O  x14 P  x14

Note:

Step 32 / 34



J



x2

Q





x2

Note:


Tip: We provide anti tipping accessories for those in need. If you need them, please install them according to the instructions. If not needed, your product installation has been completed, please feel free to use it.

1. Put the cabinet against the wall and mark the hole locked against the wall with a marker and then drill holes at the marked locations.

1




2. Place anchors (Q) into the hole.




2

3. Push the shelf close to the wall, align it with the holes, and then tighten it with screws (J).

3




Step 33 / 34




Note:


You may need patience to get a perfect smooth slide of drawer experience, and we appreciate your patience. Asking for a second person to assist you will simplify the process.




1.Align Components: Position the groove on the drawer side to match the rail profile. Insert a precision tool (e.g., screwdriver tip) into the outermost hole of the slide rail. Ensure both sides are aligned symmetrically.



2.Slide Drawer Inward: Gently push the drawer into the cabinet until slide come up against drawer front. This step needs to be done simultaneously for both sides.




3.Secure & Adjust: While maintaining pressure on the tool, slowly pull the drawer outward until slide can not be moved.



4.Finalize Installation: Locate the pre-drilled mounting holes where the rails meet the drawer sides. Securely tighten all screws on both sides.

Step 34 / 34



R  x18

Note:

Screw R needed to be installed from inside of the drawer to outside.