


















PARTS LIST




NO	QTY	DESCRIPTION
1	1PC	TOP BOARD
2	1PC	LEFT SIDE PANEL
3	1PC	RIGHT SIDE PANEL
4	1PC	SHELF
5	1PC	SHELF
6	1PC	WOOD ROD
7	1PC	LEFT DOOR
8	1PC	RIGHT DOOR
9	1PC	REAR CROSS BAR
10	2PCS	BACK BOARD

NO	PARTS	QTY	DESCRIPTION
A		8PCS	CAM BOLT
B		8PCS	CAM LOCK
C		4PCS	WOOD DOWEL
D		1PC	MAGNET
E		2PCS	SCREW
F		4PCS	PIN
G		2PCS	KNOB
H		2PCS	SCREW
I		4PCS	SCREW
J		2PCS	MAGNET PLATE
K		2PCS	SCREW
L		18PCS	BACK BOARD SCREW
M		2PCS	SCREW
N		2PCS	PLASTIC ANCHOR
O		1PC	PLASTIC CONNECTION STRIP

**TOOLS NEEDED FOR ASSEMBLY: FLAT & PHILIPS SCREWDRIVER (NOT INCLUDED)
THE USE OF POWER SCREWDRIVER IS NOT RECOMMENDED**


STEP 1



STEP 1

1. Lock Magnet D to Board 1 with Screw E.
2. Lock Bolt A to Panel 2 and plug into Wood Dowel C at the same time.
3. Lock Bolt A to Panel 2 and plug into Wood Dowel C at the same time.


STEP 2



STEP 2

1. Install Pin F into Door 7 and Door 8.
2. Lock Plate J to Door 7 and Door 8 with Screw K.
3. Lock Screw H to Knob G through Door 7 and Door 8.


STEP 3



STEP 3

1. Assemble Panel 2, Panel 3, Shelf 4, Shelf 5, Wood Rod 6 and Bar 9 together, and lock Shelf 4 and Shelf 5 with Cam Lock B.


STEP 4



STEP 4

1. Door 7 connects with Shelf 4 and Board 1.
2. Door 8 connects with Shelf 4 and Board 1.
3. Lock Screw I with Panel 2 and Panel 3 through Board 1.


STEP 5



STEP 5

1. Connect two pieces Board 10 with Strip O, and lock with Screw L at the same time.

STEP 6



STEP 6

1. Punch two holes on the wall, then knock the Plastic Anchor N into the holes (the distance of two holes is equal to the two holes on the product).
2. Lock the product to the wall with Screw M.