


# TV Stand

Assembly Instructions -Please keep for future reference



## Dimensions



























Width-94 inch  
Depth-16 inch  
Height-79 inch

Important -Please read these instructions fully before starting assembly



# Components -Fittings

Please check you have all the panels listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

 Cam Bolt x 142 +2	 Lock x 148 +2	 Dowel x 78 +2	 7*50mm Screw x 22 +1
 3.5*14mm Screw x 24 +1	 Plastic buckle x 32 +1	 3*12mm Screw x 32 +1	 Sticker Cover x 65 +2
 Handle x 6	 4*20mm Screw x 6	 Movable partition bracket x 8	 Anti-tipping device x 4
 Plastic expansion tube x 4	 4*50mm Screw x 4	 Felt pad x 14	 Plastic hinge x 12
 Nut x 6	 Screw arbor x 6	 Magnet x 4	 Sheet iron x 2
 6x35 Screw x 8	 3*14mm Screw x 42 +1	 Clamping nut x 6	 6x20 Screw x 6
 L sheet iron x 1	 Sheet iron x 4		

## Tools required



Phillips screwdriver  
(medium & large)

# Safety and Care Advice

**Important – Please read these instructions fully before starting assembly**

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



- To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

## Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

## Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure That all bolts and fittings are tightened properly.

## **WARNING** In order to help prevent overturning – please follow these instructions

To help prevent product toppling over please follow the below steps:-

- Use the anti tip stap or wall fixing method provided (if applicable)
- Do not allow children to climb or hang on the furniture
- Do not open more than one drawer at a time
- Do not place heavy items in the top drawers
- Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose


# Using Camlocks

## Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.

1


DO NOT OVER TIGHTEN.  
NE PAS SERRER EXCESSIVEMENT.



## Step 2

Push the male camlock into the entry hole.

2




## Step 3

Insert the female camlock as shown in the instruction.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.

3




## Step 4

Turn the female camlock clockwise with a screwdriver.


You should feel a click when the camlock is locked in place.

The joint is now secure.
























4























# Assembly Instructions



# There are 2 boxes of this product.


① 1200*254*24mm  1PC	② 1200*254*24mm  1PC	③ 1396*219*15mm  1PC	④ 1396*219*15mm  1PC
⑤ 1396*219*15mm  1PC	⑥ 1396*219*15mm  1PC	⑦ 201*218*15mm  1PC	⑨ 229*197*15mm  2PCS
⑫ 1396*45*15mm  1PC	⑬ 1336*45*15mm  2PCS	⑭ 1396*45*15mm  1PC	⑮ 1125*80*15mm  1PC
⑰ 1125*80*15mm  1PC	⑱ 1171*405*25mm  1PC	⑲ 1171*405*25mm  1PC	⑳ 1171*45*15mm  1PC
㉑ 1171*45*15mm  1PC	㉒ 1139*100*15mm  2PCS	㉓ 1396*50*15mm  1PC	㉔ 1234*280*5mm  1PC
㉕ 1244*237*3mm  2PCS	㉖ 1147.5*419*3mm  2PCS	㉗ 201*218*15mm  1PC	

# There are 2 boxes of this product.


<p>⑧ 229*203*15mm</p>  <p>6PCS</p>	<p>⑩ 910*219*15mm</p>  <p>1PC</p>	<p>⑪ 910*219*15mm</p>  <p>1PC</p>	<p>⑲ 555*384*15mm</p>  <p>1PC</p>
<p>⑳ 555*384*15mm</p>  <p>1PC</p>	<p>㉑ 555*384*15mm</p>  <p>1PC</p>	<p>㉒ 555*384*15mm</p>  <p>1PC</p>	<p>㉓ 511*362*15mm</p>  <p>1PC</p>
<p>㉔ 511*362*15mm</p>  <p>1PC</p>	<p>㉕ 725*352*12mm</p>  <p>2PCS</p>	<p>㉖ 1139.5*384*15mm</p>  <p>1PC</p>	<p>㉗ 1139.5*384*15mm</p>  <p>1PC</p>
<p>⑳ 510*45*15mm</p>  <p>2PCS</p>	<p>㉑ 510*45*15mm</p>  <p>2PCS</p>	<p>㉒ 510*45*15mm</p>  <p>1PC</p>	<p>㉓ 229*80*15mm</p>  <p>4PCS</p>
<p>㉔ 424*50*15mm</p>  <p>1PC</p>	<p>㉕ 616*280*5mm</p>  <p>1PC</p>	<p>㉖ 507*349*15mm</p>  <p>2PCS</p>	<p>㉗ 507*349*15mm</p>  <p>4PCS</p>

# Assembly Instructions

## Step 1



(A)




Cam Bolt x 18

(C)



Dowel x 1

## Step 2



(A)



Cam Bolt x 20


(C)




Dowel x 6

# Assembly Instructions

## Step 3




## Step 4



# Assembly Instructions

## Step 5




C



Dowel x 20

## Step 6



A



Cam Bolt x 18


C



Dowel x 8

# Assembly Instructions

## Step 7



(A)



Cam Bolt x 11

(C)



Dowel x 2

(E)




3.5\*14mm Screw x 4

(S)



Magnet x 2

## Step 8



(A)



Cam Bolt x 11

(C)



Dowel x 2

(E)



3.5\*14mm Screw x 4


(S)



Magnet x 2

# Assembly Instructions

## Step 9



(A)




Cam Bolt x 8

(C)



Dowel x 8

## Step 10




(C)



Dowel x 8

# Assembly Instructions

## Step 11



(A)




Cam Bolt x 22

(C)



Dowel x 16

## Step 12



(E)



3.5\*14mm Screw x 8

(I)



Handle x 6

(J)



4\*20mm Screw x 6

(T)



Sheet iron x 2

(Z)



Sheet iron x 4


(P)



Plastic hingex 12

# Assembly Instructions

## Step 13



**B**




Lock x 3

**Q**




Nut x 3

**R**



Screw arbor x 3

## Step 14




**B**




Lock x 8


step1



step2




step3



# Assembly Instructions


## Step 15



step1

step2

step3




(B)



Lock x 4


## Step 16



step1

step2

step3




(B)





Lock x 20

# Assembly Instructions

## Step 17



## Step 18





**B**



Lock x 6

# Assembly Instructions

## Step 19




(B)



Lock x 6

## Step 20




(D)



7\*50mm Screw x 4

# Assembly Instructions

## Step 21



Y

L sheet iron x 1

E

3.5\*14mm Screw x 2

B

Lock x 3


Q

Nut x 1

R

Screw arbor x 1

## Step 22





B

Lock x 16

# Assembly Instructions

## Step 23



**B**



Lock x 2

**Q**





Nut x 2

**R**



Screw arbor x 2

## Step 24



**B**



Lock x 16



**E**



3.5\*14mm Screw x 2

# Assembly Instructions

## Step 25



(V)




3\*14mm Screw x 42

(B)



Lock x 12

## Step 26




(U)



6x35 Screw x 8

# Assembly Instructions

## Step 27




ⓓ



7\*50mm Screw x 8

## Step 28





ⓓ



7\*50mm Screw x 6

# Assembly Instructions


## Step 29





(B)



Lock x 8




## Step 30



(B)




Lock x 8



# Assembly Instructions

## Step 31




Ⓓ



7\*50mm Screw x 4

## Step 32



⒱



Clamping nut x 6


ⓧ



6x20 Screw x 6

# Assembly Instructions

## Step 33



**B**




Lock x 4


step1

step2

step3




## Step 34



# Assembly Instructions

## Step 35



**B**




Lock x 18


step1

step2

step3





## Step 36




# Assembly Instructions




## Step 37




<p><b>B</b></p>  <p>Lock x 12</p>	<p><b>O</b></p>  <p>Felt pad x 14</p>
--	--

## Step 38



<p><b>B</b></p>  <p>Lock x 2</p>	
<p><b>F</b></p>  <p>Plastic buckle x 32</p>	<p><b>G</b></p>  <p>3*12mm Screw x 32</p>





# Assembly Instructions

