

Parts List

1	Frame	1 pc
2	Brackets	2 pcs
3	Legs	2 pcs
4	Feet	2 pc
5	Keypad	1 pc
6	Screws	16 pc



1



2



3



4



5




6



DISCLAIMER:
Buyer accepts full liability for any injury or loss to themselves, their property, and anyone else anytime and from any cause while using this product. Buyer expressly releases Uncaged Ergonomics and its agents from any liability for such loss or injury. In no event shall Uncaged Ergonomics or its agents be liable for any direct, indirect, punitive, incidental, damages or injury whatsoever arising out of or connected with the use or misuse of its products.

STEP 1: Adjust The Frame Width

- Adjust the frame to your desired width and install 8pcs of the M6x10 screws to secure it in place.
- Ensure the large circular holes on the side of the frame are uncovered.
- You can easily adjust the frame width later.



STEP 2: Connect the Columns to the Frame

- Screw the columns to the frame with 8 pcs of M6x10 screws.
- Ensure the side holes are uncovered so you can insert the screws through the frame into the column.



STEP3: Connect the Feet to the Columns

- Connect each foot to a column with 4pcs of the long M6x35 screws.
- The black, circular feet can be unscrewed later to level your desk.



STEP4: Install The Brackets

- Slide the side brackets on each end of the frame and secure them with 2pcs M6x14 screws.



How To Use The Memory Settings:

- Adjust the desk to your desired height.
- Press and hold "M" until the screen shows S1
- Press the number you'd like to save the height.



How to Reset Your Desk:

1. Press the down arrow to lower the desk. *release the down arrow*
2. Press and hold the down arrow until the screen shows ASR. *release the down arrow*
3. Press and hold the down arrow until the screen shows the numerical height. The desk should lower all the way and then raise slightly. *release the down arrow*