



# Installation & Assembly

## Corner Desk with Storage Cabinet



**Option A**




**Option B**

Two people are recommended to install, which will greatly improve your installation efficiency.

## Tips Before Assembly


1. Read through each step carefully and follow the proper order.
2. Identify, sort and count all the parts with tags.
3. To avoid any scratching, putting a soft blanket on the floor is suggested.
4. If using a power drill or power screwdriver for the screwing, please be aware to slow down and stop when screw is tight. Failure to do so may result in stripping the screw.
5. Put the screws in loosely until all pieces are together and then tighten them all. It will save your time if you make a mistake while installing.



# Using Camlocks


Connect the male camlock as directed in the assembly instructions using a screwdriver.

**1** DO NOT OVER TIGHTEN



Push the male camlock into the entry hole.


**2**



Insert the female camlock as shown in the instruction.

Note: ensure that the arrow on the top of the camlock points toward the entry hole for the male camlock.

**3**





Turn the female camlock clockwise with a screwdriver.

You should feel a click when the camlock is locked in place.


















The joint is now secure.

**4**


































PART LIST

<p><b>A</b></p>  <p>1 pc</p>	<p><b>B</b></p>  <p>1 pc</p>	<p><b>C</b></p>  <p>2 pcs</p>
<p><b>D</b></p>  <p>1 pc</p>	<p><b>E</b></p>  <p>1 pc</p>	<p><b>F</b></p>  <p>1 pc</p>
<p><b>G</b></p>  <p>1 pc</p>	<p><b>H</b></p>  <p>1 pc</p>	<p><b>I</b></p>  <p>1 pc</p>
<p><b>J</b></p>  <p>1 pc</p>	<p><b>K</b></p>  <p>1 pc</p>	<p><b>L</b></p>  <p>1 pc</p>
<p><b>M</b></p>  <p>2 pcs</p>	<p><b>N</b></p>  <p>2 pcs</p>	<p><b>O</b></p>  <p>2 pcs</p>
<p><b>P</b></p>  <p>2 pcs</p>	<p><b>Q</b></p>  <p>2 pcs</p>	





## HARDWARE LIST

<p>①</p>  <p>M6x40      14 pcs</p>	<p>②</p>  <p>M6x30      2 pcs</p>	<p>③</p>  <p>M6x16      6 pcs</p>	<p>④</p>  <p>M4x16      12 pcs</p>
<p>⑤</p>  <p>M6x28      16 pcs</p>	<p>⑥</p>  <p>Ø12      16 pcs</p>	<p>⑦</p>  <p>M3x12      26 pcs</p>	<p>⑧</p>  <p>1 pc</p>
<p>⑨</p>  <p>M4x16      4 pcs</p>	<p>⑩</p>  <p>2 pcs</p>	<p>⑪</p>  <p>M6x40      6 pcs</p>	<p>⑫</p>  <p>Ø15      6 pcs</p>
<p>⑬</p>  <p>Ø6x20      4 pcs</p>	<p>⑭</p>  <p>M6x40      4 pcs</p>		<p>⑮</p>  <p>RF Remote Control 1 pc</p>
<p>⑯</p>  <p>M6x70      4 pcs</p>		<p>⑰</p>  <p>Ø50*30mm      6 pcs</p>	<p>⑱</p>  <p>Ø48      2 pcs</p>
<p>⑲</p>  <p>2 pcs</p>	<p>⑳</p>  <p>2 pcs</p>	<p>㉑</p>  <p>2 pcs</p>	<p>㉒</p>  <p>2 pcs</p>
<p>㉓</p>  <p>M6x35      6 pcs</p>	<p>㉔</p>  <p>Ø15*1      8 pcs</p>	<p>㉕</p>  <p>M4      1 pc</p>	<p>㉖</p>  <p>1 pc</p>


STEP 1






STEP 2




STEP 3


9  x4


10  x2





STEP 4


7  x12

20  x2

22  x2




Roller at the end







# Option A


STEP 5




STEP 6





STEP 7

6  x4





STEP 8



6  x4




STEP 9




STEP 10





STEP 11


①  x6





STEP 12

③  x6

⑰  x6





STEP 13





There are no reserved holes on both sides, please use tools to screw directly.

STEP 14





There are 3 heights for the shelf to be adjusted as you need.

STEP 15




Please put the wheels align with the slots as the instruction shows, then slide into them







STEP 16





STEP 17




Please ensure that using the correct screws for panel assembly. Using the wrong screw will cause a cracked panel.




STEP 18




STEP 19





DONE






# Option B




STEP 5




STEP 6





STEP 7

⑥  x4





STEP 8



⑥  x4




STEP 9




STEP 10





STEP 11


1  x6





STEP 12

3  x6

17  x6




STEP 13




*There are no reserved holes on both sides, please use tools to screw directly.*



STEP 14



*There are 3 heights for the shelf to be adjusted as you need.*





STEP 15




Please put the wheels align with the slots as the instruction shows, then slide into them


STEP 16







STEP 17



STEP 18



STEP 19



DONE

