






Installation & Assembly




EN_IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.


USING CAM LOCK AND QUICKFIT




EN_QUICKFIT: Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.



EN_CAM LOCK: When fitting cam lock, ensure starting position is correct before you insert connecting quickfit.























EN_Quickfit head should be in the centre of the cam lock when the two panels are joined.
Cam lock should be inserted before quickfit.





EN_Turn cam lock clockwise to tighten.


PACKING DELALS

NO.	PARTS	QTY	SPARE
①		x1	
②		x1	
③		x2	
④		x1	
⑤		x2	
⑥		x1	
⑦		x2	
⑧		x1	
⑨		x1	
⑩		x4	
























NO.	PARTS	QTY	SPARE
⑪		x1	
⑫		x2	
⑬		x2	
⑭		x9	
⑮		x9	
⑯		x9	
⑰		x9	
⑱		x9	
⑲		x3	
⑳		x3	

NO.	PARTS	QTY	SPARE
②②		x3	
	 Hardware Kit	x1	


PARTS



HARDWARE



 <p>A x57 Ø6x35mm +3(spare)</p>	 <p>B x57 Ø15x10mm +3(spare)</p>	 <p>C x48 Ø6x30mm +4(spare)</p>	 <p>D x65 Ø4x35mm +6(spare)</p>	 <p>E x108 Ø3.5x12mm +9(spare)</p>	 <p>F x4</p>
 <p>G x16 Ø3.5x12mm +1(spare)</p>	 <p>H x16 Ø5x35mm +1(spare)</p>	 <p>I x2</p>	 <p>J x9 J-1</p>  <p>J-2</p>	 <p>K x2 Ø4x14mm K-1</p>  <p>K-2</p>	 <p>L x12 Ø3x16mm +2(spare) L-1</p>  <p>L-2</p>
 <p>M x2 Ø6x30mm</p>	 <p>N x8 +1(spare)</p>	 <p>O x4 Ø10x10mm</p>	 <p>P x4 Ø6x80mm</p>		
 <p>CL x9 L350mm</p>	 <p>CR x9 L350mm</p>	 <p>DL x9 L350mm</p>	 <p>DR x9 L350mm</p>		

D x45



A x45

J x9














B x45

C x18

E x54

DL x9






DR x9



A x1

E x9






CL x3



A x1

E x9

CR x3









A x2

E x36



CL x6

CR x6




180°

Second hole




C x2

D x2



B x1


C x1



D x4



09



B x2




C x2



D x2




10




B x1

C x1

D x2





C x8





C x8

O x4



P x4



H x12



H x4




F x4




G x16




I x2





D x8




C x8



A x8







L x12





L-1



L-2






If the cabinet is unstable with the ground, please rotation control the foot fitting (I)


D x2




K x2




M x2




First fix the anti-rewind screw in the reserved hole of the product.




Then, put the expansion bolt into the hole




then, use a ruler to measure the approximate height of the product on the wall, and then mark it with a pen.




Finally, pass the matching screws through the "anti-rewind" and tighten them to fix them on the wall.




Then use a tape drill to make holes in the wall that are suitable for the product screws.



WALL





WARNING

Do not push the furniture violently during the moving process, otherwise there will be a risk of tipping and damage, which is unsafe behavior. Moving furniture after assembly requires two or more people to lift it.