
Multipurpose Storage Cabinet with Display Shelves and Doors



ASSEMBLY AND CARE GUIDE

1 HOUR
ASSEMBLY TIME

2 PEOPLE REQUIRED FOR ASSEMBLY

2 x 1 m

SAFETY PRECAUTIONS

PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE ASSEMBLING AND USING THE PRODUCT.

- 1. Please check that all parts are present beforeyou start the assembly of your furniture. A **Philips** head screwdriver (not included) is required for the assembled of this product.
- 2. For ease and speed of assembly, we recommend that before you commence each step of the assembly, that you identify all the parts required for that step.
- 3. For larger items, please ensure that you have sufficient space and people to assemble your product safely.
- 4. We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- 5. For the protection of your furniture, we recommend that the product is placed on a protected surface during assembly to prevent any damage.
- 6. During assembly, Do not tighten bolts / screws completely until all bolts / screws are lined up and inserted into holes, Do not over tighten screws and bolts to avoid stripping, Do not use power tools
- 7. Always place the product on a flat, steady and stable surface.
- 8. Do not stand on the product. Do not use the product as a stepladder.
- 9. This product is intended for indoor, household use only as it is a non industrial product.

CARE AND CLEANING

- Please periodically check all fittings and re-tighten as necessary.
- To clean your item, please use a damp cloth and wipe clean.
- Never allow any kind of liquid to remain on your furniture. If liquid spills onto the product, please wipe clean as soon as possible.



WARNING: ENSURE THE WALL STRAP IS ATTACHED TO AVOID SERIOUS INJURY.


To avoid any serious or fatal injury, this product has been fitted with a wall strap to prevent toppling. We strongly recommend that this product is permanently fixed to the wall or other suitable surface. Fixing devices are not included since different surface materials require different attachments. Please seek professional advice if you are in doubt of what fixing device to use.

Do not stand on the product. Do not climb on the product. Do not swing on the product.

HARDWARE LIST

Ax16		Bx16		(30mm Cx14	Ø4X35mm Dx16
(\$8)					BAIO
	Ģ	ø3X12mm Fx36		∮6X55mm Gx8	Hx8
65	Q.				
lx8	Ģ			3X16mm Kx6	Lx3
				attrice	attitle
Mx4		Nx2		3X14mm Ox2	Ø3X14mm Px12
	0			00	
Qx12 R	x4	Sx2		Tx6	Ux1

ASSEMBLY DIAGRAM





AFTER SALES SUPPORT


If you have any general enquiries or require spare parts for this product, please feel free to contact us

You can contact us for support at any time. We'll answer you in 24hrs.

STEP 1.









Attach 6 x bolts (A) to panel (1). Tighten with a screwdriver.

STEP 2.









Attach 2 x bolts (A) to panel (7). Tighten with a screwdriver.

STEP 3.





Attach 4 x bolts (A) to panel (4). Tighten with a screwdriver.




Attach 4 x bolts (A) to panel (3). Tighten with a screwdriver.

STEP 4.






Attach panel (5) to panel (7) using 2 x wood dowels (C) and 2 x screws (D) and tighten with a screwdriver.




Attach panel (5) to panel (7) and secure with 2 x locking nuts (B) as shown. Tighten with a screwdriver.

STEP 5.





Attach panel (7) to assembled unit using 2 x wooden dowels (C) and 2 x screws (D) as shown. Tighten with as screwdriver.



Attach panel (5) to assembled unit using 2 x locking nuts (B) as shown. Tighten with a screwdriver.


STEP 7.






Attach panel (4) to assembled unit and secure with 4 \times locking nuts (B). Tighten with a screwdriver.

STEP 8.




Slide 3 x panels (6) into position as shown.

STEP 9.




Attach panel (3) to assembled unit and secure with 4 x locking nuts (B). Tighten with a screwdriver.




Attach 2 x parts (10) to 2 x parts (11) with 4 x parts (12) as shown. Secure with 16 x screws (E). Tighten with a screwdriver.

STEP 11.





Attach 4 x legs (9) to assembled unit. Secure with 8 x bolts (G) and 8 x washers (H) and 8 x washers (I). Tighten with a hex key (U). Attach 4 x foot pads (M) to legs.



Attach panel (2) to assembled unit using 6 x wooden dowels (C) and 6 x screws (D). Tighten with a screwdriver.


STEP 13.







Attach legs to assembled unit using 6 x screws (J). Tighten with a screwdriver.

STEP 14.









Attach panel (1) to assembled unit and secure with 6 x locking nuts (B). Tighten with a screwdriver.

STEP 15.






Attach 2 x hinges (T) to the door panel (8) using 4 x screws (F) as shown. Attach handle (L) to the door panel (8) using 2 x bolts (K). Tighten with a screwdriver. Repeat with the other 2 door panels.



Attach door (8) to the right side of assembled unit using 8 x screws (F). Tighten with a screwdriver.

STEP 17.




Attach 2 x doors (8) to the left side of assembled unit using 16 x screws (F) as shown. Tighten with a screwdriver.

Is your cabinet door looking crooked or unevenly spaced?


Then you've come to the right place. Follow the illustrations below to get your cabinet door aligned and ready for action.

If your door is too low or too high...




Loosen the height screws, then move the door up or down to make it level.

If the space between your doors is off...




Loosen the side-to-side screws, then screw counter-clockwise to make the gap wider or clockwise to close any gaps.

If you need to adjust the depth of the doors...




Adjust the in-and-out screws until the door is aligned with the side of the cabinet.




Attach 12 x plastic wedges (Q) to the back of assembled unit as shown and secure with 12 x screws (P). Tighten with a screwdriver.

Attach 2 x wall straps (S) to the back of assembled unit as shown and secure with 2 xscrews (O) and 2 x washers (R). Tighten with a screwdriver.

STEP 19.







Fasten to the wall using 2 x wall anchors (N) and 2 x screws (D) and tighten with a screwdriver. Ensure unit is balanced and steady before use. Final assembly.

NOTE: Supplied wall plugs are only suitable for use in masonry walls.

If you have any doubts about using the correct plug for your wall, please seek professional advice. Failure of the product due to using incorrect fixings is the responsibility of the installer.



IMPORTANT:

When drilling into walls, always check for hidden wires or pipes, etc.



Tips & Tricks


Make sure that the hardware used is suitable for supporting your unit.

P lease consult a qualified trades person if unsure.


- ☑ If you are unsure, please select a larger screw and wall plug.
- ☑ Ensure that you use the recommended drill bit to match the wall plug and hole size.
- ☐ Take extra care when drilling high walls, ceiling and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid splitting or cracking.
- ☑ Ensure that wall plugs are well fitted and are a tight fit in the drilled hole.

Types of Walls


Use one of the following types of wall plug (not included) if your walls are made of brick, breeze block, concrete, stone or wood. Screws may be able to be fixed directly to solid wood walls as they will provide a secure anchor point.




1. General Purpose Wall Plug Generally, aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.




2. Plasterboard Wall Plug
For use when attaching light loads onto plasterboard partitions.




3. Cavity Fixing Wall Plug
For use with plasterboard partitions or hollow
wooden doors.



4. Cavity Fixing Heavy Duty Wall Plug
For use when fitting or supporting heavy loads
such as shelving and wall cabinets.



5. Hammer Fixing Wall Plug
For use with concrete block or brick walls, or walls
stuck with plasterboard. The hammer fixing allows it
to be fixed to the wall rather than the plasterboard.
Always check the fixing is secure to the retaining wall.



6. Shield Anchor Wall Plug Heavy Loads For use with concrete or brick walls, or for use with heavier loads such as TV & HiFi speakers and satellite dishes, etc.