


5



L - BRACKET 4PCS


6




SHORT SCREW 8PCS

### STEP 11


TURN 180°



TOOL REQUIRED




8




STICKER 20PCS

### STEP 12



### Recommended Maximum Weight



\*Unit in Pound(lbs.)

#### WARNING:

>This unit has been designed to support the maximum loads shown. Exceeding these load limits could cause sagging, instability, product collapse, and/or serious injury.

>DO NOT allow children to climb on unit.


> Put heavier items on lower shelves.

## Assembly Instruction


Tier Open Shelf Bookcase

00:50


Approx. 50 minutes




Recomm. 2 Persons












Tools Required











## EXPLODED VIEW



## PARTS LIST


|   |  |  |
|---|--|--|
| <br>LEFT SIDE TOP PANEL   1 PC   | <br>TOP PANEL   1 PC           | <br>SHELF PANEL   3 PCS        |
| <br>BACK PANEL   5 PCS          | <br>RIGHT BOTTOM PANEL   1 PC | <br>CENTER SHELF PANEL   1 PC |
| <br>RIGHT SIDE TOP PANEL   1 PC | <br>RIGHT BOTTOM PANEL   1 PC | <br>BOTTOM PANEL   1 PC       |

## HARDWARE LIST


|  |   |
|--|---|
| <br>LONG SCREW   24 PCS       | <br>SHORT DOWEL   20 PCS    |
| <br>CAM - LOCK SCREW   4 PCS | <br>CAM - LOCK NUT   4 PCS |
| <br>L - BRACKET   4 PCS      | <br>SHORT SCREW   8 PCS    |
| <br>LONG DOWEL   2 PCS       | <br>STICKER   20 PCS       |

### USEFUL HINTS BEFORE YOU START:


1. Read each step carefully before starting.
2. It is important that each step is performed in correct order to avoid difficulties.
3. Identify, soft and count the parts before assembly.
4. Assemble your furniture on packaging cardboard to prevent scratch or damage.
5. Clean the product with mild cleanser using soft damped cloth. Do not use harsh or abrasive cleanser.
6. Using incompatible hardware might cause damage to product.




## STEP 9




### TOOL REQUIRED




## STEP 10




### TOOL REQUIRED








### STEP 7





TOOL REQUIRED




### STEP 8





TOOL REQUIRED




### STEP 1




TOOL REQUIRED




### STEP 2



TOOL REQUIRED



7




LONG DOWEL 2 PCS

4




CAM-LOCK NUT 4 PCS


### STEP 3



TOOL REQUIRED




1




LONG SCREW 4 PCS


### STEP 4




TOOL REQUIRED



### STEP 5




1



LONG SCREW 4 PCS

### STEP 6



TOOL REQUIRED

