




STEP 5

- 5.1 Attach Door Panel (G), (F) with L/R Turn Plate (5), (6) using Screw (1).
 - 5.2 Attach Door Panel (E) to the completed unit in Step 5.1.
- **Repeat Step 5 to another 2 drawers. ****




STEP 6

- 6.1 Attach Door Panel to cabinet using Plastic Nut/Screw (8).
- 6.2 Attach Handle (7) to Door Panel (E) using Screw (7).
- 6.3 Attach Shelf Panel (F) to the center of Door Panel using Screw (1).



Note: Attach Plastic Nut (8) to Plastic Cover (4) through hole and tighten with Screw (8).

Recommended Maximum Weight



*Unit in Pound(lbs)

WARNING:

>This unit has been designed to support the maximum loads shown. Exceeding these load limits could cause sagging, instability, product collapse, and/or serious injury.

>DO NOT allow children to climb on unit.

>Put heavier items on lower shelves.

Assembly Instruction

3-Door Shoe Storage Cabinet

DIMENSION : 21.8"(W) x 49.1"(H) x 10.9"(D)

00:45


Approx. 45 minutes
























Recomm. 2 Person




Tools Required



No	Hardware List	Qty
1	Screw 	32pcs
2	Wood Dowel 	10pcs
3	Cam-Lock Screw/Nut 	12pcs
4	Plastic Cover 	6pcs
5	Left Turn Plate 	3pcs
6	Right Turn Plate 	3pcs
7	Handle/Screw 	3pcs
8	Plastic Nut/Screw 	6pcs
9	Stopper 	6pcs
10	Ventilation Cover 	3pcs
11	L-Support/Screw 	4pcs

No	Parts List	Qty
A	Right Side Panel 	1pcs
B	Left Side Panel 	1pcs
C	Top Panel 	1pcs
D	Bottom Panel 	1pcs
E	Door Panel 	2pcs
F	Door Shelf Panel 	4pcs
G	Door Bottom Panel 	2pcs
H	Front Panel 	1pcs
I	Back Panel 	2pcs
J	Back Cover Panel 	2pcs




USEFUL HINTS BEFORE YOU START:

1. Read each step carefully before starting.
2. It is important that each step is performed in correct order to avoid difficulties.
3. Identify, sort and count the parts before assembly.
4. Assemble your furniture on packaging cardboard to prevent scratch or damage.
5. Clean the product with mild cleanser using soft damped cloth. Do not use harsh or abrasive cleanser.
6. Using incompatible hardware might cause damage to product.


STEP 1

- 1.1 Attach Panel (H) and (D) using Wood Dowel (2).
- 1.2 Insert Plastic Cover (4) and Stopper (9) to L/R Side Panel (A), (B), as shown.




STEP 2

Attach Panel (A), (B), (D), (H), (I) and (J) using Wood Dowel (2) and Cam-Lock Screw/Nut (3).



STEP 3

- 3.1 Slide Upper Back Panel (J) into L/R Side Panel (A), (B).
- 3.2 Attach Top Panel (C) to L/R Side Panel (A), (B) using Cam-Lock Screw/Nut (3).
- 3.3 Insert Ventilation Cover (10) to Upper Back Panel (J).



STEP 4

Attach L-Support/Screw (11) to the unit.

