





# HLG0127

Version: 1.0



**EN\_IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.**

. THANK YOU FOR PURCHASE! .

# FREE REPLACEMENT PARTS AVAILABLE!



*---NEED HELP WITH YOUR FURNITURE?---*

Scan the QR code to contact us!



If you're experiencing any issues—whether due to shipping, assembly, or any other reason  
—we're here to help.  
For any damaged or missing components, we're happy to provide FREE replacement parts.



WhatsApp


**Email: support @anymaple.com**

---


## WANT TO CONTACT US THROUGH AMAZON?

- ▶ Log in to your Amazon account.
- ▶ Go to “Your Orders” and locate your furniture order.
- ▶ Click on “Get Help with Order” to send us a message directly.


Our customer support team is ready to assist you and we will respond within  
12-24 HOURS to resolve your concerns quickly!




**EN\_QUICKFIT:** Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.













**EN\_CAM LOCK:** When fitting cam lock, ensure starting position is correct before you insert connecting quickfit.












**EN\_Quickfit** head should be in the centre of the cam lock when the two panels are joined.  
Cam lock should be inserted before quickfit.


























**EN\_Turn** cam lock clockwise to tighten.

NO.	PARTS	QTY	SPARE
1		x2	
2		x2	
3		x2	
4		x2	
5		x1	
6		x1	
7		x1	
8		x1	
9		x1	
10		x3	


NO.	PARTS	QTY	SPARE
11		x2	
12		x3	
13		x3	
14		x3	
15		x3	
16		x3	
	 Hardware Kit		



 <b>A</b> x27 Ø6x35mm +2(spare)	 <b>B</b> x27 Ø15x10mm +2(spare)	 <b>C</b> x28 Ø6x30mm +2(spare)	 <b>D</b> x25 Ø4x35mm +2(spare)	 <b>E</b> x36 Ø3.5x12mm +2(spare)	 <b>F</b> x3
 <b>G1</b>  <b>G2</b> <b>G</b> x8 Ø3x16mm	 <b>H</b> x16 Ø5x35mm +1(spare)	 <b>I</b> x2 Ø6x30mm	 <b>J</b> x2	 <b>K</b> x2 Ø4x14mm	 <b>L</b> x8
 <b>M</b> x4 Ø6x80mm	 <b>N</b> x4 Ø10x10mm	 <b>O</b> x4	 <b>CL</b> x3 300mm	 <b>CR</b> x3 300mm	 <b>DL</b> x3 300mm
 <b>DR</b> x3 300mm					

 <b>A</b> x15	 <b>C</b> x12	 <b>D</b> x15
---	---	---

**x3** **01**







B x15

F x3

x3

02



Notice


E x18

DL x3

DR x3

x3


03




E x18

CL x3

CR x3




Attention, first hole



Attention, first hole

CR

7





6

CL

A x4

C x4







5

B x4



06


Notice



C x4





07




D x4





08



10




A x8



B x8



11



M x4

Ø6x80mm




N x4


Ø10x10mm



12




C x8







H x16



# Notice






If board 1 does not have a 90 degree angle, please rotate board 1 90 degrees by hand.




D x4

O x4



Notice










G x8  
Ø3x16mm



L x8





D x2




I x2




J x2




K x2




First fix the anti-rewind screw in the reserved hole of the product.




Then, put the expansion bolt into the hole



then, use a ruler to measure the approximate height of the product on the wall, and then mark it with a pen.



Finally, pass the matching screws through the "anti-rewind" and tighten them to fix them on the wall.



Then use a tape drill to make holes in the wall that are suitable for the product screws.

