


4 DRAWER DISSING TABLE WITH
LIGHTS

ASSEMBLY
INSTRUCTIONS




Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. Count all parts and material hardware, then compare with parts list to be sure all parts are present. If any parts are missing or damaged, phone, fax, or mail to our Customer Service Department for efficient and speedy service. Please indicate the model number and code letter of part(s) needed.

NOTE: In order to prevent damage during assembly, please assemble this item with at least two people.

IMPORTANT NOTE: Follow instructions listed below in proper sequence as numbered to assure fast, easy and correct assembly.


PARTS LIST

1




TOP PANEL-1PC

2




TOP LEFT PANEL-1PC

3




UPPER BACK PANEL-1PC

4




UPPER SHELF -1PC

5




BOTTOM SHELF -1PC

6




FIXED PANEL -1PC

7




MIRROR FRAME-1PC

8




RIGHT SHELF-1PC

9




FIXED RIGHT PANEL-1PC

10




LEFT SIDE PANEL-1PC

11




RIGHT SIDE PANEL-1PC

12




STAND PANEL-1PC

13




BACK RAIL-1PC

14




MIDDLE RAIL-1PC

15




MIDDLE RAIL-1PC

16




LEFT FRONT RAIL-1PC

17




RIGHT FRONT RAIL-1PC

18



BOTTOM RAIL-1PC

19




BOTTOM PANEL-1PC

20




BACK PANEL-1PC


21

TOP DRAWER
FRONT PANEL-1PC


22

TOP DRAWER
LEFT PANEL-2PCS


23

TOP DRAWER
RIGHT PANEL-2PCS


24

TOP DRAWER
BACK PANEL-1PC


25

TOP DRAWER
FRONT PANEL-1PC


26

TOP DRAWER
BACK PANEL-1PC


27

LOWER DRAWER
FORNT PANEL-3PCS


28

LOWER DRAWER
LEFT PANEL-3PCS


29

LOWER DRAWER
RIGHT PANEL-3PCS


30

LOWER DRAWER
BACK PANEL-3PCS


31

BIG DRAWER
BOTTOM PANEL-1PC

32


SMALL DRAWER
BOTTOM PANEL-4PCS

33




SEAT FRAME-1PC






















34



CHAIR SIDE PANEL-2PCS


35

CHAIR
FRONT/BACK PANEL-2PCS

A  CAM-BOLTS - 41PCS	B  CAM-LOCKS-41PCS	C  DOWELS-59PCS
D  SCREWS - 25PCS	E  SCREWS - 87PCS	F  KNOB - 5PCS
G  BOLT - 5PCS	H  SCREW - 20PCS	I  FEMALE SLIDING LEFT-5PCS
J  MALE SLIDING LEFT-5PCS	K  FEMALE SLIDING RIGHT-5PCS	L  MALE SLIDING RIGHT-5PCS
M  SMALL CAM-BOLTS - 16PCS	N  SMALL CAM-LOCKS - 16PCS	O  SMALL DOWELS-4PCS
P  SOCKET-1PC	Q  HANGER-1PC	R  LED LIGHT - 10PCS
T  ANCHORS-4PCS	U  SCREW-4PCS	V  HOOKS-4PCS

NOTE: THE SURFACE WITH THE STICKER IS THE BACK SIDE.

W



PLASTIC BELTS-2PCS

X





CAM TOOL-1PC

Y

Z




NOTE: THE SURFACE WITH THE STICKER IS THE BACK SIDE.

NOTE: ● UPON OPENING, THOROUGHLY CLEAN ALL WOOD SURFACES TO REMOVE DUST AND DIRT THAT MAY HAVE SETTLED ONTO FINISH DURING SHIPMENT. IN ORDER TO PREVENT DAMAGE DURING ASSEMBLY, PLEASE ASSEMBLE THIS ITEM WITH AT LEAST TWO PEOPLE.





NOTE: TURN THE CAM-BOLT SCREWS UNTIL THEY ARE TIGHT, THE SHOULDER SHOULD BE AGAINST THE SURFACE OF THE PART.



HOW TO USE THE CAM-TOOL





NOTE: ● THE ARROWS ON THE HIDDEN CAM-LOCKS SHOULD POINT TO THE CAM-BOLTS





10



11



12




12

LEFT SIDE

RIGHT SIDE


1).ASSEMBLE THE FEMALE SLIDING (I/K)

- PLACE THE FEMALE SLIDING (I/K) INTO THE HOLES IN THE PANEL (10/11/12) AND ATTACH USING 28 SCREW (E).




2).ASSEMBLE THE BOTTOM PANEL (19) AND BOTTOM RAIL (18)

- ROTATE 2 CAM-BOLTS(A) INTO THE HOLES IN THE BOTTOM RAIL(18).
- PLACE THE BOTTOM RAIL (17) AND 2 DOWELS (C) INTO THE HOLES IN THE BOTTOM PANEL (19) AND ATTACH USING 2 CAM LOCK (B).




3).ASSEMBLE THE PANEL (10/12)

- ROTATE 8 CAM-BOLTS(A) INTO THE HOLES IN THE PANEL (10/12).
- PLACE THE FRONT RAIL (16), BOTTOM PANEL (19) AND 8 DOWELS (C) INTO THE HOLES IN THE PANEL (10/12) AND ATTACH USING 8 CAM LOCK (B).




4).ASSEMBLE THE RAIL (14/15)

- ROTATE 2 CAM-BOLTS (A) INTO THE HOLES IN THE RAIL(15).
- PLACE THE RAIL (14) AND 2 DOWELS (C) INTO THE HOLES IN THE RAIL (15) AND ATTACH USING 2 CAM LOCK (B).




5).ASSEMBLE THE PANEL (10)

- ROTATE 8 CAM-BOLTS (A) INTO THE HOLES IN THE PANEL (11/12).
- PLACE THE RAIL (13/14/17) AND 12 DOWELS (C) INTO THE HOLES IN THE PANEL (11/12) AND ATTACH USING 8 CAM LOCK (B).




6).ASSEMBLE THE PANEL (5/6)

- PLACE THE PANEL (6) AND 1 DOWELS (C) INTO THE HOLES IN THE PANEL (5) AND ATTACH USING 1 SCREW (D).




7).ASSEMBLE THE PANEL (3/4/5)

- PLACE THE PANEL (4/5) AND 5 DOWELS (C) INTO THE HOLES IN THE PANEL (3) AND ATTACH USING 6 SCREW (D).




8).ASSEMBLE THE PANEL (2)

- PLACE THE PANEL (2) AND 4 DOWELS (C) INTO THE HOLES IN THE PANEL (3) AND ATTACH USING 5 SCREW (D).




9).ASSEMBLE THE SHELF (8) AND THE PANEL (9)

- ROTATE 1 CAM-BOLTS (A) INTO THE HOLES IN THE SHELF (8).
- PLACE THE PANEL (9) AND 1 DOWELS (C) INTO THE HOLES IN THE SHELF (8) AND ATTACH USING 1 CAM-LOCKS (B).




10).ASSEMBLE THE FRAME (7) AND THE SHELF (8).

- PLACE THE SHELF (8) AND 4 DOWELS (C) INTO THE HOLES IN THE FRAME (7) AND ATTACH USING 3 SCREW (D).




11).ASSEMBLE THE FRAME (7) AND THE PANEL (3/6)

- ROTATE 1 CAM-BOLTS (A) INTO THE HOLES IN THE PANEL (6).
- ROTATE 3 CAM-BOLTS (A) INTO THE HOLES IN THE FRAME (7).
- PLACE THE PANEL (3) AND 3 DOWELS (C) INTO THE HOLES IN THE FRAME (7) AND ATTACH USING 4 CAM-LOCKS (B).




12).ASSEMBLE THE FRAME (7) AND THE PANEL (1).

- PLACE THE PANEL (1) AND 5 DOWELS (C) INTO THE HOLES IN THE FRAME (7) AND ATTACH USING 6 SCREWS (D).
- ROTATE 8 CAM-BOLTS (A) INTO THE HOLES IN THE PANEL (1).




12).ASSEMBLE THE TOP PANEL (1) AND MAIN BODY.

- PLACE THE PANEL (1) AND 8 DOWELS (C) INTO THE HOLES IN THE MAIN BODY AND ATTACH USING 8 CAM-LOCKS (B).




13).ASSEMBLE THE BACK PANEL (20) AND SOCKET (P).

- PLACE THE BACK PANEL (20) AND SOCKET (P) INTO THE HOLES IN THE MAIN BODY AND ATTACH USING 15 SCREWS (E).




14).ASSEMBLE THE TOP DRAWER

- ROTATE 2 SMALL CAM-BOLTS (M) INTO THE HOLES IN THE TOP DRAWER FRONT PANEL(21).
- ATTACH THE DRAWER BACK (24) AND DRAWER LEFT/RIGHT (22/23) USING 4 SCREWS (H).
- PLACE THE TOP DRAWER FRONT PANEL (21) AND 2 DOWELS (O) INTO THE HOLES IN THE DRAWER LEFT/RIGHT (22/23) AND ATTACH USING 2 SMALL CAM-LOCKS (N).
- PLACE THE SLIDING (J),(L) INTO THE HOLES IN THE DRAWER SIDE PANEL(19),(20) AND USING 8 SCREWS (E).



15).ASSEMBLE THE TOP DRAWER


- ROTATE 2 SMALL CAM-BOLTS (M) INTO THE HOLES IN THE TOP DRAWER FRONT PANEL(25).
- ATTACH THE DRAWER BACK (26) AND DRAWER LEFT/RIGHT (22/23) USING 4 SCREWS (H).
- PLACE THE TOP DRAWER FRONT PANEL (25) AND 2 DOWELS (O) INTO THE HOLES IN THE DRAWER LEFT/RIGHT (22/23) AND ATTACH USING 2 SMALL CAM-LOCKS (N).
- PLACE THE SLIDING (J),(L) INTO THE HOLES IN THE DRAWER SIDE PANEL(19),(20) AND USING 8 SCREWS(E).



X3


16).ASSEMBLE THE LOWER DRAWER

- ROTATE 4 SMALL CAM-BOLTS (M) INTO THE HOLES IN THE LOWER DRAWER FRONT PANEL(27).
- ATTACH THE DRAWER BACK (30) AND DRAWER LEFT/RIGHT (28/29) USING 12 SCREWS (H).
- PLACE THE LOWER DRAWER FRONT PANEL INTO THE HOLES IN THE DRAWER LEFT/RIGHT (28/29) AND ATTACH USING 2 SMALL CAM-LOCKS (N).
- PLACE THE SLIDING (J),(L) INTO THE HOLES IN THE DRAWER SIDE PANEL(19),(20) AND USING 24 SCREWS (E).




17).ATTACH THE DRAWERS, LED LIGHTS (R) AND HANGER (Q).

- SLIDE THE DRAWERS INTO THE SLIDERS-OUTS.
- ROTATE LED LIGHTS (R) INTO THE HOLES IN THE MIRROR FRAME (7).
- PLACE THE HANGER (Q) INTO THE HOLES IN THE MAIN BODY AND ATTACH USING 2 CREWS (E).



18).ASSEMBLE THE STOOL.

- INSERT 4 DOWELS (C) INTO THE HOLES IN THE SIDE CHAIRS (34).
- ROTATE 8 CAM-BOLTS (A) INTO THE HOLES IN THE SIDE CHAIRS (34).
- PLACE THE CAMBOLTS (A) AND DOWELS (C) INTO THE HOLES IN THE FRONT/BACK CHAIRS (35) AND ATTACH USING 8 CAM-LOCKS (B)
- PLACE THE CHAIR BODY IN THE SEAT FRAME (33) AND ATTACH USING 4 SCREWS (D).



19).ASSEMBLE THE ANTI-TIP HARDWARE.

- ATTACH HOOKS (V) USING 2 SCREWS (E) IN THE PREDRILLED HOLES OF REAR TOP PANEL (1).
- DRILL 4 HOLES INTO THE WALL, PLEASE REFER TO THE REAR TOP FRAME HOLE DISTANCE AND HEIGHT.
- PUT 4 ANCHORS (T) INTO THE HOLES IN THE WALL, AND ROTATE 4 SCREWS (U) INTO THE GECKOS (T).
- CONNECT THE TWO HOOKS (V) WITH A PLASTIC BELT (W).