
























GAUTION:When tightening the screws,tighten sequentially.
Do not tighten any screws fully and then towards the next one.
When every part is OK,then tighten all the screws.






<p>A x 22+1</p>  <p>Ø5x40</p>	<p>B x 6+1</p>  <p>M6x60</p>	<p>C x 2+1</p>  <p>M6x40</p>	<p>D x 16+1</p>  <p>M6x28</p>
<p>E x 2+1</p>  <p>M6x12</p>	<p>F x 18+1</p>  <p>Ø6x35</p>	<p>G x 18+1</p>  <p>Ø12 Ø6x35</p>	<p>H x 2</p>  <p>M4x10</p>
<p>I x 3</p>  <p>250mm</p>	<p>J x 25+2</p>  <p>3.0x12</p>	<p>K x 1</p> 	<p>L x 4+1</p> 
<p>M x 1</p> 	<p>N x 2</p>  <p>M6x15</p>	<p>O x 4+1</p>  <p>M6</p>	<p>P x 3</p>  <p>M4x18</p>
<p>Q x 1</p>  <p>6.4MM</p>	<p>R x 6+1</p>  <p>M6x20</p>	<p>TOOL</p>   <p>3mm</p> <p>4mm</p>	


Attention



Be sure to use the proper screws to avoid damaging the parts




Wrong screws can cause the plank to crack




The right screw is the right size

STEP 1






STEP 2




G x2




STEP 3




F		x2
G		x2


STEP 4




		3mm
F		x4
A		x4



STEP 5




F  x6


STEP 6




 3mm
A  x6


STEP 7






F  x4


STEP 8







G  x4




STEP 9




L  x4

STEP 10




 3mm G  x4 A  x4

STEP 11




J		x4
I		x1
P		x1




STEP 12




		3mm
G		x8
A		x8

STEP 13







J		x8
I		x2
P		x2

STEP 14






STEP 15




		4mm
N		x2
B		x2



STEP 16




		4mm
E		x2


STEP 17




	4mm
D 	x6



STEP 18




F 	x2
---	----



STEP 19




	4mm
D 	x4



STEP 20




	4mm
R 	x6




STEP 21




K		x1
H		x2

STEP 22



Q		x1
J		x1
M		x1

STEP 23



STEP 24

