


Enjoy Cozy Life!

**12'x12' ALEXANDER HARDTOP GAZEBO  
WITH DOUBLE ROOF**

**ASSEMBLY MANUAL**



**KOZYARD LLC PRODUCTS**

[www.kozyard.com](http://www.kozyard.com)

© Copyright 2016 - 2020 Kozyard LLC. | All Rights Reserved.



1.Three or more people are required for assembly.



5.Use the hex keys in the box.



2.You will need one or more stepladders.




6.Please use a Phillips screwdriver.



3. Wearing protective gloves is recommended.




7.Do not fully tighten screws prior to complete assembly.



4.You may need a safety hat.




8.For ease of construction, you may need to use a drill.




9.Lay every part on soft surface to avoid any scratches .

## Alexander 12x12' ANCHOR BLUEPRINT





A (x4)




L1 (x4)



B (x4)




L2 (x4)



B1 (x4)



R1 (x4)




B2a (x4)



M1 (x4)



M2 (x8)




B2b (x4)



M3 (x4)



M4 (x4)



D (x4)



M5 (x92+5)



W (x4)



E (x4)



W1 (x4)



E1 (x4)



F1 (x4)




F2 (x4)




H (x8)



J (x4)



K (x1)



K1 (x1)

ITEM	DESCRIPTION	QTY
A	Pole	4
B	Beam	4
B1	Beam	4
B2a	Sidewall Track	4
B2b	Sidewall Track	4
D	Union Bar	4
E	Corner Roof Bar	4
E1	Roof Bar	4
F1	Jointer Bar	4
F2	Jointer Bar	4
H	Solidifying Bar	8
J	Finishing End	4
K	Outside Roof Connector	1
K1	Inside Roof Connector	1
L1	Corner Solidifying Bar	4
L2	Corner Solidifying Bar	4
R1	Finishing Bar	4
M1	Plate	4
M2	Finishing End	8
M3	Iron Angle	4
M4	Iron Angle	4
M5	Spacer	92+5
W	Corner Cover	4
W1	Joint Cover	4



Q x112+6




R x72+2




M6\*47




S x8+2




Net x4



D1 x16+1




18 x1



M6\*23




T x72+7




M6\*23

U x20+3




M6\*15

V x228+10



M6\*10


X x16+2



M6\*42




X1 x8+2



Y x24+5




Wa x1




W2 x1




Z x1




P x4




P1 x4




N x4




N1 x4




N2 x4




N3 x4



N4 x4



N5 x4




N6 x4



N7 x4



ITEM	DESCRIPTION	QTY
D1	Metal Bracket	16+1
R	Metal Bracket	72+2
Q	Hook	112+6
N	Roof Panel	4
N1	Roof Panel	4
N2	Roof Panel	4
N3	Roof Panel	4
N4	Roof Panel	4
N5	Roof Panel	4
N6	Roof Panel	4
N7	Roof Panel	4
P	Roof Panel	4
P1	Roof Panel	4
S	Screws	8+2
T	Screws	72+7
U	Screws	20+3
V	Screws	228+10
X	Screws	16+2
X1	Screws	8+2
Y	Screws	24+5
Wa	Screws	1
W2	Wrench	1
Z	Allen Key	1
18	Silicone Sealant	1
ZS3	Net Frame	4

## Parts Required:



## Step 1:


Set up poles (Part A) with stand plates (Part M1) using screws V as shown in diagram.



## Parts Required:



B (x4)



D (x4)




B1 (x4)




V (x24)

## Step 2:


Connect (Part B) and (Part B1) into one beam using union bar (Part D) with screws V.



## Parts Required:




## Step 3: Put 7 hooks into each slot of sidewall track (Part B2a & Part B2b)




Connect parts (B2a&B2b) to the finished beam (Part B1& Part B) using screws V as shown in diagram.

Attach parts (F1& F2) to finished beam (B1 & B) using screws V as show in diagram.






## Parts Required:



## Step 5:

Use screws (U & X) to connect poles and beams together as shown in diagram.



Tip:  
At least two people since  
this step.



## Parts Required:




L1 (x4)



L2 (x4)




V (x32)



## Step 6:

Affix the frame with corner solidifying bars (Parts L1 & L2) using screws V as shown in diagram.



### Tip:

Please measure diagonally from corner to corner. If your structure is square, those two measurements will be the same distance. If they're not, then do a little shifting until they measure the same.

Parts Required:



W (x4)




W1 (x4)



V (x4)




Y (x24)







Step 7:

Finish connecting beams using corner covers (Part W) and screws Y as shown in diagram.

Affix middle beams using joint cover (Part W1) and screws Y and V as shown in diagram.




## Parts Required:




## Reminder:

with silicone rubber to seal  
after finishing the assembly  
it will be better for no water  
leaking in heavy rain.



## Parts Required:




K1 (x1)



E (x4)




M2 (x4)




R1 (x4)




V (x16)






## Step 8: Set up roof frame



Connect the inside roof connect(Part K1) with the corner roof bar (Part E)using screws V.





Attach corner roof bar(Part E) to main frame using screw V as shown in diagram




Attach finishing bar (Part R1) with Finish End (Part M2) using screws V to corner roof bar (Part E) as shown in diagram.

## Parts Required:





## Step 9:


### Upward View




Attach roof bar (Part E1) to inside roof connector using screws V, Attach net frames (Part ZS3) to finishing bars (Part R1) using screws V as shown in diagram.



Attach roof bar (Part E1) to main frame using screw V as shown in diagram.



## Parts Required:




K (x1)




Wa (x1)

### Upward View







**Step 10:** Connect outside roof connector (Part K) to inside roof (Part K1) using screw Wa as shown in diagram.



# Parts Required:




**Step 11:** Cover metal bracket  
(Part D1&R) to roof panels  
as shown  
in diagram.




**Tip:**  
Wearing protective gloves is  
recommended.



# Parts Required:





## Downward View



## Step 12:

Push the roof panels (Part P,P1) to upper roof as shown in diagram.



Attach finishing bars (Part J1&J) to upper roof with finish end (Part M2) using screws V as shown in diagram.



Tip:  
Wearing protective gloves is recommended.





# Parts Required:



## Step 13:


Affix solidifying bars to roof corner bar using iron angle (Part M4) and screw V as shown in diagram.

Affix solidifying bars (Part H) together to roof bar using iron angle (Part M3) and screws V as shown in diagram.



## Overall roof assembly:

Please put the panels on the frame anti-clockwisely








Tip:

Wearing protective gloves is recommended.

Parts Required:  M5 (x92)  M6\*23  T (x72)  M6\*42  X1 (x8)  M6\*47  S (x8)  U (x4)  M6\*23

**Step 15:** Affix roof panels using screws and spacers (Part M5) as shown in diagram.


**Attention:**  
Put on one roof panel and fasten it accordingly before attaching second roof panel.




## Parts Required:



Net  
(x4)





Curtain  
(x4)





(x4)

Secure curtain  
and netting



## Step 16:

Hang up mosquito sidewalls and solid sidewalls  
as shown in diagram.



Attention:

In the end, Check all screws are fixed tightly before using.

# Enjoy Cozy Life!

**SUPPORT:**

Toll free: 1-866-355-0018

[www.kozyard.com](http://www.kozyard.com)

email: [support@kozyard.com](mailto:support@kozyard.com)

**SOCIAL MEDIA:**

Follow us on Instagram

[www.instagram.com/kozyard](http://www.instagram.com/kozyard)

Upload a picture of your Kozyard product in your home, with the hashtag #kozyard to receive \$20 Kozyard Gift Card.

## KOZYARD LLC

10808 6th ST, Unit 100,  
Rancho Cugamonga, CA 91730