

















## Hardware

## Tools Required


Power tools NOT recommended

NO	Quantity	Accessory
A	4	 Corner Bracket
B	4	 Flat Bracket
C	14	 3.5x30 mm
D	32	 Screw 8X25 mm
E	3	 Center Leg
F	1	 Allen Wrench 5mm
G	4	 Wood leg
H	7	 Screw Pad

NO	Quantity	Accessory
A	4	 Corner Bracket
B	4	 Flat Bracket
C	14	 3.5x30 mm
D	32	 Screw 8X25 mm
E	3	 Center Leg
F	1	 Allen Wrench 5mm
G	4	 Wood leg
H	7	 Screw Pad

### King Bed

### Queen Bed




## Hardware

## Tools Required


Power tools NOT recommended

1


1. Attach brackets (A) and (B) to connect side rails with headboard and footboard using screws (D) and Allen wrench (F).
2. Screw wooden legs (G) with Screw pad (H) into the threaded holes at the bottom of headboard and footboard.
3. Keep screws slightly loose until frame is aligned, then tighten fully.



- 2) 1). Insert the 3 support legs (E) with Screw pad (H) into the designated holes along the underside of the center rail.
- 2). Twist each leg to adjust the height and ensure all legs are at the same level for even support.



- 3) 3) Position the center support rail between the side rails and attach each end of the center rail to the brackets on the side rails.



- 4
- 1). Place the slats evenly across the bed frame.
  - 2). Secure the slats using the screws (B ).
  - 3). The bed is fully assembled and ready to use.

