



OFFICE CHAIR

Assembly Instructions




ASSEMBLY


01




02




03




04




05




06




07



08



09




READ ALL
INSTRUCTIONS
BEFORE USE AND
SAVE FOR FUTURE
REFERENCE

- DO NOT exceed the maximum load capacity of 400 lbs / 181 kg.
- DO NOT use if any part is worn, damaged, or missing. Inspect for signs of wear or damage before use.
- Make sure that the chair is properly assembled before use.
- Check regularly that all parts and hardware of the chair are tightened.
- DO NOT use the chair as a ladder. The chair is not designed to be stood on.
- DO NOT sit on the armrest or edge of the seat to prevent overturn and injury.
- DO NOT allow more than one person in one chair.
- DO NOT put your finger into any part or gap of the chair.
- DO NOT lean against the chair while it is standing.
- DO NOT use for any purpose other than intended.

IN THE BOX




A x1




B x1




C x1




C1 x5




D x1




E x1




G-R x1



G-L x1




F x5



J x1



H x2



Q x1



6 x20MM
L x4+1



6 x25MM
N x2+1



6 x30MM
M x8+2




6 x14MM
W x10+2




Y x4+1

ADJUSTMENT


Headrest Height




Headrest Height



Lumbar Support Height



Armrest Height



Seat Height

