




For convenience and safety, we recommend two people to assemble.  
If you have any questions, please contact our customer service.




# PARTS LIST




1 X1




2 X1




3 X1



4 X1



5 X1




6 X1



7 X1




8 X1




9 X2




10 X2




11 X1




12 X1




13 X1



14 X1



15 X2



16 X1



















17 X2




























18 X1

# PARTS LIST

 <p><b>19X1</b></p>	 <p><b>20X1</b></p>	 <p><b>21X1</b></p>
 <p><b>22X1</b></p>	 <p><b>23X1</b></p>	 <p><b>24X1</b></p>
 <p><b>25X1</b></p>	 <p><b>26X2</b></p>	 <p><b>27X2</b></p>
 <p><b>28X2</b></p>	 <p><b>29X2</b></p>	 <p><b>30X8</b></p>
 <p><b>31X2</b></p>	 <p><b>32X2</b></p>	 <p><b>33X10</b></p>



Please prepare the following tools



**Tips:** The number after "+" represents the spare hardware.

# IMPORTANT NOTES:




The item you are purchasing is a large furniture product that requires a large number of components to assemble.

Please take all parts boxes out of the packaging and place them in order. So that you can follow the steps in the installation manual to find the corresponding parts box and quantity of need when installing. Please do not take too many parts to prevent the parts from scattering.



Please be patient and follow the instructions step by step for installation. If you have any problems during the installation process, you can ask our customer service to help you solve them!




# SAFETY TIPS:

Static charge may cause dust on foam – clean with a dry or damp cloth. Small foam strands may be present – handle gently and dispose of properly. Do not burn or incinerate. Check local recycling guidelines.





Cam Lock/Dowel Placement Supplement		
<p><b>CORRECT</b> 1</p>  <p>When inserting the Cam lock, make sure that the open End of the cam Lock faces the Cam Screw Entry. The Dowel will be inserted in the hole NEXT to the Cam Lock/Cam Screw hole.</p>	<p><b>INCORRECT</b> 2</p>  <p>The Cam Lock is backwards in this illustration. The Cam Screw can not connect to the Cam Lock because the Dowel is in the incorrect hole.</p>	<p>3</p>  <p>To tighten, turn the Cam Lock <b>CLOCKWISE</b> until the arrow or "△" signs point <b>AWAY</b> from the connected board.</p> <p><b>*NOTE: DO NOT USE AN AUTOMATIC SCREWDRIVER TO TIGHTEN CAM LOCKS, DO NOT OVER-TIGHTEN.</b></p>


**1**

<b>A</b>	6PCS	<b>B</b>	6PCS
			



2

<b>D</b>	3 PCS	<b>E</b>	2 PCS	<b>N<sub>1</sub></b>	4 PCS	<b>X<sub>3</sub></b>	2 PCS
							




Align the screw with the pilot hole, then tighten it.






First, insert wooden dowel D into the designated side hole, followed by the installation of other components.



Note: Here is a hole.





Note: Pay attention to the hole orientation of Board 3.




B	2 PCS	D	3 PCS	E	2 PCS
					






4



D	6 PCS	E	8 PCS
			



Watch out for the direction of the board pieces and align them accurately with the holes.


5

<b>LED</b>	1 PC	<b>Y</b>	3 PCS	<b>O1</b>	3 PCS
					







<b>A</b>	2 PCS	<b>E</b>	1 PCS









Note: The hole positions on Board 18 correspond to those on Board 16.




 Ensure the back board is inserted into the slot.

**7**

<b>A</b>	6 PCS	<b>B</b>	8 PCS	<b>N<sub>1</sub></b>	4 PCS	<b>X<sub>3</sub></b>	2 PCS
							






Align the screw with the pilot hole, then tighten it.









<b>A</b>	2 PCS	<b>D</b>	4 PCS	<b>E</b>	6 PCS






<b>B</b>	2 PCS	<b>N1</b>	4 PCS	<b>X3</b>	2 PCS
					








Ensure the back board is inserted into the slot.




Align the screw with the pilot hole, then tighten it.

**10**




A	2 PCS	B	6 PCS	D	4 PCS	E	6 PCS
							









Ensure the back board is inserted into all four slots, then tighten the screws.








**11**

A	4 PCS	B	4 PCS	D	4 PCS
					







**12**

<b>A</b>	6 PCS	<b>D</b>	4 PCS	<b>V<sub>3</sub></b>	4 PCS
					





**13**

<b>B</b>	6 PCS	<b>R</b>	1 PC	<b>N<sub>1</sub></b>	2 PCS
					






Align the screw with the pilot hole, then tighten it.

180°



14


<b>A</b>	6 PCS	<b>D</b>	6 PCS
			





This step is difficult to install.  
Note: Make sure that board 17 is inserted into the groove of board 2 and then fasten A.

This step requires two people to complete




use foam to cushion the bottom of the backplane.





**15**



<b>K4</b>	<b>8 PCS</b>	<b>N2</b>	<b>8 PCS</b>
			

Align the screw with the pilot hole, then tighten it.




**16**

<b>D</b>	8PCS	<b>E</b>	16PCS
			














Ensure that the iron pipe is inserted into the holes of the upper and lower boards, then tighten the screws.





**x2**

**17**


<b>B</b>	8 PCS	<b>I<sub>2</sub></b>	2 PCS	<b>J</b>	4 PCS	<b>N<sub>1</sub></b>	4 PCS	<b>X<sub>4</sub></b>	2 PCS
									




**18**

<b>A</b>	8 PCS	<b>D</b>	8 PCS
			



Note: Board **27** and the door board handle must be on the same side.




Note: Board **26** and the door board handle must be on the same side.



**19**






<b>D</b>	8PCS	<b>E</b>	16PCS
			













⚠ Ensure that the iron pipe is inserted into the holes of the upper and lower boards, then tighten the screws.



**x2**

**20**


<b>B</b>	12 PCS	<b>I<sub>2</sub></b>	2 PCS	<b>J</b>	4 PCS	<b>N<sub>1</sub></b>	8 PCS	<b>X<sub>4</sub></b>	4 PCS
									




**21**

<b>A</b>	12 PCS	<b>D</b>	8 PCS
			



Note: Board **29** and the door board handle must be on the same side.



Note: Board **28** and the door board handle must be on the same side.







**22**



<b>F</b>	8PCS	<b>O<sub>3</sub></b>	24PCS
			

Align the screw with the pilot hole, then tighten it.


\*NOTE:Hinge axis facing outward






**23**



This step requires two people to complete




**24**





Open the door beneath  
and install the shelf pins.

**25**



Align the holes at the bottom of the shelf with the shelf pegs, then press down.


**26**

<b>Q</b>	20 PCS	<b>N7</b>	20 PCS
			


Installing back board fasteners can improve the overall stability of the furniture. It ensures the verticality of the furniture and that the door boards are level, so that the gaps are uniform.

Also, you can adjust the level of the cabinet by using the adjustable feet at the bottom of the furniture to make the gaps between the cabinet door boards even.

During the adjustment process, you should first place the furniture in the position where it is needed. Otherwise, when you move it to that position after adjustment, you may encounter an uneven floor.




# 27



Warning: If you overturn the furniture, it may cause serious or fatal crushing injuries. We have a wall connection device attached, please use it to hold the furniture following these instructions.

1. Mark the corresponding hole positions where you want to place the furniture;
2. Use a impact drill to drill holes and pay attention to avoid wires and water pipes;
3. Knock the expansion pipes into the wall holes;
4. Place the furniture in the corresponding position and tighten the wall connection device with screws.



Place sticker (C) on the hole.

## Final Assembly