




































Accessories

Name		Picture	Qty	Name		Picture	Qty
1	Side panel		2	11	Floor		1
2	Kick plate		2	12	Left glass door		1
3	Left back panel		1	13	Right glass door		1
4	Right back panel		1	14	Waist plate		1
5	Top panel		1	15-1	Top waist face		1
				15-2	Lower waist face		1
6	Shelf		2	16	Guide rail bracket		2
7	Dome front tube		1	17	Drawer front panel		1
8	Dome panel		1	18	Drawer bucket		1
9	Dome back tube		1	19	Drawer seal		1
10	Dome back panel		1	20	Left steel door		1

Accessories

Name		Picture	Qty	Name		Picture	Qty
21	Right steel door		1				
A	13/32 Screw		64	G	M4*5 screw		2
B	M5 Nut		3	H-1	Left guide rail		1
				H-2	Right guide rail		1
C	M5*10 Screw		3	I	Expansion screw		2
D	Shelf clasp		8	J	Magnet		8
E	The doorknob		5	K	Door pivot		4
F	M4*22 screw		8	L	Shim		8



CAUTION

An assistant is required.


If there is any problem, please feel free to contact our customer service team and we are always here to assist with you!

If there is any slight dent or damage, you can try to fix it by pliers or hammers.

Step 1

Insert side panels 1 into kick plates 2 and fix them with screws A

Ⓐ  × 4




The door shaft hole is in the front

Step 2

Connect left back panel 3 with side panel 1 and kick plate 2 by screws A

Ⓐ  × 4




Step 3

Connect right back panel 4 with side panel 1 and kick plate 2 by screws A, then connect two back panels 3 and 4 with nuts B and screws C

(A)  × 4

(B)  × 3


(C)  × 3



Step 4

Install waist faces 15 on the left side panel with screws A


Ⓐ  × 4



Step 5

Install waist faces 15 on the right side panel with screws A

(A)  × 4




Step 6

Install the guide rail brackets 16 on both side panels with screws A, then install the guide rails H

(A)  × 4

Attention: the direction!


Insert the back of rail to the hole of the back panel, then align the front hook of another side (the slider can be pull out) to the rectangle hole of bracket 16, press down and insert into the hole.



Step 7


Install waist panel 14 with screws A

Ⓐ  × 4



Step 8




Unfold drawer bucket 18 and fold the small parts







Step 9

Then install drawer panel 17 with 4 screws A, and install drawer seals 19 with 2 screws A (put in the front of 19 firstly)


Fix the doornob E to the drawer with screws G

- (A)  × 6
- (E)  × 1
- (G)  × 2



Step 10

Install the assembled drawer in the cabinet



There are 2 ways to install the drawer.

Option 1: First, completely pull out the slide rails of the left and right side panels, and place the drawer above the inner side of the slide rails. Make sure that the hanging holes in the front on both sides of the drawer are aligned with the hooks of the slide rails, connect them first, then press down the end holes to make the hooks fully enter the hanging holes.


Option 2: Completely pull out the slide rail, find the small black part on the front rail, put it upward or downward to divide the rail to 2 parts. Attach the front part on the drawer side panel, so as the another side. Then align the rails on the side panels A and drawer sides and push it.

Pull out the drawer twice slowly and the lubricating oil inside the slide rails will come out and the drawer will work.

Step 11

Connect top panel 5 with back panels and side panels by screws A

(A)  × 8



Step 12


Install the shelf clasps D and put the shelves 6 on them

Tilt floor 11 into the cabinet and press it down to snugly fit against the kick plate (No screws are needed to fix the floor)

Install 8 magnets J on the top and bottom as shown below





ⓓ  × 8


ⓐ  × 8



Step 13





Insert the door pivots K into the holes of the both sides of the bottom corners(shims L can be used to adjust), then insert the doors into the door pivots on the bottom and adjust the spring shaft on the top
Install 2 doorknobs E on the doors with screws F


(K)		× 2
(L)		× 4
(F)		× 4
(E)		× 2



Step 14

Install the doornobs E and doors 12 and 13 with the same steps in the previous step


(K)		× 2
(L)		× 4
(F)		× 4
(E)		× 2



Step 15

Fold all the small parts on dome panel 8 towards the middle for 90 degree

Insert dome panel 8 into dome back tube 9 and dome front tube 7




Step 16

Fix the dome panels and tubes with 10 screws

A in the middle and ends

Fix the dome back panel 10 with 5 screws A


Ⓐ  × 15



Step 17


Fix the dome on the top of the cabinet with screws A, then adjust the feet of the cabinet

(A)  × 7



Step 18

Fix the cabinet to the wall with screws
I to prevent tipping

①  × 2

