




# Product Installation Instructions







Ax1




Bx2




Cx1




Dx1




Ex1




Fx2




Gx2




Hx1




Ix2




Jx1




Kx2




Lx1




Mx1




Nx1




Ox1




Px2




Qx1




Rx1




Sx1




Tx1
























Ux1




Vx1



1

①		Two In One Screw (6x28mm)	78pcs +4pcs
②		Two In One Nut (10x12mm)	78pcs +4pcs
③		Wood Chipping (6x30mm)	32pcs +4pcs
④		Non-slip pads	12pcs +2pcs
⑤		Wire Clamp	2pcs
⑥		Fixing Clip & Screw (3x16mm)	8pcs +1pcs
⑦		Laminate support nail	8pcs
⑧		Power Socket & Screw (3x10mm)	2pcs 1pcs
⑨		Rebound Device & Screw (4x12mm)	16pcs +2pcs 2pcs
⑩		Screw & Guide(12 inch) (3x12mm)	2pcs 10pcs +2pcs
⑪		Iron guide rail	1pcs
⑫		Iron guide rail hook	4pcs
⑬		Plastic slide	4pcs
⑭		Screw & Plastic hoses (6x28mm)	4pcs
⑮		Screw (6x12mm)	8pcs +1pcs
⑯		Screw (3.5x12mm)	8pcs +1pcs
⑰		Concealed lock & Screw (3x12mm)	6pcs +1pcs 1pcs
⑱		Screw (4x25mm)	6pcs +1pcs
<div><div> 1pcs</div><div> Double-head screwdriver, use as required</div><div></div></div>			


# Product structure decomposition






Use parts ① and ②




Step1



Step2




Step3





Use a screwdriver to lock in the direction of the "+" sign

Disassemble along the direction of "-" sign


Step 1




- ①  x8
- ②  x8

Step 2


1

x12




Step 3


2

x12



4

x4



Tear off release paper and stick the black foot pad on the board



Step 4




Step 5







Step 6

17


  
x1


  
x2



Step 7


2


  
x2




Step 8

- 1


x6
- 3


x2



Step 9



- 2

x6







Step 10




Step 11




Step 12

2




x2




Step 13

1




x6

2




x4

3





x4




Step 14

- 1

x4
- 3


x4




x2

Step 15

- 2


x4






Step 16

2




x6




Step 17

1




x3

2




x3




Step 18

18




x3




Step 19

1




x7

3




x3






## Step 20

2




x7


Slightly pull upwards before installation




Step 21

- 1


x3
- 2


x3



Step 22


- 18


x3




Step 23

- 1


x7
- 3

x3




## Step 24

2




x7







Step 25

8




x1

x2







Step 26






Step 27

- ③  x8




Step 28

- ①  x10
- ③  x8





Step 29


2




x10




Step 30

7  x8







Step 31






Step 32



## Step 33




11

x1





14


x4





The screw is threaded through the iron guide rail, then through the rubber hose, and then installed in place


Step 34

- |    |   |    |
|----|---|----|
| 13 |  | x2 |
| 16 |  | x4 |




Step 35

- |    |   |    |
|----|---|----|
| 13 |  | x2 |
| 16 |  | x4 |








Step 36






Step 37

- |    |   |    |
|----|---|----|
| 12 |   | x4 |
| 15 |  | x8 |





# Drawer rail breakdown diagram






Step 1 : Pull the rails apart

Step 2 : Push the nylon buckle outward ①




## Step 38






## Step 39

10



x2








This hole is for strengthening fixed hole customers can choose to install according to their needs.



Step 40




- |  |  |
|--|--|
|     |  |
| ⑩ x2   | x4   |
| ⑪⑦  | x1   |
| ⑪⑦  | x4   |






## Step 41





Move the sliding ball to the position shown in the picture



Push in





If any problems are found after installing the Q board, you can move the slide up and down to adjust it





## Step 42



Please note that the screw holes cannot be tightened during installation and require adjustment positions for adjustment



# Effect 1

Attention: Please review the following two effects before selecting the location where you want to install

## Step 43







Step 44


# Effect 1

9



If there is a large gap found after the installation of the R board, the screws can be adjusted to adjust the gap

Step 45




Push in the opposite direction of opening






## Step 46

Please note that the screw holes cannot be tightened during installation and require adjustment positions for adjustment

9




## Effect 2




## Step 47

4



Tear off release paper and stick the black foot pad on the board








Step 48

# Effect 2

9




If there is a large gap found after the installation of the R board, the screws can be adjusted to adjust the gap

Step 49

Pull the R board up


open

Pull



pushdown

push




Push in the opposite direction of opening





Step 50

17



x1


lock



x1

17

Open lock





Place the magnetic key  
above the hidden lock





Step 51

6

  
x8

  
x8





## User's Guide

Thank you for purchasing this product.

To use this product, please plug it into a 12V DC power supply.

Please use if the product works normally after connecting to power.

## Introduction

The box is an intelligent controller. It has 1 USB output port 1 Type-c port and can distribute the current output up to 5V DC-2A. With 2 touch buttons, it can turn. ON/OFF the light, change light colors, and adjust the light luminance.

## Operation




This touch button is used to turn on/off, change colors, and adjust brightness.

- A. Short touch -> lighting on -> short touch -> change light color -> short touch -> change light color -> short touch -> lighting off.
- B. Long touch -> adjust the luminance.



This touch button is used to turn on/off the induction function.

- A. Short touch to turn on the induction function. It can auto-turn on the light when people are close to the controller in 1 meters. It can auto power off the light when the body is far away from the controller after 30 seconds.
- B. Long touch to turn off the induction function.
- C. Note: When you touch the light button to change the light modes, the induction function will automatically turn off. It is best to turn on this function after selecting the light color and adjusting the brightness you want.



### ATTENTION PLEASE

1. If there is no touch response suddenly, Re-plug the power to reset the touch static electricity.
2. If you have any questions when installing, please feel free to contact us. Thank you.