










## CARE AND MAINTENANCE

Leather surfaces on Safavieh Furniture should be dusted regularly with a dry or slightly damp soft cloth. Avoid using saddle soap or other cleaners. Leather desks and tabletops have a lacquer coating, therefore they can be lightly waxed. Suede surfaces should only be cleaned with a dry, stiff brush. Exposure to liquid spills should be avoided since suede cannot be washed or cleaned like leather. 100% Safavieh Bicast Leather.


## NOTICE

- \* Please make sure that you have all parts indicated before you begin assembly of this item
- \* This item should be assembled on a soft surface to prevent scratching the finish during assembly
- \* This item may require periodic tightening

## Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	SEAT		1X
B	STEEL FRAME		1X
C	STEEL FRAME		1X
HW1	Gold Flat Hex bolt 4x1x25MM		1X
HW2	Hex bolt 4x1x12MM		1X
HW3	Hex bolt 4x1x18MM		4X
HW4	Flange(Nut+Washer) 7mm		1X
HW5	Allen key M6		1X
HW6	Hexagon Wrench		1X

Product Dimensions:W28.3"XD23.2"XH33"



 **WARNING:**  
**WEIGHT CAPACITY 260 LBS.**  
**NO NOT STAND ON CHAIR**


## PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.


If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 10 minutes.


Tools Required for Assembly (included): Allen Key and Hexagon Wrench




**Step 1**  
Pls find the part B and C, then assemble same as the picture in cross, and use Allen key (HW5) and Hex bolts (HW2) for assembled at last.



**Step 2**  
Assemble the bottom of frame for using Allen key (HW5) with Gold Flat Hex bolt (HW1). Then lock the Hexagon Wrench (HW6) with Flange (HW4).



**Step 3**  
Put the frame in the bottom of seat (A). Then use the Allen key (HW5) with Hex bolts (HW3).



**Step 4**  
Assembled finishing