



End Table

Assembly Instructions - Please keep for future reference



Dimensions

Width - 17.7inch
Depth - 17.7inch
Height - 23.62inch

Important – Please read these instructions fully before starting assembly

Issue 1 - 29/05/2025



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close (room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



- To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure that all bolts and fittings are tightened properly.

WARNING In order to help prevent overturning – please follow these instructions


To help prevent product toppling over please follow the below steps:-

- Use the anti tip strap or wall fixing method provided (if applicable)
- Do not allow children to climb or hang on the furniture
- Do not open more than one drawer at a time
- Do not place heavy items in the top drawers
- Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose


You will need to provide wall plugs and screws applicable for your wall type

Components - Panels

Please check you have all the panels listed below




1 (477X417X14mm)X2




2 (477X417X14mm)X2




3 (477X50X14mm)X4




4 (300X40X35mm)X8




5 (415X386X14mm)X2




6 (394X321X2.5mm)X2




7 (85*50X50mm)X8




8 (314*45X14mm)X4




9 (331X45X14mm)X4




10 (450X450X14mm)X2




11 (394X158X2.5mm)X2




12 (450X450X24mm)X2




13 (310X160X14mm)X4




14 (300X120X12mm)X4



15 (300X120X12mm)X4



16 (295X274X2.5mm)X4














17 (266X120X12mm)X4


Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. in some cases more fittings may be supplied than are required.


A  Cam Bolt x 80	B  Cam Lock x 80	C  Wooden Dowel x 48
D  Drawer slider 12" x 8	E  3.5*12mm Screw x 36	F  4*35mm Screw x 16
G  Handle & Fixings x 4	H  Back Panel Stiffener x 16	I  Protective Feet x 8
J  Socket x 2	K  6x35mm Bolt x 24	

Tools required



Phillips screwdriver
(medium & large)

Ruler - Use this ruler to help correctly identify the screws




The screws length is measured from the head to the point (30mm screw shown).

Using camlocks


Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.




Step 2

Push the male camlock into the entry hole.



Step 3

Insert the female camlock as shown in the instructions.
Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.




Step 4


Turn the female camlock clockwise with a screwdriver.

You should feel a click when the camlock is locked in place.

The joint is now secure.





Assembly Instructions



Assembly Instructions





Step 1



Step 2

CAM-LOCK

Tighten until shoulder is flush with panel. Do not overtighten or undertighten (see example below)



X2



Attach cam bolt (A) to Parts (3) with a screwdriver.

Assembly Instructions

Step 3

CAM-LOCK


Tighten until shoulder is flush with panel. Do not overtighten or undertighten (see example below)




A x 8



C x 40



X2



Attach cam bolt (A) to Parts (1, 2) with a screwdriver.
Insert wooden dowel (C) into Parts (1, 2).

Assembly Instructions


Step 4

B



B x 4

X2



Attach Part (3) to Part (1), then insert Female Cam Lock (B) and secure.


Step 5

B



B x 4


X2



Attach Part (3) to Part (2), then insert Female Cam Lock (B) and secure.


Assembly Instructions

Step 6



Attach Parts (4) to Parts (1, 2), using Bolt (K) with a screwdriver.
Note: Pay attention to the direction of the arrow on the Parts (4)


Step 7




Attach Drawer slider (D1) to Parts (4), align the pre-hole of Parts (4) using Screw (E) with a screwdriver

Assembly Instructions

Step 8




C 
C x 8

X2


Insert wooden dowel (C) into Part (5).

Step 9



B 
B x 4



X2



Attach Part (5) to Part (2), then insert Female Cam Lock (B) and secure.


Assembly Instructions

Step 10



Attach Part (1) to Part (5), then insert Female Cam Lock (B) and secure.

Step 11





Insert Part (6) into the groove of Parts (1, 2, 5).

Assembly Instructions


Step 12

CAM-LOCK

Tighten until shoulder is flush with panel. Do not overtighten or undertighten (see example below)



A x 16





Attach cam bolt (A) to Part (7) with a screwdriver.

Step 13



B x 16





Attach Parts (7) to Parts (8, 9), then insert Female Cam Lock (B) and secure.

Assembly Instructions


Step 14

CAM-LOCK

Tighten until shoulder is flush with panel. Do not overtighten or undertighten (see example below)




A x 16




X2

Attach cam bolt (A) to Part (10) with a screwdriver.

Step 15



K x 8




X2

Attach Part (10) to Pre-assembled Bottom Frame (7, 8, 9). Insert the Bolts (K) into Parts (7) through the Part (10) tighten them with a screwdriver.

Assembly Instructions

Step 16

I 
J x 8




X2


Insert protective feet (I)

Step 17

B 
B x 8



X2





Insert Female Cam Lock (B) to Parts (8, 9) and twist to secure.

Assembly Instructions

Step 18

CAM-LOCK


Tighten until shoulder is flush with panel. Do not overtighten or undertighten (see example below)




X2

Attach cam bolt (A) to Part (10) with a screwdriver.

Step 19




X2



Attach Parts (1, 2) to Part (10), then insert Female Cam Lock (B) and secure.

Assembly Instructions

Step 20








X2

Insert Part (11) into the groove of Parts (1, 2, 5).

Step 21

CAM-LOCK

Tighten until shoulder is flush with panel. Do not overtighten or undertighten (see example below)




X2

Attach cam bolt (A) to Part (12) with a screwdriver.


Assembly Instructions

Step 22



Insert Part (12) to Parts (1, 2, 11)
then insert Female Cam lock (B) to Part (1, 2) and secure.

Step 23



Insert Part (J) to Part (12) using Screw (E) with a screwdriver.

Assembly Instructions

Step 24

E





E x 16

D2



D2 x 8



X4


Attach Drawer slider (D2) to Parts (14, 15) using Screw (E) with a screwdriver.

Step 25

A



A x 16




X4

Attach cam bolt (A) to Part (13) with a screwdriver.


Assembly Instructions

Step 26



Insert Parts (14, 15) to Part (13) then insert Female Cam lock (B) and secure.



Step 27



Insert Part (16) into the groove of Parts (14, 15).

Assembly Instructions



Step 28



X4

Insert screw (F) into the pre-drilled on Parts (14,15), tighten it with a screwdriver

Step 29




X4

Attach Handle (G) to Part (13) using Screw (G) with a screwdriver.

Assembly Instructions

Step 30




X2





Attention:

1. Align the slide runners on the drawer with the unit and push it carefully inside until it stops.

★ If the drawer does not go in smoothly please take it out and repeat the step.



Step 31



X2

Insert Plastic wedge (H) to the back panel using Screw (H).
The position in the manual for your reference.

Assembly Instructions

Step 32



X2

Assembly is complete.