



## Assembly Instructions




# General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
- V. The provided glue is to secure wood dowels in place . When first inserting dowels , locate the appropriate hole for the dowel , place a small amount of glue in the hole and insert the dowel . Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together , place a small amount of glue on the end of the dowel before attaching parts together . Wipe away excess glue immediately.




- VI. A Phillips head screwdriver is required for the assembly of this product .




- VI. Power tools should not be used to assemble this product .




- VII. Concealed hinges are three-way adjustable.



Horizontal  
by screw adjustment




In-and-Out  
by loosening the hinge-arm  
mounting screw or via cam  
adjustment


























Vertical  
Via slots in the mounting  
plate or via cam adjustment

# Parts List



# Hardware List


A		Ø8x30mm	Wooden dowel	30 pcs
B		Ø6x35mm	Cam lock	26 pcs
C		Ø15x11mm	Cam lock	26 pcs
D		Ø30mm	Sticker	26 pcs
E			magnetic bump	2 pcs
F		Ø3x15mm	Screw	4 pcs
G		Ø4x32mm	Screw	2 pcs
H			Angular Code	3 pcs
I		M6*12mm	Screw	8 pcs
J			Gasket	2 pcs
K			Anti-tipping iron sheet	2 pcs
L			house lizard	2 pcs
M		Ø4x25mm	Screw	2 pcs
N		M 4	Hex Key	1 pc
O		Ø6x50mm	Bolt	4 pcs
P		Ø8x5x16mm	Shelf support pin	8 pcs
Q			Door hinges	8 pcs
S		Ø3x12mm	Screw	40 pcs
T			Hold hands	4 pcs
U		Ø4x19mm	Screw	8 pcs
V			Magnetic nail	4 pcs
W			Small White Glue	1 pc




Philips head screwdriver required for assembly  
(not included)


*The hardware quantities listed above are required for proper assembly.  
Some extra hardware may also have been included.*

# Step 1






A

X30

## Step 2






# Step 3





F	E
	
X4	X2

## Step 4






G

X2


# Step 5






C
X2


# Step 6




C

X5



# Step 7




C

X4




# Step 8




N	O
	
X1	X4



# Step 9





I	H	N
		
X3	X3	X1


# Step10





N	I
	
X1	X3


# Step 11





C

X4

# Step 12




C

X7

# Step 13





# Step 14




D
O
X26

# Step 15






P

X8

## Step 16





# Step 17




S	Q
	
X24	X8




## Step 18




S

X8


# Step 19




V	U	T
		
X2	X4	X2




## Step 20



S

X8


# Step 21




V	U	T
		
X2	X4	X2

## Step 22

**Make two holes 40MM deep**



## Step 23









L



X2

# Step 24



N	M	K	J	I
				
X1	X2	X2	X2	X2

## Step 25

