





HLG083

Version: 1.0




EN_IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.


USING CAM LOCK AND QUICKFIT




EN_QUICKFIT: Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.



EN_CAM LOCK: When fitting cam lock, ensure starting position is correct before you insert connecting quickfit.
















EN_Quickfit head should be in the centre of the cam lock when the two panels are joined.
Cam lock should be inserted before quickfit.





















EN_Turn cam lock clockwise to tighten.




PACKING DELALS

NO.	PARTS	QTY	SPARE
①		x1	
②		x1	
③		x1	
④		x1	
⑤		x1	
⑥		x1	
⑦		x1	
⑧		x2	
⑨		x1	
⑩		x2	

NO.	PARTS	QTY	SPARE
⑪		x4	
⑫		x2	
	 Hardware Kit		




<p>A x8 Ø6x35mm</p> 	<p>B x8 Ø15x10mm</p> 	<p>C x18 Ø6x30mm +1(spare)</p> 	<p>D x8 Ø4x35mm</p> 	<p>E x48 Ø3.5x12mm +4(spare)</p> 	<p>F x4</p> 
<p>G x2</p> <p>G-1 G-2 G-3</p> 	<p>H x8 Ø3x16mm</p> <p>H-1 H-2</p> 	<p>I x6</p> 	<p>J x2 Ø4x14mm</p> <p>J-1 J-2</p> 	<p>K x2</p> <p>K-1 K-2</p> 	<p>L x12 Ø15mm</p> 
<p>M x8 Ø5x35mm</p> 	<p>N x4</p> 	<p>O x4</p> 	<p>P x4</p> 	<p>Q x4 Ø6x80mm</p> 	



B x4



02





E x12

I x6

Q x4


P x4

03




C x8

04




E x12

05





F x4




M x8

L x8





C x4

D x4






Pay attention to the position of the slot





D x4

L x4




A x4




B x4



C x6



O x4





E x8







G x2



N x4









To adjust the vertical height.

Loosen the four screws "p" on both hinges. Two of them are usually in slotted holes which allows you to adjust up or down by a few mm. Then tighten back up.



To adjust depth.

Loosen screw "b" and adjust door, if the door can not be adjusted, please loosen screw "c", then try again. Tighten screw "b" and "c".



To adjust side ways.

Turning the screw "c" on BOTH hinges on each door.




H x8





H-1




H-2







First fix the anti-rewind screw in the reserved hole of the product.




then, use a ruler to measure the approximate height of the product on the wall, and then mark it with a pen.



Then use a tape drill to make holes in the wall that are suitable for the product screws.



Then, put the expansion bolt into the hole



Finally, pass the matching screws through the "anti-rewind" and tighten them to fix them on the wall.

